

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AMZCHEF](#) /

› [AMZCHEF Espresso Machine with LCD Display, 20 Bar Cappuccino Machines with Automatic Milk Frother for Home Gifts, Latte Coffee Maker with Dual Wall & ESE Filters, Stainless Steel Style](#)

AMZCHEF CM1636-SV

AMZCHEF Espresso Machine User Manual

MODEL: CM1636-SV

Your guide to perfect coffee creations.

Introduction

The AMZCHEF Espresso Machine is designed to bring barista-quality coffee to your home. Featuring a 20-bar high-pressure pump, an intuitive LCD display, and an automatic milk frothing system, this machine allows you to effortlessly prepare espresso, cappuccino, and latte with customizable settings. Its sleek stainless steel design and user-friendly features make it a valuable addition to any kitchen.

Safety Instructions

- Always read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only original accessories provided by the manufacturer.
- This appliance is for household use only.
- Keep hands and cords away from hot parts of the appliance during operation.
- Ensure the frothing wand is free from residual water before making milk-based drinks.
- The machine is in a high temperature state during and after use. Do not touch the brewing head, and the metal part of the steam rod.

Package Contents

Your AMZCHEF Espresso Machine package includes:

- Espresso coffee machine
- 24 oz Detachable Milk Frother

- 61 oz detachable water tank
- Single cup brewing filter
- Double cup brewing filter
- Pod filter
- Spoon
- User manual



The AMZCHEF Espresso Machine and its complete set of accessories, including the milk frother, water tank, filters, and spoon.

Setup

Initial Cleaning

Before first use, thoroughly clean all detachable parts of the machine, including the milk reservoir, water tank, filter holder, and filters, with warm soapy water. Rinse well and dry.

Your browser does not support the video tag.

Video demonstrating the initial cleaning process for the detachable components of the espresso machine before first use.

Priming the Machine

After cleaning, fill the water tank with fresh water and the milk reservoir with water. Place a cup under the brewing head. Turn on the machine and press the Espresso button once to run hot water through the system. This primes the machine and removes any residual manufacturing dust.

Your browser does not support the video tag.

Video showing the priming process of the espresso machine by running water through it for the first use.

Operating Instructions

The AMZCHEF Espresso Machine offers various options for your coffee preferences. The LCD display provides real-time information on temperature and brewing status.



AUTOMATIC MILK FROTHING SYSTEM

Ours | Create milk foam and shut off automatically

Others | Create milk foam manually

Close-up view of the LCD display and control buttons for Espresso, Cappuccino, and Latte.

Making Espresso

Fill the filter with your desired amount of coffee grounds (single or double shot) and tamp firmly. Insert the filter holder into the machine and lock it into place. Place your cup(s) on the drip tray. Press the "Espresso" button once for a single shot or twice for a larger serving.

Your browser does not support the video tag.

Video tutorial on how to prepare espresso, cappuccino, and latte using the machine's automatic functions.

Making Cappuccino and Latte

For cappuccino or latte, ensure the milk reservoir is filled with chilled full-fat milk for optimal froth. Insert the filter holder with coffee grounds. Place your cup under the brewing head. Press the "Cappuccino" or "Latte" button once for a standard serving or twice for a larger cup. The machine will automatically dispense milk and then coffee.

CHOOSE THE COFFEE YOU WANT

Instant one-button creation of espresso, latte, and cappuccino



Visual representation of the one-button selection for Espresso, Cappuccino, and Latte.

Customizing Volume

You can customize the volume of your coffee. For specific volume adjustments, refer to the detailed instructions in the full user manual. The machine also supports manual control for precise coffee amount.

Your browser does not support the video tag.

Video demonstrating how to set and customize the volume for your coffee beverages.



20 BAR ITALIAN PUMP FOR BREWING OPTIMAL FLAVOR

Diagram showing options for 1 shot (1.02 oz), 2 shots (2.05 oz), and manual control for coffee volume.

Maintenance & Cleaning

Regular cleaning ensures optimal performance and longevity of your espresso machine.

Automatic Cleaning Function

The machine features a built-in automatic cleaning function, especially useful after preparing milk-based drinks. To activate, press and hold the Latte button for 3 seconds. This will run hot water through the milk dispensing tube to clean

it.

Your browser does not support the video tag.

Video demonstrating the automatic cleaning function of the machine, particularly for the milk frother.

Cooling Down the Machine

If the machine indicates an overheat alert, follow the cooling down procedure outlined in the full manual. This typically involves running water through the system to lower the internal temperature.

Your browser does not support the video tag.

Video showing the process to cool down the machine, which is important for optimal performance and safety.

Detachable Components

The detachable drip tray and milk frother components are designed for easy cleaning. Regularly remove and wash them to prevent residue buildup.



**ESPRESSO
VOLUMETRIC
CONTROL**

The image shows a silver AMZCHEF espresso machine with a digital display showing '198'. The machine is dispensing coffee into a glass cup. To the left, two more glasses of coffee are shown on a tray. The machine has buttons for 'ON/OFF', 'Espresso', 'Cappuccino', and 'Latte'. A 'Lock' button is also visible. The AMZCHEF logo is on the front of the machine.

 1 Shot 1.02 oz	 2 Shot 2.05 oz	 Manual Control the amount of coffee by yourself
---	---	--

Overview of the detachable parts: 24 oz Detachable Milk Frother, Cup Warmer Plate, Detachable Drip Tray, and 61 oz Removable Water Reservoir.

Troubleshooting

If you encounter any issues with your AMZCHEF Espresso Machine, please refer to the troubleshooting section in the comprehensive user manual for detailed solutions. Common issues may include:

- Machine not turning on.
- Coffee not brewing.
- Milk not frothing correctly.
- Leaks or unusual noises.
- Error codes on the LCD display.

For persistent problems, please contact AMZCHEF customer support.

Specifications

Brand	AMZCHEF
Model Name	Espresso Machine with Automatic Milk Frother
Item Model Number	CM1636-SV
Color	Silver
Product Dimensions	13"D x 6.5"W x 12"H
Item Weight	12 pounds
Pressure	20 Bar
Voltage	120 Volts (AC)
Operation Mode	Fully Automatic
Filter Type	Dual Wall & ESE
Special Features	Smart Overheating Alerts, Automatic Milk Frothing System, Intelligent LCD Control

Warranty and Support

Most AMZCHEF products are guaranteed for a year from the date of purchase. For any inquiries, technical assistance, or warranty claims, our customer service team is available 24 hours a day to provide quality service and ensure a good user experience.

Please refer to the contact information provided in your purchase documentation or visit the official AMZCHEF website for support.

