

[Manuals.plus](#) /

› [Anmutig](#) /

› Anmutig Patio Swivel Dining Chairs Instruction Manual

Anmutig Patio Swivel Dining Chairs (Set of 2)

Anmutig Patio Swivel Dining Chairs Instruction Manual

Model: Patio Swivel Dining Chairs (Set of 2)

1. INTRODUCTION

Thank you for choosing Anmutig Patio Swivel Dining Chairs. This manual provides essential information for the safe assembly, operation, and maintenance of your new chairs. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: Anmutig Patio Swivel Dining Chairs in an outdoor setting.

2. SAFETY INFORMATION

To ensure safe use of your Anmutig Patio Swivel Dining Chairs, please observe the following safety guidelines:

- **Weight Capacity:** Each chair is designed to support a maximum weight of **300 lbs (136 kg)**. Do not exceed this limit to prevent injury or damage to the chair.
- **Swivel Function:** The 360° swivel mechanism is designed for smooth rotation. Avoid sudden, forceful movements that could destabilize the chair.
- **Rocking Motion:** The 15° rocking motion is gentle. Do not attempt to rock excessively or beyond the intended range, as this may lead to tipping.
- **Assembly:** Ensure all parts are correctly assembled and all fasteners are securely tightened before use. Periodically check fasteners for tightness.
- **Placement:** Place chairs on a flat, stable surface. Avoid uneven ground that could cause instability.

- **Children:** Supervise children when they are using or near the chairs to prevent accidents.
- **Maintenance:** Regularly inspect the chairs for any signs of wear, damage, or loose components. Discontinue use if any damage is found and contact customer support.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact Anmutig customer support.

- Chair Body (Seat and Backrest Assembly)
- Swivel Base
- Hardware Pack (bolts, washers, nuts, Allen wrench)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward, typically taking approximately 25 minutes per chair. All parts are labeled, and a step-by-step manual is included in the package. It is recommended to keep all bolts slightly loose until the entire chair is assembled, then tighten them securely.

1. **Step 1: Assemble the Swivel Base.** Attach the legs to the central swivel mechanism according to the diagrams provided in your included manual.
2. **Step 2: Attach the Chair Body.** Secure the seat and backrest assembly to the upper part of the swivel mechanism.
3. **Step 3: Connect Base to Chair Body.** Join the assembled swivel base to the chair body, ensuring all connection points align.
4. **Final Tightening:** Once all parts are in place, securely tighten all bolts using the provided Allen wrench. Do not overtighten.



Image 4.1: Visual guide for the 3-step assembly process.

5. OPERATING INSTRUCTIONS

Your Anmutig Patio Swivel Dining Chairs are designed for comfort and flexibility with two primary motion features:

- **360° Swivel:** The chair seat can rotate a full 360 degrees. To swivel, simply apply gentle pressure with your feet or body in the desired direction. The mechanism is designed for smooth, quiet rotation.
- **15° Rocking Motion:** The chair also features a gentle 15-degree rocking motion. Lean back slightly to engage the rocking function. This motion is intended for subtle relaxation, not vigorous rocking.

BREATHABLE FABRIC

Premium textile mesh fabric which is not only comfortable but also dries quickly in outdoors



Quick Drying



Weather Resistant



Anti-fading




Image 5.1: Illustration of the chair's swivel and rocking capabilities.

6. MAINTENANCE

Proper care will extend the life and appearance of your chairs:

- **Cleaning:** The Textilene fabric and powder-coated steel frame are easy to clean. Simply wipe clean with a damp cloth and mild soap. For deeper cleaning, the chairs can be power washed and will dry quickly. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Care:** The Textilene mesh fabric is weather-resistant, quick-drying, and anti-fading. Regular cleaning helps maintain its vibrant color and breathability.
- **Frame Care:** The powder-coated steel frame is rust-resistant. Inspect the frame periodically for any scratches or chips in the coating that could expose the metal to moisture. Touch up any damage as needed to prevent rust.
- **Seasonal Storage:** While designed for outdoor use, storing the chairs indoors or covering them during extreme weather conditions (heavy snow, prolonged rain, strong winds) will further prolong their lifespan.

80% Assembled

4 PARTS 3 STEPS 25 MINS



25 MIN EASY INSTALLATION



STEP 1



STEP 2



STEP 3

Image 6.1: Features of the breathable, quick-drying, and weather-resistant Textilene fabric.



Image 6.2: Illustration of the multi-layer rust-resistant coating on the steel frame.

7. TROUBLESHOOTING

If you encounter any issues with your chairs, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair feels unstable or wobbly	Loose fasteners; uneven ground	Check and tighten all bolts. Ensure the chair is on a flat, level surface.
Swivel or rocking motion is stiff	Mechanism needs lubrication; debris in mechanism	Apply a silicone-based lubricant to the swivel and rocking components. Clean any visible debris.
Missing parts during assembly	Packaging error	Contact Anmutig customer support immediately with your purchase details.
Difficulty tightening bolts	Paint/powder coat in threaded holes; misaligned parts	Ensure parts are correctly aligned. If paint is obstructing, carefully clear the threads. Use a ratchet for better leverage if needed, but do not overtighten.

8. SPECIFICATIONS

Key specifications for the Anmutig Patio Swivel Dining Chairs:

- **Brand:** Anmutig
- **Model Name:** Swivel chair
- **Color:** Tan Grey (for this specific variant)
- **Material:** Powder-Coated Steel Frame, Textilene Fabric
- **Product Dimensions (D x W x H):** 22.8" x 22.8" x 40"
- **Seat Depth:** 19.3 inches
- **Seat Height:** 17.7 inches
- **Item Weight:** Approximately 48.4 pounds (per chair)
- **Maximum Weight Recommendation:** 300 pounds
- **Features:** 360° Swivel, 15° Rocking Design, Breathable Fabric, Rust-Resistant Frame, Curved Armrests
- **Indoor/Outdoor Usage:** Outdoor
- **Product Care Instructions:** Wipe Clean

360° SWIVEL & 15° ROCKING



SWIVEL MOVEMENT



SMOOTH ROCKING
MOTION



ROCK BACK & FORTH

Relaxing swing of a rocker

Image 8.1: Detailed dimensions of the swivel dining chair.

9. WARRANTY AND SUPPORT

Anmutig stands behind the quality of its products. For any warranty claims, missing parts, or technical support, please contact our customer service team. Keep your purchase receipt as proof of purchase.

Contact Information: Please refer to the contact details provided with your purchase or visit the official Anmutig website for support.

© 2026 Anmutig. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question