

[Manuals.plus](#) /

› [BELLA](#) /

› BELLA Single Serve Coffee Maker Instruction Manual

BELLA 35185

BELLA Single Serve Coffee Maker

Model: 35185

INTRODUCTION

Thank you for choosing the BELLA Single Serve Coffee Maker. This compact and efficient appliance is designed to provide a fresh, hot cup of coffee tailored to your preference, whether using coffee pods or freshly ground coffee. Please read this manual thoroughly before first use to ensure safe and optimal operation.



The BELLA Single Serve Coffee Maker, showcasing its sleek design and compact footprint.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or coffee maker in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.

PRODUCT OVERVIEW

The BELLA Single Serve Coffee Maker is designed for convenience and versatility. Key components include:

- **Water Reservoir:** 14oz capacity with measurement markings.
- **Brew Head:** Accommodates K-Cups or the reusable coffee grounds filter.
- **Adjustable Drip Tray:** Designed to fit various mug sizes, including travel mugs up to 7 inches tall.
- **One-Touch Brew Button:** Simple operation for quick brewing.
- **Auto Shut-off:** For peace of mind and energy saving.




Included accessories: K-Cup adapter (top) and reusable coffee grounds filter (bottom).



The coffee maker's slim profile is ideal for any countertop.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and inspect the coffee maker for any damage.
2. **Initial Cleaning:** Before first use, wash the reusable filter, coffee pod adapter, and drip tray in warm, soapy water. Wipe the exterior of the coffee maker with a damp cloth.
3. **Placement:** Place the coffee maker on a stable, level surface near an electrical outlet. Ensure there is adequate clearance above the unit for opening the lid.
4. **Fill Water Reservoir:** Open the lid and fill the 14oz water tank with fresh, cold water. Use the measurement markings inside the reservoir to fill to your desired brew size (6oz to 14oz).



The 14oz water tank features clear measurement markings for precise filling.

5. Insert Coffee:

- **For K-Cups:** Place a K-Cup into the coffee pod adapter.
- **For Ground Coffee:** Fill the reusable coffee grounds filter with your preferred ground coffee. Do not overfill.



Fits travel mugs
Adjustable drip tray fits mugs
with heights up to 7"

Choose between a coffee pod or fresh coffee grounds using the included accessories.

6. **Close Lid:** Securely close the lid until it clicks into place.

OPERATION

1. **Place Mug:** Position your mug or travel cup on the adjustable drip tray. The drip tray can be adjusted to accommodate mugs up to 7 inches tall.



Space-saving design Fits on all countertops

The adjustable drip tray fits various mug sizes, including travel mugs up to 7 inches.

2. **Start Brewing:** Press the one-touch brew button located on the side of the coffee maker. The indicator light will illuminate, and brewing will begin.
3. **Brewing Complete:** The coffee maker will automatically shut off once the brewing cycle is complete. The indicator light will turn off.
4. **Enjoy:** Carefully remove your hot cup of coffee and enjoy.

The coffee maker brews single servings from 6oz to 14oz, depending on the water added to the reservoir.



Our coffee maker

- ✓ One-touch operation
- ✓ Cord tie feature
- ✓ Compact & modern design
- ✓ Travel mug friendly

Other coffee makers

- ✗ Complicated settings
- ✗ Tangled mess
- ✗ Bulky & outdated
- ✗ Limited cup size options

Customize your brew size from 6oz to 14oz.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

Daily Cleaning

- **Drip Tray:** Remove and empty the drip tray after each use. The drip tray is dishwasher-safe.
- **Coffee Filter/Adapter:** Remove and rinse the reusable coffee grounds filter or K-Cup adapter after each use. These parts are dishwasher-safe.
- **Exterior:** Wipe the exterior of the coffee maker with a damp, soft cloth. Do not use abrasive cleaners.

Descaling (Monthly or as needed)

Mineral deposits from water can build up over time, affecting performance. Descale your coffee maker monthly or when you notice slower brewing or reduced coffee temperature.

1. Fill the water reservoir with a mixture of one part white vinegar and two parts water.
2. Place a large mug on the drip tray.
3. Run a brew cycle without coffee.
4. After the cycle, let the coffee maker sit for 30 minutes with the vinegar solution inside.
5. Run two full cycles with fresh, clean water to rinse thoroughly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee is not hot enough.	Mineral buildup; insufficient heating time.	Perform descaling procedure. Ensure the unit is plugged in and powered on for a few moments before brewing.
Water splatters during brewing.	Mug not positioned correctly; drip tray not adjusted.	Ensure mug is centered. Adjust the drip tray height to minimize splash.
Coffee maker does not stop brewing automatically.	This model brews all water added to the reservoir.	Only add the exact amount of water needed for your desired cup size (6oz to 14oz). The machine will brew until the reservoir is empty.
Grounds in coffee.	Reusable filter overfilled or not seated correctly.	Do not overfill the reusable filter. Ensure it is properly seated in the brew head.

SPECIFICATIONS

Feature	Detail
Brand	BELLA
Model Name	K Cup Coffee Maker
Model Number	35185
Color	Blossom
Product Dimensions	5.7"D x 8.38"W x 12.99"H
Item Weight	2.75 pounds
Voltage	120V
Power	1000 Watt
Coffee Input Type	Ground Coffee, Coffee Pods
Filter Type	Reusable

Feature	Detail
Special Features	Auto Shutoff, Removable Tank, Adjustable Drip Tray



Product dimensions for easy placement.

WARRANTY

The BELLA Single Serve Coffee Maker comes with a**2-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal household use. For full warranty details and terms, please refer to the warranty card included with your product or visit the official BELLA website.



The BELLA Single Serve Coffee Maker is backed by a 2-Year Warranty.

CUSTOMER SUPPORT

For any questions, assistance, or to register your product, please contact BELLA Customer Support:

- **Website:** Visit the official BELLA website for FAQs and support resources.
- **Phone:** Refer to your product packaging or the BELLA website for the most current contact number.

Please have your model number (35185) and proof of purchase ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question