

Bush Furniture NRD154DW-03

Bush Furniture Nora 54W Writing Desk (Model NRD154DW-03) User Manual

Dark Walnut Finish

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Bush Furniture Nora 54W Writing Desk. Designed with Scandinavian minimalism and mid-century modern aesthetics, this desk offers a functional workspace with integrated storage. Please read all instructions carefully before proceeding with assembly and use.



Figure 1.1: The Bush Furniture Nora 54W Writing Desk, showcasing its dark walnut finish and minimalist design. This image

provides an overall view of the desk's appearance.

2. SETUP AND ASSEMBLY

Assembly of the Bush Furniture Nora 54W Writing Desk is required. It is recommended to have a second person assist with assembly for ease and safety. Ensure all components are present before beginning.

2.1 Unpacking and Component Check

- Carefully unpack all contents from the packaging.
- Verify that all parts and hardware listed in the included assembly guide are present and undamaged.
- Place components on a soft, clean surface to prevent scratches during assembly.

2.2 Assembly Instructions

Refer to the separate assembly guide provided with your product for step-by-step instructions. While specific tools are not included, standard household tools such as a Phillips head screwdriver may be required.



Figure 2.1: A diagram highlighting key features of the desk, including the full-extension box drawer for small office supplies, the minimalist modern design, and the solid rubberwood legs. This visual aids in understanding component placement during assembly.

2.3 Placement Considerations

- Position the desk on a level surface to ensure stability.
- Avoid placing the desk in direct sunlight or near heat sources to prevent material damage.
- The desk is finished on all sides, allowing for flexible placement in any room orientation.

3. OPERATING INSTRUCTIONS

The Nora Writing Desk is designed for versatile use in various home or office settings.

3.1 Workspace Utilization

The 54-inch desk surface provides ample space for a computer, books, and other work essentials. The durable desktop supports a maximum weight of 200 pounds.



Figure 3.1: The desk integrated into a home office environment, demonstrating its use with a laptop and office chair. This illustrates the practical application of the desk as a functional workspace.

3.2 Storage Features

- **Box Drawer:** The integrated box drawer operates on full-extension ball-bearing slides, providing smooth and quiet access. It is suitable for organizing writing utensils, small office supplies, and personal items.
- **Open Compartment:** An open compartment is available for storing items that require frequent access, such as notebooks, documents, or small electronic devices.

4. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Bush Furniture Nora Writing Desk.

4.1 Cleaning

- Wipe the desk surfaces with a damp cloth.

- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Promptly clean up spills to prevent staining.

4.2 General Care

- Periodically check and tighten all hardware to maintain structural integrity.
- Avoid placing extremely hot or cold items directly on the desk surface; use coasters or protective pads.
- Do not exceed the maximum weight recommendation of 200 pounds on the desktop.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your writing desk.

5.1 Drawer Does Not Slide Smoothly or Closes Improperly

- **Check Alignment:** Ensure the drawer slides are correctly aligned and securely attached to both the drawer and the desk frame. Misalignment can cause friction.
- **Obstructions:** Verify there are no objects obstructing the drawer's path or caught within the slide mechanism.
- **Hardware Tightness:** Confirm all screws securing the drawer slides are tightened appropriately. Loose screws can affect operation.

5.2 Desk Appears Unstable or Wobbly

- **Level Surface:** Ensure the desk is placed on a completely level floor. Adjustments may be needed for uneven surfaces.
- **Tighten Connections:** Re-check all assembly hardware, especially those connecting the legs to the desktop. Tighten any loose bolts or screws.
- **Correct Assembly:** Review the assembly instructions to confirm all parts were installed correctly.

5.3 Missing or Damaged Parts

- If you discover any missing or damaged parts upon unpacking, do not proceed with assembly.
- Contact Bush Furniture customer support immediately for assistance with replacement parts.

6. SPECIFICATIONS

Detailed technical specifications for the Bush Furniture Nora 54W Writing Desk.




Figure 6.1: A detailed diagram illustrating the overall dimensions of the desk, including height, width, and depth, as well as internal dimensions for the drawer and open compartment. All measurements are provided in both inches and centimeters.

Attribute	Detail
Brand	Bush Furniture
Model Name	Nora
Model Number	NRD154DW-03
Color	Dark Walnut
Product Dimensions (D x W x H)	29.37" x 59.45" x 29.91" (74.6 cm x 151 cm x 76 cm)
Item Weight	68 Pounds (30.8 kg)
Maximum Weight Recommendation	200 Pounds (90.7 kg)
Base Material	Engineered Wood
Furniture Leg Material	Solid Rubberwood

Drawer Type	Box Drawer with Full-Extension Ball-Bearing Slides
Storage Options	1 Box Drawer, 1 Open Compartment
Assembly Required	Yes
Safety Standards	Meets or exceeds ANSI/BIFMA standards

7. WARRANTY INFORMATION

The Bush Furniture Nora 54W Writing Desk is backed by a **1 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For specific details regarding warranty coverage, limitations, and how to file a claim, please refer to the warranty documentation included with your product or visit the official Bush Furniture website.



8. CUSTOMER SUPPORT





Should you require further assistance with assembly, parts, or have any questions regarding your Bush Furniture Nora Writing Desk, please contact Bush Furniture customer support.

- **Online Support:** Visit the Bush Furniture official website for FAQs, assembly videos, and contact forms.
- **Telephone Support:** Refer to the contact information provided in your product packaging for direct assistance.

When contacting support, please have your model number (NRD154DW-03) and proof of purchase readily available.

Related Documents - NRD154DW-03

	<p>Bush Furniture Assembly and Care Instructions</p> <p>Comprehensive guide for assembling Bush Furniture products, including instructions for tightening KD cams, cleaning surfaces, and installing drawer slides, with links to video tutorials.</p>
	<p>Bush Furniture 60W L-Desk Assembly Guide</p> <p>Comprehensive assembly guide for the Bush Furniture 60W L-Desk, model series KWD160. This document provides step-by-step instructions, a detailed parts list, safety warnings, and contact information for assistance. It is designed for easy understanding and efficient assembly.</p>

 <p>Top Coffee Table</p>	<p>YOKO Soft Close Lift Top Coffee Table with Storage - Assembly Instructions & Warranty</p> <p>Detailed assembly instructions, safety warnings, parts list, and warranty information for the YOKO Soft Close Lift Top Coffee Table with Storage by Bush Furniture.</p>
 <p>Assembly Guide</p> <p>If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-950-4762.</p> <p>L-Desk</p> <p>List Code: #</p> <p>Part Number: A159345K</p>	<p>Bush Furniture L-Desk Assembly Guide - Model A159345K</p> <p>Comprehensive assembly guide for the Bush Furniture L-Desk (Model A159345K). Includes step-by-step instructions, parts list, hardware identification, safety warnings, and customer support contact information.</p>
 <p>MODEL: HM66615A, HM66615A, HM66615A</p> <p>Bush Furniture</p> <p>Thank you for purchasing this Bush Furniture product. We want to ensure you have a positive experience with your new Bush Furniture product. Please read the instructions carefully and follow the steps provided. If you have any questions or need assistance, please call our customer support team at 1-800-950-4762.</p> <p>THE BUSH FURNITURE difference</p> <ul style="list-style-type: none"> • QUALITY • INNOVATION • SERVICE • VALUE <p>AL74577</p> <p>1 Year</p>	<p>Bush Furniture Desk Assembly Guide and Product Information</p> <p>Comprehensive assembly guide and product details for Bush Furniture desks (Models HM66315A, HM66615A, HM66915A, HM66115A), including safety warnings, parts lists, step-by-step instructions, and warranty information.</p>
 <p>Assembly Guide</p> <p>If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-950-4762.</p> <p>End Table</p> <p>List Code: #</p> <p>Part Number: A220099</p>	<p>Bush Furniture End Table Assembly Guide</p> <p>Comprehensive assembly guide for the Bush Furniture End Table (Model: A220099), including safety warnings, parts list, and step-by-step instructions.</p>