

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ninja](#) /
- › [Ninja CFP105 DualBrew Hot & Iced Coffee Maker Instruction Manual](#)

Ninja CFP105

Ninja CFP105 DualBrew Hot & Iced Coffee Maker Instruction Manual

Model: CFP105

1. INTRODUCTION

Welcome to the world of versatile coffee brewing with your new Ninja CFP105 DualBrew Hot & Iced Coffee Maker. This appliance is designed to offer a flexible brewing experience, accommodating both ground coffee and coffee pods. You can enjoy a range of brew sizes, from a single cup to a full carafe, and select from various brew styles including Classic, Rich, and Over Ice. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your coffee maker.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your Ninja CFP105 DualBrew Hot & Iced Coffee Maker. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the outlet when not in use and before cleaning.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep hands and cords away from hot surfaces. The brewing chamber and warming plate become hot during operation.
- Use only cold, filtered water in the water reservoir. Do not use milk, juice, or other beverages.
- Always ensure the carafe or cup is properly placed on the drip tray before brewing to prevent spills.
- This appliance is for household use only. Do not use outdoors.

3. SETUP

3.1 Unpacking and Initial Cleaning

Carefully remove all packaging materials and promotional labels from your coffee maker. The following components are included:

- Ninja DualBrew Hot & Iced Coffee Maker
- Paper Filter Kit
- 12-Cup Glass Carafe

- Ninja Pod Adapter
- Ninja Smart Scoop
- Grounds Adapter
- Brew Basket

Wash the water reservoir, carafe, brew basket, pod adapter, and Ninja Smart Scoop in warm, soapy water. Rinse thoroughly and dry all parts. Wipe the exterior of the coffee maker with a clean, damp cloth.

3.2 Water Reservoir Setup

Place the coffee maker on a clean, dry, and level surface. Fill the 60-ounce removable water reservoir with cold, filtered water up to the MAX fill line. Ensure the reservoir is securely seated on the side of the appliance.



Image: The Ninja CFP105 DualBrew Coffee Maker with its clear, removable water reservoir filled with water, positioned on the right side of the main unit.

3.3 Power Connection

Plug the power cord into a grounded electrical outlet. The display will illuminate, indicating the coffee maker is ready for use.

4. OPERATING INSTRUCTIONS

4.1 Brewing with Ground Coffee

1. Open the brew chamber lid.

2. Insert the Brew Basket into the brew chamber.
3. Place a paper filter (if desired) or the reusable permanent filter into the brew basket.
4. Use the Ninja Smart Scoop to add your desired amount of ground coffee to the filter. Refer to the scoop markings for recommended amounts based on brew size.
5. Close the brew chamber lid firmly.
6. Place the 12-Cup Glass Carafe or your preferred mug on the drip tray.
7. Select your desired brew size using the arrows on the control panel.
8. Choose your brew style: **Classic** or **Rich**. For iced coffee, select **Over Ice** and ensure your carafe/cup is filled with ice.
9. Press the **START BREW** button to begin brewing.



Coffee made quicker*

Faster single-serve pod brewing from start-up.

Image: A close-up view of the Ninja CFP105 DualBrew Coffee Maker's brewing area, showing coffee dispensing into a mug placed on the adjustable platform.

4.2 Brewing with Coffee Pods

1. Open the brew chamber lid.
2. Remove the Brew Basket if it is installed.

3. Insert the Ninja Pod Adapter into the brew chamber.
4. Place a coffee pod into the adapter.
5. Close the brew chamber lid firmly.
6. Place your preferred mug on the drip tray. The foldable cup platform can be used for smaller mugs.
7. Select your desired brew size (6-12 oz) using the arrows on the control panel.
8. Choose your brew style: **Classic** or **Rich**. For iced coffee, select **Over Ice** and ensure your mug is filled with ice.
9. Press the **START BREW** button to begin brewing.



Adjustable fold-away cup platform

Elevates your coffee mug to reduce splashing of freshly brewed coffee.

Image: The Ninja CFP105 DualBrew Coffee Maker showing the adjustable foldable cup platform in its extended position, suitable for smaller cups.

4.3 Brew Styles and Sizes

Your Ninja DualBrew offers various options to customize your coffee:

- **Brew Sizes:** Choose from 9 sizes for ground coffee, and 6-12 oz options for pods. The machine can brew up to a 14-cup carafe.
- **Classic Brew:** A balanced and smooth coffee experience.
- **Rich Brew:** A more intense and full-bodied flavor, ideal for milk, cream, or flavoring.

- **Over Ice Brew:** Designed to brew hot coffee directly over ice without dilution, resulting in a refreshing iced coffee.

 **CERTIFIED
REFURBISHED**



3 brew style choices

Select Classic, Rich, or Over Ice for your grounds or coffee pods.

Image: A visual representation of three different coffee brew styles: Classic, Rich, and Over Ice, showcasing the variety offered by the coffee maker.

4.4 Keep Warm Function

When brewing a carafe, the intelligent warming plate will automatically activate to keep your coffee at an optimal temperature. You can adjust the warming time up to 4 hours using the **KEEP WARM** button.



Intelligent warming plate

Adjust the time (up to 4 hours) to keep your coffee at the ideal temperature.

Image: The Ninja CFP105 DualBrew Coffee Maker with a glowing red indicator on the warming plate, signifying that the keep warm function is active.

4.5 Delay Brew Function

The **DELAY** button allows you to program your coffee maker to brew at a later time. Set your desired brew time, size, and style, then press **DELAY**. The indicator light will illuminate, and your coffee will brew automatically at the set time.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your Ninja DualBrew Coffee Maker.

5.1 Daily Cleaning

- **Water Reservoir:** Empty any remaining water and rinse the reservoir after each use.
- **Brew Basket & Pod Adapter:** Remove and rinse the brew basket or pod adapter after each use. These parts are dishwasher-safe.
- **Drip Tray:** The removable drip tray and its cover should be washed regularly with warm, soapy water.
- **Carafe:** Wash the glass carafe and its lid with warm, soapy water after each use.
- **Exterior:** Wipe the exterior of the coffee maker with a soft, damp cloth.

5.2 Descaling (CLEAN Cycle)

The **CLEAN** indicator light will illuminate when it's time to descale your coffee maker. This process removes calcium buildup and ensures proper operation.

1. Empty the water reservoir and carafe.
2. Pour 16 oz of white vinegar into the water reservoir, then fill the rest with water up to the MAX fill line.
3. Place the empty carafe on the drip tray.
4. Press the **CLEAN** button. The cleaning cycle will begin and typically takes about 20-30 minutes.
5. Once the cycle is complete, discard the cleaning solution.
6. Rinse the water reservoir and fill it with fresh water up to the MAX fill line.
7. Run a full carafe of plain water through the machine to rinse thoroughly. Repeat if necessary until the vinegar smell is gone.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee not brewing.	No water in reservoir; brew chamber not closed; power issue.	Fill reservoir; ensure brew chamber lid is fully closed; check power connection.
Weak coffee.	Insufficient coffee grounds; incorrect brew style selected.	Add more coffee grounds; select 'Rich' brew style for stronger coffee.
'CLEAN' light illuminated.	Mineral buildup in the system.	Perform a descaling cycle as described in Section 5.2.
Water leaking from appliance.	Water reservoir not seated correctly; drip tray overflow.	Ensure water reservoir is firmly in place; empty drip tray.

7. SPECIFICATIONS

- **Brand:** Ninja
- **Model:** CFP105
- **Color:** Black
- **Product Dimensions:** 12.49"D x 9.94"W x 11.03"H
- **Coffee Maker Type:** Drip Coffee Machine
- **Coffee Input Type:** Grounds and Pods
- **Water Reservoir Capacity:** 60 oz (approx. 14 cups)
- **Special Features:** Auto Shut-Off, Removable Tank, Cup Warmer, Dishwasher Safe Parts, Permanent Filter, Fully Automatic Operation, Delay Brew, Keep Warm Function
- **Voltage:** 120 Volts
- **Item Weight:** 9.1 pounds

8. WARRANTY AND SUPPORT

This Ninja CFP105 DualBrew Hot & Iced Coffee Maker is a manufacturer-refurbished unit. It comes with a **90-day manufacturer refurbished warranty**. Additionally, this bundle includes a **2-Year Extended Warranty** for enhanced protection.

For technical support, troubleshooting assistance, or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official Ninja website.

