

Casio MTP1302D-3AV

Casio MTP1302D-3AV Men's Analog Watch Instruction Manual

1. INTRODUCTION

This manual provides essential information for the proper use and care of your Casio MTP1302D-3AV Men's Analog Watch. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece. This watch combines classic design with reliable quartz movement, offering both style and functionality for daily wear.

2. PRODUCT OVERVIEW

The Casio MTP1302D-3AV features a striking green dial, complemented by luminous hands and markers for enhanced readability. Its durable stainless steel case and bracelet ensure resilience for everyday use. A date display is conveniently located at the 3 o'clock position.



Figure 1: Front view of the Casio MTP1302D-3AV watch, highlighting its green dial and stainless steel construction.

3. SETUP

3.1 Setting the Time

1. Pull the crown out to the second click position.
2. Rotate the crown to move the hour and minute hands to the desired time.
3. Push the crown back in to the normal position to start timekeeping.

3.2 Setting the Date

1. Pull the crown out to the first click position.
2. Rotate the crown to set the desired date.
3. Push the crown back in to the normal position.

Note: Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change mechanism.

4. OPERATING THE WATCH

4.1 Wearing the Watch

Ensure the watch bracelet is adjusted to fit comfortably on your wrist. The stainless steel bracelet features a buckle clasp for secure fastening. If adjustment is needed, it is recommended to consult a professional jeweler.

4.2 Water Resistance (WR 50M)

This watch is designed with 50-meter water resistance (WR 50M), making it suitable for everyday use and light water exposure. It can withstand splashes, rain, and brief immersion in water. However, it is not recommended for swimming, diving, or watersports where prolonged water exposure or high water pressure is involved. Do not operate the crown while the watch is wet.

5. MAINTENANCE

5.1 Cleaning

Regularly wipe the watch case and bracelet with a soft, dry cloth to remove dirt and moisture. For stainless steel parts, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners or abrasive materials.

5.2 Battery Replacement

The watch is powered by a Japanese Quartz movement, which requires a battery. When the watch stops or the second hand begins to jump at irregular intervals, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to maintain water resistance and ensure proper function.

5.3 Storage

When not in use, store your watch in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from dust and scratches.

6. TROUBLESHOOTING

6.1 Watch Not Running

- Check if the crown is pushed in completely.
- The battery may need replacement. Consult a technician.

6.2 Incorrect Time/Date

- Refer to Section 3 for instructions on setting the time and date.
- Ensure the crown is fully pushed in after setting.

6.3 Condensation Inside the Watch

If you notice condensation inside the watch, it may indicate a loss of water resistance. Have the watch inspected by a qualified technician immediately to prevent further damage.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Model Name	MTP1302D-3AV
Brand	Casio
Display Type	Analog
Movement Type	Japanese Quartz
Power Source	Battery Powered
Case Material	Stainless Steel
Band Material	Stainless Steel
Dial Color	Green
Case Diameter	44.2 Millimeters
Water Resistance Depth	50 Meters (165 Feet)
Crystal Type	Mineral Glass
Clasp Type	Buckle
Item Weight	0.5 Pounds (8 ounces)

8. WARRANTY AND SUPPORT

8.1 Limited Warranty

Your Casio MTP1302D-3AV watch comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects under normal use.

8.2 Customer Support

For any questions, service, or repair needs not covered in this manual, please contact Casio customer support or an authorized service center. Do not attempt to open or repair the watch yourself, as this may void the warranty and cause further damage.