

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› **THERMOS** /

› **THERMOS FUNTAINER 16 Ounce Stainless Steel Vacuum Insulated Food Jar with Folding Spoon - Instruction Manual**

THERMOS F31104OR6

THERMOS FUNTAINER 16 Ounce Stainless Steel Vacuum Insulated Food Jar

Model: F31104OR6

INTRODUCTION

The THERMOS FUNTAINER 16 Ounce Food Jar is designed to keep meals at their optimal temperature, whether hot or cold. Featuring THERMOS vacuum insulation technology, this food jar is ideal for transporting a variety of foods. Its lightweight and compact design, along with a convenient push-button lid and included folding spoon, make it suitable for daily use. This manual provides essential information for proper setup, operation, and maintenance to ensure the longevity and performance of your food jar.



Image: THERMOS FUNTAINER 16 Ounce Food Jar in Neon Orange with its folding spoon.

SETUP

1. **Initial Cleaning:** Before first use, wash all parts of the food jar and spoon with warm soapy water. Rinse thoroughly and dry.
2. **Pre-heating for Hot Foods:** For maximum heat retention, pre-heat the food jar by filling it with hot water (not boiling) for 5-10 minutes. Empty the hot water before adding your hot food.
3. **Pre-cooling for Cold Foods:** For maximum cold retention, pre-cool the food jar by filling it with cold water for 5-10 minutes. Empty the cold water before adding your cold food.

DESIGNED FOR KIDS, AND THEIR PARENTS



Image: Key features and dimensions of the food jar.

OPERATING INSTRUCTIONS

1. **Filling:** After pre-heating or pre-cooling, fill the food jar with your desired food. The wide mouth allows for easy filling.
2. **Sealing:** Ensure the lid is securely screwed onto the body of the food jar to prevent leaks and maintain temperature.
3. **Using the Folding Spoon:** The food jar includes a full-size stainless steel folding spoon stored conveniently within the lid. To access, press the button on the lid to open the top compartment, remove the spoon, and unfold it for use. After use, fold the spoon and place it back in its compartment before closing the lid.

4. **Opening the Lid:** To open the main lid, twist counter-clockwise. To open the spoon compartment, press the small button on the lid.



Image: Details of the food jar's design and features.

MAINTENANCE AND CARE

- **Cleaning:** The food jar and spoon are dishwasher safe. However, hand washing is recommended to prolong the product's lifespan and maintain its finish.
- **Drying:** Ensure all parts are completely dry before reassembling and storing to prevent odors or mildew.
- **Storage:** Store the food jar with the lid removed or slightly ajar to allow air circulation.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners or scrubbers as they may damage the finish.

KEEP FOODS HOW THEY LIKE THEM

Hotter, Colder, Fresher, Longer



Image: Temperature retention capabilities of the food jar.

SPECIFICATIONS

Feature	Detail
Brand	THERMOS
Model Number	F31104OR6
Color	Neon Orange
Material	Stainless Steel
Capacity	16 Ounces
Product Dimensions	3.72"D x 3.46"W x 6.65"H
Item Weight	9.6 ounces
Special Features	Durable, Lightweight, Insulated, Folding Spoon

Feature	Detail
Temperature Retention (Hot)	Up to 5 hours
Temperature Retention (Cold)	Up to 7 hours

TROUBLESHOOTING

If you experience any issues with your THERMOS FUNTAINER food jar, please ensure all parts are correctly assembled and the lid is securely tightened. For persistent problems or concerns, refer to the manufacturer's official support channels or contact customer service for assistance.