

SUPRENT Black Scorpion-T

SUPRENT Cordless Hair Trimmer with LED Display - Model Black Scorpion-T

Instruction Manual

INTRODUCTION

Thank you for choosing the SUPRENT Cordless Hair Trimmer, Model Black Scorpion-T. This high-performance rechargeable trimmer is designed for precise hair and beard grooming at home. Featuring durable titanium blades, a powerful 6000RPM motor, and a convenient LED display, it offers a professional-grade trimming experience. Please read this manual thoroughly before first use to ensure safe and optimal operation.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions.

- Keep away from water sources. Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- Avoid contact with eyes.
- Always unplug the trimmer and allow it to cool before cleaning or storing.
- Do not use on infants or children.
- Always use with caution and follow recommended safety guidelines.
- This appliance is intended for household use only.

PRODUCT COMPONENTS

The SUPRENT Cordless Hair Trimmer package includes the following items:



Image: The SUPRENT Cordless Hair Trimmer, showing the main unit, three attachment combs (1.5mm, 3.0mm, 4.5mm), a cleaning brush, blade oil, and a USB-C charging cable.

- SUPRENT Hair Trimmer Unit
- Attachment Combs (1.5mm, 3.0mm, 4.5mm)
- USB-C Charging Cable
- Cleaning Brush
- Blade Oil
- Instruction Manual (this document)

SETUP AND CHARGING

1. **Initial Charge:** Before first use, fully charge the trimmer. Connect the USB-C charging cable to the trimmer's charging port and plug the other end into a compatible USB power source (e.g., laptop, phone charger, or power bank).
2. **Monitor Battery:** The intelligent LED display will show the charging status and remaining battery life. A full

charge typically takes approximately 2 hours.

3. **Attachment Combs:** Select the desired attachment comb (1.5mm, 3.0mm, or 4.5mm) and securely snap it onto the trimmer blade. Ensure it is firmly attached before use.



Image: The trimmer's LED display showing battery percentage and a USB-C cable connected for charging. The display indicates a charging time of 2 hours for 210 minutes of running time.

OPERATING INSTRUCTIONS

Power On/Off

- To turn on the trimmer, press the power button located on the side of the unit.
- To turn off the trimmer, press the power button again.

Trimming Techniques

The SUPRENT trimmer features a powerful 6000RPM motor and titanium blades for efficient cutting. Its zero-gapped design allows for precise trimming and detailing.



Style, Sculpt, and Trim with Ease

FACTORY-CALIBRATED ZERO GAP FOR PRECISE TRIMMING

Close to 0.1mm
Not Adjustable

Image: Close-up of the trimmer's zero-gapped blade, highlighting its ability for precise trimming with a cutting distance of approximately 0.1mm.

Note: The trimmer blade is not adjustable.

- **Beard Trimming:** For an even beard trim, attach the desired comb. Move the trimmer against the direction of hair growth, using smooth, even strokes.
- **Detailing and Edging:** For sharp lines and intricate designs, remove the attachment comb. Use the zero-gapped blade carefully to define necklines, sideburns, and beard edges.
- **Fading:** Utilize the different comb sizes to create gradual transitions in hair length. Start with a longer comb and progressively switch to shorter combs.
- **Hair Carving:** The precision of the zero-gapped blade is suitable for creating detailed hair carvings.




Image: Demonstrates the multifunctional use of the trimmer for beard grooming, hair carving, and fading techniques.

Note: The trimmer blade is factory-calibrated to a zero-gapped design and is not adjustable.

MAINTENANCE

Cleaning the Blades

1. Ensure the trimmer is turned off and unplugged from any power source.
2. Use the provided cleaning brush to remove loose hairs from the blades and the trimmer head.
3. For a more thorough cleaning, the blades can be rinsed under running water. Ensure the trimmer body does not get wet. Allow blades to air dry completely before reattaching or storing.

Oiling the Blades

Regular oiling helps maintain blade sharpness and ensures smooth operation.

- After cleaning and drying, apply a small drop of the provided blade oil to the teeth of the blades.
- Turn on the trimmer for a few seconds to distribute the oil evenly.
- Wipe off any excess oil with a soft cloth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully using the USB-C cable. Check the LED display for battery level.
Trimmer pulls or snags hair.	Blades are dull or dirty. Not enough oil. Hair buildup.	Clean the blades thoroughly. Apply blade oil. Ensure blades are free of hair debris.
Reduced cutting performance.	Blades are dirty or not oiled. Battery is low.	Clean and oil the blades. Recharge the trimmer.
Trimmer makes unusual noise.	Blades are not properly aligned or need oiling.	Ensure blades are clean and oiled. If the issue persists, contact customer support.



SPECIFICATIONS





- **Model:** Black Scorpion-T
- **Brand:** SUPRENT
- **Motor Speed:** 6000 RPM
- **Blade Material:** Titanium-coated
- **Cutting Distance:** Approximately 0.1mm (Zero-gapped, non-adjustable)
- **Power Source:** Battery Powered
- **Charging Port:** USB-C
- **Charging Time:** Approximately 2 hours
- **Running Time:** Up to 3.5 hours (210 minutes)
- **Item Weight:** 0.35 Kilograms (approx. 12.31 ounces)
- **Package Dimensions:** 7.6 x 3.58 x 2.83 inches
- **Color:** Black

LEGAL DISCLAIMER

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is a personal grooming appliance and should be used as directed in this manual.

Related Documents - Black Scorpion-T

	<p>Ufree All-in-One Hair Clipper User Manual and Safety Guide</p> <p>Comprehensive guide to the Ufree All-in-One Hair Clipper (Model: U-1779), covering safety instructions, charging, usage of various trimmer heads, travel lock function, and maintenance. Learn how to achieve different hairstyles and beard styles with this versatile grooming kit.</p>
	<p>Ufree Professional Hair Clippers & Grooming Kit - Model U-2226 User Manual</p> <p>Comprehensive user manual for the Ufree U-2226 Professional Hair Clippers and Grooming Kit. Learn about features, safety, charging, maintenance, and usage for beard trimming, hair cutting, and detail grooming.</p>

	<p>VGR V-085 Professional Hair Trimmer Manual and Safety Instructions</p> <p>This document provides comprehensive safety instructions, components list, usage guidelines, cleaning and maintenance procedures, and technical specifications for the VGR V-085 Professional Hair Trimmer.</p>
	<p>MANSCAPED Beard Hedger User Manual</p> <p>Instructions for charging, trimming, cleaning, and maintenance of the MANSCAPED Beard Hedger trimmer. Learn how to adjust settings, remove and install the comb and blade, and care for your device.</p>
	<p>Suprent BT575BX Beard Trimmer User Manual</p> <p>User manual for the Suprent BT575BX Beard Trimmer, detailing specifications, basic parameters, product description, and warranty information.</p>
	<p>U-1733 Hair Trimmer User Manual</p> <p>Instructions for the U-1733 Hair Trimmer, including product specifications, how to use, maintenance, troubleshooting, and environmental protection guidelines.</p>