ChooChoo CT2303-BK

ChooChoo Coffee Table Lift Top User Manual

Model: CT2303-BK

Product Overview

The ChooChoo Multi-Function Convertible Coffee Table Lift Top is designed to optimize space utilization in your living area. This versatile table can transform from a standard coffee table into an office desk or a dining table, offering practical solutions for various needs. It features hidden storage compartments and a lower shelf for organization.



Image: The ChooChoo Coffee Table Lift Top in a living room, demonstrating its full extension as a dining table, complete with place settings.

Safety Information

- **General Warning:** Ensure proper assembly for stability and safety.
- Do not exceed the weight limit of the table. Refer to the specifications section for details.
- When operating the lift-top mechanism, ensure hands and fingers are clear of moving parts to prevent injury.

Setup and Assembly

Assembly of the ChooChoo Coffee Table Lift Top is designed to be straightforward. All necessary parts are numbered, and clear instructions are included with the product. A screwdriver is the recommended tool for assembly.

Assembly Tips:

- It is recommended to have a second person assist when attaching the tabletop to the base for easier alignment and stability.

- Before fully extending the lift-top, ensure the lower table section is properly opened for support to avoid potential damage to the mechanism or table structure.
- When lifting the tabletop, it is best to lift from the center if working alone, or with one person on each side if two people are assisting.
- Consider adding small rubber feet or bumpers under the tabletop to provide cushioning and prevent slamming when closing the lift-top mechanism.



Image: A detailed diagram illustrating the product dimensions and the lift-top mechanism, highlighting the need to open the lower table for support.

Operating Instructions

The ChooChoo Coffee Table Lift Top features a gas lift mechanism and hydraulic rods for smooth and cushioned operation, allowing for multiple configurations.

Table Configurations:

1. **Regular Coffee Table:** In its closed position, the table functions as a standard coffee table, providing a stable surface for everyday use.
2. **Office Desk / Half-Open:** The lift-top can be partially raised to create a comfortable working surface,

ideal for using a laptop or enjoying a meal while seated on a sofa.

3. **Dining Table (4-8 People):** The table can be fully extended and lifted to a dining height, accommodating 4 to 8 people. This transformation is facilitated by the gas lift mechanism and hydraulic rods, ensuring a stable and elevated surface.



Image: Visual representation of the three primary uses: regular coffee table, double lift-top for working, and fully extended as a dining table.

Storage Features:

- **Hidden Compartments:** The table includes three hidden compartments located beneath the lift-top surface. These are suitable for storing remote controls, magazines, or other small items to keep your living space tidy.
- **Lower Shelf:** A decorative slat bottom shelf provides additional open storage or display space for books, baskets, or decorative items.



Image: An exploded view diagram detailing the internal structure and features, such as the gas lift mechanism and hidden compartments.

Maintenance and Care

To ensure the longevity and appearance of your ChooChoo Coffee Table, follow these maintenance guidelines:

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the wood surfaces.
- **Protection:** Use coasters under beverages and placemats under hot dishes to protect the tabletop from heat and moisture damage.
- **Mechanism Care:** Periodically check the lift mechanism for smooth operation. If it becomes stiff, a small amount of silicone-based lubricant can be applied to the moving parts, avoiding contact with wood surfaces.
- **Fasteners:** Periodically check and tighten all screws and fasteners to maintain structural integrity.

Troubleshooting

If you encounter issues with your ChooChoo Coffee Table Lift Top, refer to the following common solutions:

- **Table feels wobbly after assembly:** Ensure all screws and fasteners are securely tightened. Verify that all parts are correctly oriented according to the assembly instructions. Uneven flooring can also contribute to wobbling; consider using furniture pads or shims.
- **Lift-top mechanism is not smooth or slants:** When raising or lowering the lift-top, ensure you are applying even pressure. If it consistently slants or is difficult to move, check for any obstructions in the mechanism. Ensure the lower table support is correctly engaged before lifting. If the issue persists, contact customer support.
- **Damage during shipping:** If any parts arrived damaged, do not proceed with assembly. Contact ChooChoo customer support immediately for assistance and replacement parts.

Specifications

Feature	Detail
Brand	ChooChoo
Model Name	CT2303-BK
Product Dimensions (D x W x H)	19.7"D x 39.4"W x 26"H
Extended Length	19.7 Inches
Maximum Lifting Height	26 Inches
Color	Black
Item Weight	56.4 Pounds
Frame Material Type	Wood
Top Material Type	Wood
Handle Material	Metal
Style	Modern
Indoor/Outdoor Usage	Indoor
Tools Recommended For Assembly	Screw Driver
Is the item resizable?	Yes (referring to lift-top functionality)

Warranty and Support

ChooChoo is committed to providing quality products and customer satisfaction.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to the retailer's return policy for detailed information.

- **Customer Support:** For any product inquiries, assembly assistance, or to report damaged parts, ChooChoo offers responsive customer support. Inquiries typically receive a reply within 24 hours.
- **Contact:** You can visit the official ChooChoo store for more information or to contact support: ChooChoo Store