Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Link2Home L2H-B0CZV1PDJX

Link2Home Space Saver Pop-Up Outlet Station with USB (Model L2H-B0CZV1PDJX) User Manual

Your guide to installation, operation, and maintenance.

Safety Information | Product Overview | Setup & Installation | Operating Instructions | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Safety Information

Please read and understand all safety instructions before installing or using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Indoor Use Only:** This device is designed for indoor use in dry locations. Do not install or use in wet or damp environments.
- **Electrical Rating:** Do not exceed the maximum electrical rating of 15A, 125VAC, 1875W. Overloading may cause damage or fire.
- **Grounding:** Ensure the product is properly grounded. The unit features grounded outlets for safety.
- **Installation:** Installation should be performed by a qualified individual if you are unsure about electrical wiring. Ensure power is disconnected before installation.
- **Water Exposure:** While splash resistant, avoid direct water exposure or submersion.
- **Children:** Keep out of reach of children.
- **Damage:** Do not use if the product or power cord is damaged. Contact support for assistance.

2. Product Overview

The Link2Home Space Saver Pop-Up Outlet Station provides convenient access to power and USB charging ports in a discreet, retractable design. Ideal for kitchen islands, office tables, and workshops, it helps maintain a clean and organized workspace.

2.1 Key Features

- **Space-Saving Design:** Fully retractable unit sinks to 2.9 inches beneath the countertop when concealed.
- **Multiple Power Options:** Equipped with 2 standard 15A AC power outlets.
- **USB Charging:** Includes 2 USB ports (2.4A total) for fast charging mobile devices.
- **Splash Resistant:** Designed to withstand minor splashes, suitable for kitchen environments.

- **Durable Finish:** Features a stainless-steel finish for a modern and unobtrusive appearance.
- **Overload Protection:** Built-in protection for enhanced safety.
- **ETL & FCC Certified:** Ensures compliance with safety and quality standards.

2.2 Package Contents

- Link2Home Pop-Up Outlet Station (Model L2H-B0CZV1PDJX)
- Installation Ring
- User Manual



Figure 2.1: Two Link2Home Pop-Up Outlet Stations, showing the retractable design and attached power cords.



Figure 2.2: Diagram illustrating the key features including 2 Type-A USB ports, 2 AC outlets (15A/125VAC/1875W) with overload protection, ETL & FCC certification, and a 14AWG SJT cable for indoor use.

3. Setup & Installation

Follow these steps for proper installation. Ensure all safety precautions are observed before beginning.

3.1 Required Tools (Not Included)

- Hole saw (2.4 to 2.5 inches diameter)
- Measuring tape
- Pencil or marker
- Safety glasses
- Gloves

3.2 Installation Steps

1. **Choose Location:** Select a suitable location on your countertop, desk, or workbench, ensuring there is sufficient clearance below for the unit (approximately 2.9 inches depth when concealed) and access to a power outlet.
2. **Mark and Drill:** Using a pencil or marker, mark the center of your desired installation spot. Carefully drill a hole with a diameter between 2.4 inches and 2.5 inches using a hole saw.
3. **Prepare Unit:** Remove the threaded ring from the base of the pop-up outlet station.
4. **Insert Unit:** From the top of the surface, slide the body of the pop-up outlet station through the drilled hole.
5. **Secure Unit:** From underneath the surface, screw the threaded ring tightly onto the base of the unit until it is firmly secured against the underside of the countertop.
6. **Connect Power:** Plug the attached power cord into a standard 120V AC grounded wall outlet. Ensure the cord is routed safely and not pinched.





Figure 3.1: Illustration of the pop-up outlet's dimensions (6.3 inches extended height, 2.9 inches concealed depth) and the required hole diameter (2.4-2.5 inches) for installation.

4. Operating Instructions

The Link2Home Pop-Up Outlet Station is designed for simple and intuitive use.

4.1 Extending the Unit

1. **To access USB ports:** Gently press down on the top cap of the unit. The top section, containing the USB ports, will pop up slightly. Pull it up fully until it locks into place.
2. **To access AC outlets:** After the USB section is extended, continue to pull the entire unit upwards until the AC outlets are fully exposed and the unit locks into its extended position.



Figure 4.1: Visual guide showing the unit in its concealed state and how it extends to reveal the power outlets and USB ports.

4.2 Using Power Outlets and USB Ports

- Plug your devices into the available AC outlets or USB ports.
- The USB ports provide 2.4A for fast charging compatible devices.
- Ensure total power consumption does not exceed 1875W (15A at 125V).



Figure 4.2: The pop-up outlet in an extended position, actively charging a smartphone via USB and providing power to a computer monitor.

4.3 Retracting the Unit

- Unplug all devices from the outlets and USB ports.
- Gently push down on the top cap of the unit until it fully retracts and sits flush with the surface.

5. Maintenance

Proper care ensures the longevity and safe operation of your pop-up outlet station.

- **Cleaning:** Disconnect power before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically inspect the unit and power cord for any signs of damage, wear, or loose connections.
- **Avoid Obstructions:** Ensure no debris or objects obstruct the pop-up mechanism.
- **Splash Resistance:** While splash resistant, do not immerse the unit in water or expose it to heavy water spray.



Figure 5.1: The pop-up outlet demonstrating its splash-resistant feature, suitable for environments where minor water splashes may occur.

6. Troubleshooting

If you encounter issues with your Link2Home Pop-Up Outlet Station, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
No power from outlets/USB ports.	Unit not plugged in; wall outlet not active; internal overload protection tripped.	Ensure the unit's power cord is securely plugged into a live wall outlet. Test the wall outlet with another device. Unplug all devices from the pop-up unit, wait a few minutes, and then plug them back in one by one to see if the overload protection resets. Reduce the number of connected devices if it trips again.

Problem	Possible Cause	Solution
Unit does not pop up or retract smoothly.	Obstruction; mechanism dirty; improper installation.	Check for any objects or debris around the unit that might be hindering its movement. Clean the exterior of the unit. Verify that the installation ring is not overtightened or misaligned, which could cause friction.
USB devices charge slowly or not at all.	Device incompatibility; faulty USB cable; excessive power draw.	Ensure your device is compatible with 2.4A USB charging. Try a different USB cable. If multiple devices are connected, try charging one at a time.

If the problem persists after trying these solutions, please contact Link2Home customer support.

7. Specifications

Feature	Detail
Model Number	L2H-B0CZV1PDJX
AC Outlets	2 (Grounded, Type B - 3 pin North American)
USB Ports	2 (2.4A total)
Electrical Rating	15A / 125VAC / 1875W
Power Cord Length	6 feet
Product Dimensions (Extended)	Approximately 2.9"L x 2.9"W x 6.3"H
Product Dimensions (Concealed)	Approximately 2.9"L x 2.9"W x 2.9"H (below surface)
Required Hole Diameter	2.4 - 2.5 inches
Material Finish	Stainless-Steel
Certifications	ETL, FCC
Item Weight	4.04 pounds



Figure 7.1: Key features and specifications including two grounded outlets, two 2.4A USB ports, and a 6-foot power cord.

8. Warranty & Support

Link2Home products are manufactured to high-quality standards. This product comes with a **1-Year Warranty** from the date of purchase against defects in materials and workmanship.

What the Warranty Covers: This warranty covers defects in materials and workmanship under normal use.

What the Warranty Does Not Cover: This warranty does not cover damage caused by misuse, abuse, accident, unauthorized modification, improper installation, or natural disasters.

To Obtain Warranty Service: Please contact Link2Home customer support with your proof of purchase. Do not attempt to repair

the product yourself.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please visit the official Link2Home website or contact their customer service department. Refer to the product packaging for specific contact details.



Figure 8.1: The product is backed by a 1-year warranty.

© 2024 Link2Home. All rights reserved. Model: L2H-B0CZV1PDJX

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZV1PDJX

More documents and user manuals: **https://manuals.plus/**