ADESSO WKB-7000BB

ADESSO EasyTouch 7000 User Manual

Model: WKB-7000BB

1. Introduction

The ADESSO EasyTouch 7000 is a versatile, wireless Bluetooth keyboard designed for multi-device and multi-OS compatibility. Featuring quiet scissor-switch keys and a compact, portable design, it offers a comfortable and efficient typing experience across various platforms. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your keyboard.



Image 1.1: The ADESSO EasyTouch 7000 Multi OS Multi-Device Bluetooth Scissor Switch Keyboard.

2. Key Features

- **3 Devices Switch with A Single Clicking:** Connects to up to three devices simultaneously, allowing seamless switching.
- **Multi-OS Ready:** Compatible with Windows, macOS, Android, and Linux, with specific modifiers and command keys.
- **Copilot AI Hotkey:** Provides instant access to an advanced AI assistant for enhanced productivity.

- **Scissor Switch Technology:** Offers a quiet, slim, and responsive typing experience.
- **Portable and Durable Design:** Features a sleek metal body, ideal for travel and daily use.

3. Package Contents

- ADESSO EasyTouch 7000 Bluetooth Keyboard
- USB-C Charging Cable
- User Manual

4. Setup

4.1 Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the supplied USB-C cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.



Image 4.1: The keyboard features a USB Type-C port for recharging and offers up to 30 hours of performance.

4.2 Bluetooth Pairing

The EasyTouch 7000 can connect to up to three Bluetooth devices. Follow these steps to pair your keyboard:

1. Turn on the keyboard using the power switch located on the side.
2. Press and hold the **Fn** key and one of the Bluetooth device keys (**BT1**, **BT2**, or **BT3**) for 3-5 seconds until the corresponding indicator light above the key starts blinking rapidly. This indicates the keyboard is in pairing mode.
3. On your device (computer, tablet, smartphone), enable Bluetooth and search for new devices.
4. Select "ADESSO WKB-7000BB" from the list of available devices.
5. If prompted, enter the pairing code displayed on your screen using the keyboard and press **Enter**.
6. Once paired, the indicator light will stop blinking and remain solid for a few seconds before turning off, indicating a successful connection.
7. Repeat these steps for up to two additional devices using **BT2** and **BT3**.



Image 4.2: The keyboard supports multi-point Bluetooth 5.0, allowing connection to three devices (01, 02, 03) simultaneously.

4.3 Operating System Selection

The keyboard supports multiple operating systems. To optimize key functions for your specific OS, use the following key combinations:

- **Fn + Q:** For Android OS
- **Fn + W:** For Windows OS
- **Fn + E:** For Mac OS



Image 4.3: The keyboard provides multi-OS layout support for Windows, macOS, Android, and Linux.

5. Operating the Keyboard

5.1 Switching Between Devices

Once paired with multiple devices, you can switch between them instantly by simply pressing the corresponding Bluetooth device key (**BT1**, **BT2**, or **BT3**). The keyboard will automatically connect to the selected device.

5.2 Function Keys (F1-F12)

The top row of keys serves dual functions. By default, they act as standard function keys (F1-F12). To access their secondary multimedia or system control functions, press and hold the **Fn** key simultaneously with the desired function key.

5.3 Copilot AI Hotkey

The keyboard features a dedicated Copilot AI Hotkey. Pressing this key will launch or activate the Copilot AI assistant on

compatible operating systems, providing quick access to AI functionalities.



Image 5.1: Close-up view of the Copilot AI Hotkey, providing quick access to AI features.

6. Maintenance

To ensure the longevity and optimal performance of your ADESSO EasyTouch 7000 keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaner to wipe the surface of the keyboard. Avoid using harsh chemicals, solvents, or abrasive materials.
- **Dust and Debris:** Regularly use compressed air to remove dust and debris from between the keys.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Liquid Exposure:** Avoid exposing the keyboard to liquids. In case of accidental spills, immediately disconnect the keyboard and allow it to dry completely before attempting to use it again.

Image 6.1: Diagram illustrating the scissor-switch mechanism, highlighting its slim and quiet design.

7. Troubleshooting

If you encounter issues with your ADESSO EasyTouch 7000 keyboard, refer to the following common problems and solutions:

Problem	Possible Solution
Keyboard does not turn on.	Ensure the power switch is in the 'ON' position. Recharge the keyboard using the USB-C cable.
Keyboard does not connect via Bluetooth.	Ensure Bluetooth is enabled on your device. Make sure the keyboard is in pairing mode (blinking indicator). Delete previous pairings on your device and re-pair. Ensure the keyboard is charged.
Keys are not responding or typing incorrectly.	Recharge the keyboard. Ensure the correct operating system mode is selected (Fn + Q/W/E). Check for any debris under the keys.
Connection is unstable or lags.	Move the keyboard closer to your device. Ensure there are no strong interference sources (e.g., Wi-Fi routers, other Bluetooth devices) nearby. Recharge the keyboard.
Copilot AI Hotkey does not work.	Ensure your operating system and applications support the Copilot AI feature. Check for any software updates for your OS.

8. Specifications

Feature	Detail
Brand	ADESSO
Model Number	WKB-7000BB
Connectivity Technology	Bluetooth 5.0
Keyboard Description	Bluetooth Keyboard
Key Type	Scissor-Switch
Number of Keys	78
Compatible Devices	Laptop, PC, Smart TV, Tablet
Operating System Support	Android, Mac OS, Windows, Linux
Power Source	Battery Powered (Rechargeable via USB-C)
Item Weight	1.2 pounds (approx. 0.54 kg)
Product Dimensions (LxWxH)	11.1 x 4.8 x 0.7 inches (approx. 28.2 x 12.2 x 1.8 cm)

9. Warranty and Support

The ADESSO EasyTouch 7000 keyboard is covered by a manufacturer's warranty. For specific warranty terms, duration, and to obtain technical support, please visit the official ADESSO website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Online Support: www.adesso.com/support

Contact Information: Refer to the ADESSO website for the most current contact details.

© 2024 ADESSO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question