

[Manuals.plus](#) /

› [EASYmaxx](#) /

› EASYmaxx Insect Protect Telescopic Mosquito Screen User Manual

EASYmaxx 14883

EASYmaxx Insect Protect Telescopic Mosquito Screen

Model: 14883

PRODUCT OVERVIEW

The EASYmaxx Insect Protect telescopic mosquito screen provides a quick and effective solution for keeping insects out of your home. Designed for easy installation without the need for tools, drilling, or cutting, this screen features a flexible, extendable frame and an integrated, weather-resistant net. It offers reliable protection against mosquitoes, wasps, flies, spiders, and other pests, while maintaining optimal visibility and airflow through your windows.

This product is suitable for window openings ranging from a minimum of 70 x 80 cm up to a maximum of 115 x 135 cm. It is not designed for use in door openings.

SAFETY INFORMATION

Please read all safety information before installation and use.

- The EASYmaxx Insect Protect screen is designed exclusively for window openings.
- Ensure the window dimensions are within the specified range (minimum 70 x 80 cm to maximum 115 x 135 cm) for proper fit and function.
- Do not attempt to install this product in door frames or openings larger than the maximum specified dimensions.
- Keep packaging materials away from children to prevent suffocation hazards.

SETUP AND INSTALLATION

The EASYmaxx Insect Protect screen is designed for quick and tool-free installation, typically within 3 minutes.

1. Check Window Compatibility

Before installation, ensure your window frame meets the necessary clearance requirements. The screen is compatible with plastic (PVC), aluminum, and wooden window frames.

COMPATIBILE TELAI DELLE FINESTRE

EASYmaxx
INSECT PROTECT




Image: Diagram illustrating the compatibility of the EASYmaxx screen with various window frame materials, including plastic (PVC), aluminum, and wood. The telescopic frame is available in anthracite and white.

You will need a minimum of 25 mm space between the window frame and any roller blind or external obstruction. Additionally, a minimum of 27 mm space is required for the spring stops within the inner frame.


CONTROLLO DELLA FINESTRA: tutto pronto per l'installazione?



È necessaria una superficie di contatto di almeno **25 mm** all'esterno del telaio della finestra.



25 mm di spazio richiesto tra il telaio e l'avvolgibile



Spazio minimo di **27 mm** per i fermi a molla nel telaio interno.

Image: Diagram detailing the necessary clearances for proper installation. It shows a minimum of 25 mm space required between the window frame and any roller blind, and a minimum of 27 mm for the spring stops in the inner frame. Weather bars might impede installation.

2. Prepare the Screen

The EASYmaxx screen comes with a pre-assembled frame and integrated net, eliminating the need for cutting or gluing. Simply unpack the screen.

TELAIO PREASSEMBLATO CON RETE INTEGRATA

- nessun taglio e scarto



Image: A close-up view of the pre-assembled frame with its integrated net, highlighting that no cutting or waste is involved in the setup process. The image also shows the extensible frame and how the net adapts to the extended size.

3. Install the Screen

The installation process is straightforward:

1. **Unpack and Extend:** Gently unroll the screen and extend the telescopic frame to roughly match your window opening.
2. **Position:** Place the pre-assembled screen into the window opening.
3. **Secure:** Push the lower spring stops into the corners of the window frame.
4. **Adjust:** Simply extend the frame until it fits snugly and securely into the desired dimensions of your window. The integrated net will adapt to the extended size.

SENZA INSETTI IN 3 MINUTI!



Image: Visual guide demonstrating the quick 'Super-Fix' installation process, showing a window with the screen installed and icons indicating no drilling or cutting is required. The image highlights the minimal time needed for setup.

The screen is designed to be immediately effective against insects like mosquitoes, wasps, flies, and spiders upon proper installation.



Image: An illustrative image depicting various common insects such as mosquitoes, wasps, flies, beetles, and spiders on the fine mesh of the EASYmaxx screen, underscoring its effectiveness in providing reliable insect protection.

OPERATING AND USAGE


Once installed, the EASYmaxx Insect Protect screen provides continuous insect protection while allowing fresh air to circulate. The special black fabric is designed to be nearly invisible, ensuring an optimal view without darkening your room.

EASYMAXX INSECT PROTECT

Più trasparenza



Passaggio d'aria affidabile



TESSUTO STANDARD

Meno trasparenza



Meno aria fresca




Image: A visual comparison demonstrating the superior transparency and reliable airflow of the EASYmaxx Insect Protect screen compared to standard fabric screens, which offer less transparency and reduced fresh air circulation.

The elastic and resilient mesh adapts to the frame's size when extended and maintains its shape, even with repeated mounting and dismounting. This allows you to enjoy ventilation or sleep with your window open without disturbance from insects.

PROTEGGERE LA TUA FAMIGLIA

24 ore su 24 una sensazione
di sicurezza.



Prevenire le punture di insetti



Mangiare, cucinare, ventilare indisturbati



Dormire con la finestra aperta

Image: A collage illustrating the benefits of using the EASYmaxx screen for family protection, including preventing insect bites, allowing undisturbed eating, cooking, and ventilation, and enabling comfortable sleep with open windows.

MAINTENANCE

To ensure the longevity and effectiveness of your EASYmaxx Insect Protect screen, follow these simple maintenance guidelines:

- **Cleaning:** The weather-resistant mesh can be gently cleaned with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the fabric or frame.
- **Storage:** For seasonal storage, the screen can be collapsed and stored in a dry, protected area. Ensure it is clean and dry before storing to prevent mold or mildew.
- **Inspection:** Periodically inspect the mesh for any tears or damage. While the fabric is resilient, sharp objects can cause punctures.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause / Solution
Screen appears opaque or blocks too much light/air.	The elastic mesh is designed to be taut. Ensure the screen is fully extended to its maximum possible dimensions within your window opening. The mesh becomes more transparent and allows better airflow when properly stretched.
Difficulty retracting the screen or re-inserting sliding hooks.	The mechanism requires careful handling. Apply gentle, even pressure when collapsing the frame. If hooks are difficult to re-insert, ensure the frame is aligned correctly and not twisted. Avoid forcing the components.
Hooks or clips seem to deform window seals over time.	While designed for secure fit, prolonged pressure on certain window seal types might cause minor impressions. Ensure the screen is installed correctly and not overly tight. If concerned, consider removing the screen during periods of non-use.
Screen does not fit window opening.	Verify your window dimensions against the product's specified range (70x80 cm to 115x135 cm). Ensure there are no obstructions preventing the screen from fully extending or seating properly. Refer to the "Check Window Compatibility" section.

SPECIFICATIONS

Feature	Detail
Brand	EASYmaxx
Model Number	14883
Manufacturer	DS Produkte GmbH
Product Dimensions (Collapsed)	120 x 140 x 3 cm
Adjustable Dimensions (Min-Max)	Width: 70 cm - 115 cm; Height: 80 cm - 135 cm (Note: Based on product feature bullets. Some images suggest slightly different ranges.)
Color	Anthracite
Style	Window
Material	ABS, Aluminum, Nylon, Elastane, Steel
Shape	Rectangular
Installation Method	Clamps (Telescopic, no drilling/screws)
Special Features	Telescopic Mosquito Screen, Pre-assembled Frame, Integrated Net
Included Components	2 aluminum frames with integrated mosquito net (for the 2-piece set)
Item Weight	4.16 Kilograms

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation provided with your purchase or contact the retailer from whom you purchased the EASYmaxx Insect Protect screen. Warranty terms and conditions may vary by region and retailer.

If you require technical support or have questions not covered in this manual, please contact the manufacturer, DS Produkte

GmbH, or your point of purchase for assistance.