

Yomile AD005-UK

Yomile Mini Vacuum Cleaner & Air Duster User Manual

Model: AD005-UK

Brand: Yomile

INTRODUCTION

This user manual provides comprehensive instructions for the Yomile 2-in-1 Mini Vacuum Cleaner and Air Duster (Model AD005-UK). This versatile device combines powerful vacuuming capabilities with high-speed air dusting, making it ideal for cleaning various environments such as cars, offices, and homes. Please read this manual thoroughly before operating the device to ensure safe and efficient use.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- Yomile 2-in-1 Mini Vacuum Cleaner & Air Duster Unit
- Flat Nozzle (for vacuuming)
- Brush Nozzle (for vacuuming and dusting)
- Long Brush Nozzle (for dusting)
- Narrow Nozzle (for dusting)
- Wide Nozzle (for air pump function)
- Washable HEPA Filter (pre-installed)
- USB-C Charging Cable
- Storage Bag
- User Manual



Image: The Yomile 2-in-1 Mini Vacuum Cleaner and its complete set of accessories, including various nozzles, charging cable, and storage bag.

PRODUCT OVERVIEW

The Yomile AD005-UK features a compact, ergonomic design with a powerful brushless motor. It offers both vacuuming and air dusting functionalities, easily switchable by reconfiguring the attachments.

Key Components:

- **Main Unit:** Contains the brushless motor, battery, and control buttons.
- **Dust Collection Bin:** Transparent bin for collecting debris in vacuum mode.
- **HEPA Filter:** Washable filter located inside the dust collection bin.
- **Power Button:** Controls power on/off and speed settings.
- **Charging Port:** USB-C port for recharging the device.

210000RPM BRUSHLESS MOTOR



Image: An internal view highlighting the powerful brushless motor, which provides high RPM for both vacuuming and air dusting.

SETUP

Initial Charging:

Before first use, fully charge the device.

1. Connect the provided USB-C charging cable to the device's charging port.
2. Plug the other end of the USB-C cable into a compatible USB power adapter (not included) or a USB port on a computer.
3. The battery indicator lights on the device will illuminate during charging. A full charge typically takes 3-4 hours.
4. Once fully charged, the indicator lights will change or turn off, depending on the unit's design.



Image: The device displaying its battery charge level and the USB-C charging port for convenient recharging.

Attaching Accessories:

Accessories can be attached to either the suction end (for vacuuming) or the blowing end (for dusting/blowing).

- Align the desired nozzle with the appropriate port on the device.
- Gently push and twist until the nozzle is securely in place.
- To remove, twist and pull the nozzle off.

OPERATING INSTRUCTIONS

Power On/Off and Speed Adjustment:

The device features a single power button for control.

- **To Power On:** Press and hold the power button for approximately 3 seconds until the device starts.
- **To Adjust Speed:** Briefly press the power button while the device is on to cycle through the 3 available speed settings (Low,

Medium, High).

- **To Power Off:** Press and hold the power button for approximately 3 seconds, or briefly press the button when the device is at its highest speed setting.

Vacuum Mode:

Attach the flat nozzle or brush nozzle to the suction inlet.

- Power on the device and select the desired suction speed.
- Direct the nozzle towards the area to be cleaned.
- Move the vacuum slowly over the surface to effectively pick up dust, crumbs, pet hair, and other small debris.



Image: The Yomile mini vacuum cleaner effectively cleaning debris from car seats and tight spaces around the console.

Air Duster Mode:

Attach the long brush nozzle, narrow nozzle, or wide nozzle to the air outlet.

- Power on the device and select the desired blowing speed.

- Direct the nozzle towards the area where dust needs to be blown away, such as computer keyboards, car vents, or electronic components.
- Use short bursts of air for delicate items or continuous flow for larger areas.

210000RPM BRUSHLESS MOTOR COMPRESSED AIR DUSTER



Image: The Yomile air duster effectively removing dust from a computer tower's internal components and a laptop keyboard.

Your browser does not support the video tag.

Video: Official demonstration of the Yomile 2-in-1 Mini Car Vacuum and Air Duster, showcasing its dual functionality and effectiveness in various cleaning scenarios.

MAINTENANCE

Emptying the Dust Collection Bin:

For optimal performance, empty the dust collection bin regularly, especially after each significant use.

1. Ensure the device is powered off.
2. Twist and detach the dust collection bin from the main unit.

- 3. Carefully remove the HEPA filter from the bin.
- 4. Empty the collected debris into a trash receptacle.

Cleaning the HEPA Filter:

The HEPA filter is washable and reusable. Clean it periodically to maintain suction power.

- 1. After removing the filter from the dust bin, tap it gently to dislodge loose dust.
- 2. Rinse the filter under cool running water until the water runs clear.
- 3. Allow the filter to air dry completely for at least 24 hours before reinserting it into the device. *Do not use the device with a wet filter.*



Image: The washable HEPA filter being rinsed under water, demonstrating the ease of maintenance.

Cleaning the Device Exterior:

Wipe the exterior of the device with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

If you encounter issues with your Yomile Mini Vacuum Cleaner & Air Duster, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB-C cable.
Weak suction/blowing power.	Dust collection bin is full. Filter is clogged. Nozzle is blocked.	Empty the dust collection bin. Clean or replace the HEPA filter. Check and clear any blockages in the nozzle or air pathways.

Problem	Possible Cause	Solution
Device stops unexpectedly.	Battery is low. Overheating protection activated.	Recharge the device. Allow the device to cool down for a few minutes before resuming use.
Unusual noise during operation.	Debris caught in the motor or fan. Loose component.	Power off the device and carefully inspect for any foreign objects. If the issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact Yomile customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	Yomile
Model Name	AD005-UK
Special Feature	Portable, 2-in-1 Vacuum & Air Duster
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	0.3 Liters
Wattage	6.5 watts
Runtime	Up to 40 minutes
Form Factor	Handheld
Color	Sliver
Product Dimensions	4.23"L x 2.4"W x 7"H
Battery Type	Lithium-Ion (9000mAh)
Charging Time	3-4 hours (USB-C Fast Charging)
Number of Speeds	3
Item Weight	1.1 pounds

SAFETY INFORMATION

Please adhere to the following safety guidelines to prevent injury or damage to the device:

- Do not operate the device with wet hands or near water.
- Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- Do not vacuum or blow flammable or combustible liquids, such as gasoline, or use in areas where they may be present.

- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Store the device in a dry place when not in use.
- Keep out of reach of children.

WARRANTY AND SUPPORT

Yomile is committed to providing high-quality products and excellent customer service.

- **After-Sale Service:** Enjoy 24 months of after-sale service from the date of purchase.
- **Customer Support:** Our customer support team is available 7 days a week, 24 hours a day, to assist you with any inquiries or issues.
- **Return Policy:** This product is eligible for a return or replacement within 30 days of receipt.

For warranty claims or technical support, please contact us through the platform where you purchased the product or visit the official Yomile website for contact information.




Image: A customer service representative, symbolizing the available 24/7 customer support and hassle-free service.

© 2025 Yomile. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question