

[Manuals.plus](#) /

› [Dtirszxy](#) /

› Dtirszxy Replacement Remote Control User Manual for TD Systems K40DLX11FS, K43DLX11US, K50DLX11US, K58DLX11U UHD LED HDTV TVs

Dtirszxy K40DLX11FS, K43DLX11US, K50DLX11US, K58DLX11U

Dtirszxy Replacement Remote Control User Manual

For TD Systems K40DLX11FS, K43DLX11US, K50DLX11US, K58DLX11U UHD LED HDTV TVs

1. INTRODUCTION

This manual provides instructions for the Dtirszxy Replacement Remote Control, designed for use with various TD Systems UHD LED HDTV models including K40DLX11FS, K43DLX11US, K50DLX11US, and K58DLX11U. This remote control operates using infrared technology and requires no complex setup.

2. SETUP

2.1 Battery Installation

To begin using your remote control, you must install two new batteries (not included). Ensure correct polarity (+/-) when inserting the batteries into the compartment.



Figure 1: Battery compartment with batteries being inserted.

2.2 Initial Use

No setup is required. After installing new batteries, the remote control is ready for immediate use with compatible TD Systems TVs.

3. OPERATING INSTRUCTIONS

For proper operation, point the remote control directly towards the signal receiving window of your television. Ensure there are no obstructions between the remote and the TV.



Figure 2: Front view of the remote control.

3.1 Basic Functions

- **Power Button (U)**: Turns the TV on or off.
- **Number Buttons (0-9)**: Selects channels directly.
- **Volume Up/Down (VOL +/-)**: Adjusts the volume level.
- **Channel Up/Down (CH +/-)**: Changes channels sequentially.
- **Mute Button ()**: Mutes or unmutes the TV audio.
- **Menu Button (MENÚ)**: Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **Input Button (ENTRADA)**: Selects the input source (HDMI, AV, etc.).
- **Exit Button (SALIR)**: Exits the current menu or function.
- **Info Button (INFO)**: Displays program information.

4. MAINTENANCE

4.1 Battery Care

- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Do not mix old and new batteries.
- Do not mix different types of batteries (e.g., alkaline with rechargeable).
- Replace all batteries at the same time with new ones of the same type.






Figure 3: Back view of the remote control, showing the battery cover.

5. TROUBLESHOOTING

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are correctly installed and have sufficient charge. Replace with new batteries if necessary.
- **Line of Sight:** Make sure there are no objects blocking the path between the remote control and the TV's infrared sensor.
- **Distance:** Ensure you are within the effective operating range (up to 10 meters) of the TV.
- **TV Compatibility:** Verify that your TV model is listed as compatible with this remote control.

6. SPECIFICATIONS

Feature	Specification
Brand	Dtirszyx
Compatible Devices	TD Systems K40DLX11FS, K43DLX11US, K50DLX11US, K58DLX11U UHD LED HDTV TVs
Connectivity Technology	Infrared

Maximum Range	10 Meters
Max Number of Supported Devices	1
Color	Black
UPC	763114237914

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This product comes with a 90-day warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For any questions or issues not covered in this manual, please refer to the seller's contact information provided at the time of purchase.

© 2024 Dtirszy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D11TWM5V>

More documents and user manuals: <https://manuals.plus/>