

ECONTROLLY SENUO-A6500

ECONTROLLY Replacement Remote Commander User Manual

Model: SENUO-A6500

1. INTRODUCTION

This manual provides instructions for the ECONTROLLY Replacement Remote Commander, designed for use with various iSTAR Box OTT TV Receiver models. This remote control offers a direct replacement solution without the need for complex programming or pairing procedures. It is compatible with a wide range of iSTAR Box models, ensuring seamless operation for your entertainment system.

Compatible iSTAR Box OTT TV Receiver models include:


- ZEED222, ZEED333, ZEED4, ZEED5, ZEED 222, ZEED 333, ZEED 4, ZEED 5
- X50000, X60000, X70000
- A1600, A6500, A65000, A7000, A7500, A8000, A8500, A9000, A9700
- X1500, X2200, X25000, X35000, X40000

2. SETUP

The ECONTROLLY Replacement Remote Commander requires minimal setup. No programming or pairing is necessary. The primary setup step involves installing the batteries.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.



Battery type required:

2pcs AAA alkaline batteries (NOT included)



Image: Back of the remote control with the battery compartment open, indicating the required battery type (2x AAA alkaline batteries).

Once batteries are installed, the remote control is ready for use with your compatible iSTAR Box OTT TV Receiver.

3. OPERATING INSTRUCTIONS

This remote control provides standard functions for navigating and controlling your iSTAR Box OTT TV Receiver. Ensure there is a clear line of sight between the remote control and the receiver's infrared sensor for optimal performance.





Image: Front view of the remote control, displaying all functional buttons.

3.1 Button Functions Overview

- **Power (Red Button):** Turns the iSTAR Box OTT TV Receiver on or off.
- **Mute:** Mutes or unmutes the audio output.
- **MOTOR:** Function related to motor control (e.g., for satellite dish positioning, if applicable to your receiver model).
- **EPG:** Accesses the Electronic Program Guide.
- **TEXT:** Displays teletext or similar text-based information.
- **SUB:** Toggles subtitles on or off.
- **PLAY, PAUSE, STOP, RECALL, RECORD:** Standard media playback controls.
- **Rewind, Fast Forward, Previous, Next:** Navigation controls for media playback.
- **AUDIO:** Selects audio tracks or modes.
- **ZOOM:** Adjusts the screen zoom level.
- **INFO:** Displays program information.
- **F1:** A function key, its specific use may vary by receiver model.
- **SAT:** Switches between satellite inputs or modes.
- **MENU:** Accesses the main menu of the receiver.
- **OK:** Confirms selections or enters menus.
- **Arrow Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **EXIT:** Exits current menu or screen.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes channels.
- **DISPLAY:** Toggles display information on screen.
- **ONLINE TV:** Direct access to online TV features.
- **Number Pad (0-9):** Directly enters channel numbers or other numerical inputs.
- **TV/RADIO:** Switches between TV and Radio modes.
- **FAV:** Accesses favorite channels list.



Image: Demonstrating the remote control in use, pointing towards a television.

4. MAINTENANCE

Proper maintenance ensures the longevity and reliable performance of your remote control.

4.1 Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Refer to Section 2.1 for detailed battery installation instructions. Always use two new 1.5V AAA alkaline batteries.

4.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

4.3 Storage

When not in use for extended periods, store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for several months, it is advisable to remove the batteries to prevent leakage and potential damage to the remote.

5. TROUBLESHOOTING

If you encounter issues with your remote control, refer to the following troubleshooting steps:

- **Remote is unresponsive:**
 - Check if the batteries are correctly inserted with the correct polarity (+/-).
 - Replace the batteries with new 1.5V AAA alkaline batteries.
 - Ensure there is a clear line of sight between the remote control and the iSTAR Box OTT TV Receiver. Obstructions can block the infrared signal.
 - Verify that the iSTAR Box OTT TV Receiver is powered on.
- **Buttons are not working:**
 - Clean the remote control surface, especially around the buttons, to remove any dirt or debris that might be obstructing them.
 - If only specific buttons are not working, it might indicate a fault with the remote. Consider replacing the remote.
- **Short operating range:**
 - This often indicates low battery power. Replace the batteries.
 - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the infrared signal.

If these steps do not resolve the issue, the remote control may require replacement.

6. SPECIFICATIONS

Feature	Detail
Brand	ECONTROLLY
Model Number	SENUO-A6500
Product Dimensions (L x W x H)	5.91 x 1.97 x 0.59 inches (approximately 15 x 5 x 1.5 cm)
Item Weight	1.76 ounces
Color	Black
Special Feature	Ergonomic design
Max Number of Supported Devices	1 (iSTAR Box OTT TV Receiver)
Compatible Devices	TV Set Top Box (iSTAR Box OTT TV Receiver models)
Battery Type Required	2 x 1.5V AAA Alkaline Batteries (not included)





L: 17.5CM



W: 4.5CM

Image: Remote control with approximate length (17.5cm) and width (4.5cm) dimensions.

7. WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not available in the provided product data. For specific warranty details or support inquiries, please refer to the product packaging or contact the retailer or manufacturer directly.

ECONTROLLY Replacement Remote Commander User Manual - Model: SENUO-A6500

Please retain this manual for future reference.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D126KX4D>

More documents and user manuals: <https://manuals.plus/>