

Seealle lamp 04075

Seealle 22" Tall Modern Touch Bedside Lamps with USB C+A, 3 Way Dimmable

Model: lamp 04075 | Brand: Seealle

INTRODUCTION

Thank you for choosing the Seealle 22" Tall Modern Touch Bedside Lamps. This instruction manual provides essential information for the safe and efficient use of your new lamps. These lamps feature 3-way dimmable touch control, and convenient USB-C and USB-A charging ports, making them ideal for various settings such as bedrooms, living rooms, and offices.



Image: Two Seealle 22-inch tall modern lamps with white rectangular shades and black bases. One lamp shows a phone charging via its USB-C port, and another phone charging via its USB-A port. Two E26 LED bulbs are also shown next to the lamps.

SAFETY INSTRUCTIONS

- Ensure the lamp is unplugged before assembly, cleaning, or replacing the bulb.
- Do not use the lamp in wet or damp locations.
- Keep the lamp away from flammable materials.
- Use only E26 base LED bulbs as specified.
- Do not exceed the maximum wattage of 6 watts for the included LED bulbs.
- Avoid disassembling the lamp base or electrical components.

PACKAGE CONTENTS

Upon unpacking, please verify that all components are present:

- 2 x Lamp Bases (Black Metal)
- 2 x Fabric Lampshades (White)

- 2 x E26 LED Bulbs (6W, 3000K, 680 Lumens)
- 2 x Socket Rings

High Quality Table Lamp



Fabric Lampshade



USB A+C Charging Port



Standard E26 Base



LED Bulb Included

Image: All components of the Seealle lamp set: two black metal lamp bases, two white rectangular fabric lampshades, two E26 LED bulbs, and two socket rings.

SETUP AND ASSEMBLY

Assembly of your Seealle lamps is quick and straightforward. Follow these three simple steps:

1. **Install the Lampshade:** Carefully place the fabric lampshade onto the lamp base, aligning it with the socket.
2. **Screw the Socket Ring On:** Secure the lampshade by screwing the provided socket ring onto the lamp socket until it is firm.
3. **Install the Bulb:** Screw the included E26 LED bulb into the lamp socket. Ensure it is tightened securely.

Once assembled, plug the lamp into a standard 120V AC power outlet.

How To Install



Image: A three-step visual guide showing how to assemble the lamp: 1. Place the lampshade, 2. Screw on the socket ring, 3. Install the LED bulb.

OPERATING INSTRUCTIONS

Your Seealle lamp features intuitive touch control and 3-way dimmable brightness settings:

- **Turning On/Off:** Simply touch any metallic part of the lamp base or body to turn the lamp on or off.
- **Adjusting Brightness:** Each subsequent touch will cycle through the three brightness levels: Low (25%), Medium (60%), and High (100%). After the highest setting, the next touch will turn the lamp off.

Large Lamps for Living Room



Image: A visual demonstration of the 3-way dimmable touch control. The image shows a hand touching the lamp base and three different brightness levels: 25% (low), 60% (medium), and 100% (high).

Video Demonstration: 3-Way Dimmable Touch Lamps

Your browser does not support the video tag.

Video: A review demonstrating the 3-way dimmable touch functionality of the lamps, showing how to cycle through brightness levels by touching the lamp base.

CHARGING FEATURES

The lamp base is equipped with both a USB-C and a USB-A charging port, allowing you to conveniently charge two devices simultaneously. These ports function whether the lamp is turned on or off.

- **USB-C Port:** For modern devices requiring USB-C charging.
- **USB-A Port:** For devices compatible with standard USB-A charging.



Image: Close-up of the lamp base showing the integrated USB-C and USB-A charging ports on the back, with charging cables connected to two smartphones.

Video Demonstration: USB Charging Ports

Your browser does not support the video tag.

Video: A review highlighting the convenience of the USB-A and USB-C charging ports located on the lamp base, demonstrating their use for charging devices.

MAINTENANCE

- **Cleaning:** To clean the lamp, ensure it is unplugged. Wipe the metal base with a soft, dry cloth. For the fabric lampshade, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners on any part of the lamp.
- **Bulb Replacement:** When replacing the bulb, ensure the lamp is unplugged and the bulb has cooled. Unscrew the old E26 bulb and replace it with a new E26 LED bulb (max 6W).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Power cord not plugged in, faulty bulb, power outage.	Check power connection, replace bulb, check household circuit breaker.
Touch control is unresponsive.	Loose bulb, electrical interference.	Ensure bulb is tightly screwed in. Try plugging into a different outlet.
USB ports are not charging devices.	Device not compatible, faulty cable, lamp not powered.	Ensure device and cable are functional. Verify lamp is plugged into a live outlet.

SPECIFICATIONS

Feature	Detail
Model Number	lamp 04075
Dimensions	5.3"D x 12"W x 22"H
Weight	7.09 pounds (per set)
Material	Metal base, Fabric shade
Finish Type	Polished
Switch Type	Touch Control
Dimmable	3-Way (Low, Medium, High)
Charging Ports	1 x USB-C, 1 x USB-A
Bulb Base	E26
Light Source Type	LED
Wattage	6 watts (included bulb)
Brightness	680 Lumens
Color Temperature	3000 Kelvin (Neutral White)
Power Source	Corded Electric (120 Volts AC)
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

Seealle products are designed for quality and durability. For any questions, concerns, or support needs regarding your lamps, please contact Seealle customer service. Information regarding specific warranty terms can typically be found on the product packaging or the official Seealle website.

