Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Catitru BX17

Catitru BX17 Wireless Earbuds User Manual

Model: BX17

INTRODUCTION

Thank you for choosing the Catitru BX17 Wireless Earbuds. These Bluetooth headphones are designed for an immersive audio experience with extended playback, IPX7 waterproofing, and a power display, making them ideal for sports, workouts, and running. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your earbuds to ensure optimal performance.



Image: The Catitru BX17 Wireless Earbuds, showcasing their red color and over-ear hook design, placed within their open charging case. The charging case features a digital LED power display.

Package Contents

- BX17 Wireless Earbuds (Left and Right)
- Wireless Charging Case
- S, M, L Eartips (one set pre-installed)
- Type-C Charging Cable
- User Manual

Setup

1. Initial Charge

Before first use, fully charge the earbuds and the charging case. Connect the Type-C charging cable to the charging case and a power source. The LED power display on the case will indicate the charging status.



Image: A close-up of the charging case with its lid open, showing the digital LED display indicating battery percentages for both the case and the individual earbuds.

2. Pairing with Your Device (Bluetooth 5.3)

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "BX17" in the list of available Bluetooth devices and select it to connect.
4. Once connected, the earbuds will indicate successful pairing. For subsequent uses, the earbuds will automatically connect to the last paired device when the case is opened.



Image: An illustration depicting the Bluetooth 5.3 chip and a smartphone screen showing the "BX17" earbuds connected, emphasizing the fast and easy one-step pairing process.

3. Choosing the Right Ear Tips

The BX17 earbuds come with S, M, and L size ear tips. Select the size that provides the most comfortable and secure fit for optimal sound quality and noise isolation.



Image: A visual demonstrating the ergonomic design of the earbuds with flexible earhooks, alongside images of the three different ear tip sizes (S, M, L) to ensure a perfect fit.

Operating Instructions

Button Touch Controls

The BX17 earbuds feature intuitive button controls for easy management of music and calls. Refer to the table below for specific functions:

Action	Function
One Tap R/L	Answer/End Call
Long Press	Reject Call
One Tap R/L	Play/Pause Music

Action	Function
Long Press -	Previous Track
Long Press +	Next Track
One Tap +	Volume Up
One Tap -	Volume Down
Voice Assistant	Activate Voice Assistant



Image: A diagram illustrating the various button controls on the earbuds, showing icons for answering calls, voice assistant, track control, and volume adjustment.

Audio Features

- **Hi-Fi Stereo Sound:** Equipped with 12mm speaker driving units and a 14.3mm Graphene Diaphragm for strong bass and bright treble.

- **ENC Noise Cancelling:** Provides clear voice detection even in noisy environments, ensuring an immersive audio experience.



Image: An exploded view diagram showing the internal components of the earbud, highlighting the 14.3mm Graphene Diaphragm responsible for Hi-Fi stereo sound.

Battery and Charging

- **Playback Time:** Up to 15 hours on a single charge for one earbud.
- **Total Playtime with Case:** Up to 80 hours with multiple charges from the charging case.
- **Fast Charging:** The charging case supports Type-C fast charging.
- **LED Power Display:** The dual digital display on the charging case shows the remaining power for both the case and individual earbuds in real-time.



Image: A graphic illustrating the battery life, showing 1.5 hours for fast charging, 15 hours for a single earbud charge, and 60 hours from the charging case, totaling 80 hours of playback.

Maintenance

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Do not use abrasive cleaners or solvents.

Water Resistance (IPX7)

The BX17 earbuds are IPX7 waterproof, meaning they can withstand splashes, sweat, and rain. They are suitable for sports and workouts. However, they are not designed for swimming or prolonged submersion in water. Ensure the charging port is dry before charging.



Image: A visual emphasizing the IPX7 waterproof rating, showing water droplets and a person working out, indicating suitability for sports activities.

Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

Troubleshooting

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid to activate pairing mode. Make sure Bluetooth is enabled on your device and "BX17" is selected. Try forgetting the device on your phone and re-pairing.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.

- **Charging issues:** Ensure the Type-C cable is securely connected to both the case and the power source. Check if the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Poor sound quality:** Ensure the ear tips provide a good seal in your ear canal. Try different sized ear tips. Clean the earbud speakers if necessary.

Specifications

Feature	Detail
Model	BX17
Connectivity	Bluetooth 5.3
Playback Time (Earbud)	Up to 15 hours
Total Playtime (with Case)	Up to 80 hours
Charging Port	Type-C
Water Resistance	IPX7
Speaker Unit	12mm driving units, 14.3mm Graphene Diaphragm
Noise Cancellation	ENC Noise Cancelling Mic
Material	Plastic, Rubber, Silicone
Ear Placement	Over Ear (with earhooks)
Form Factor	In Ear

Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official Catitru website. Keep your proof of purchase for warranty claims.

© 2024 Catitru. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D12NW6YF

More documents and user manuals: **https://manuals.plus/**