Youroke YOSLPL071-2

Youroke 3-Pack Brushed Nickel Pendant Lights User Manual

Model: YOSLPL071-2

1. Introduction and Overview

Thank you for choosing the Youroke 3-Pack Brushed Nickel Pendant Lights. These modern hanging light fixtures are designed to provide ample illumination and enhance the aesthetic of various indoor spaces, including dining rooms, kitchen islands, hallways, living rooms, and bedrooms. Featuring a brushed nickel finish and white linen frosted glass shades, these lights offer adjustable hanging heights to suit your specific needs. This manual provides essential information for safe installation, operation, and maintenance of your new lighting fixtures.



Image: The Youroke 3-Pack Brushed Nickel Pendant Lights, showcasing their design and finish.

2. Safety Information

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).

Contact a qualified electrician if you are unfamiliar with proper electrical wiring.

- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the bulb.
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture when in operation.
- This product is designed for indoor use only. Do not expose to water or excessive moisture.

3. Package Contents

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact Youroke customer service.

- 3 x Pendant Light Fixtures (with canopy, rod, and lamp holder)
- 3 x White Linen Frosted Glass Shades
- 12 x Rods (4 rods per lamp: 2 x 10-inch, 2 x 6-inch)
- Mounting Hardware Kit (screws, wire nuts, mounting plate)
- Instruction Manual

Note: Bulbs are not included. This fixture requires E26 socket base bulbs.

4. Setup and Installation

Follow these steps carefully for proper installation. Professional installation is recommended if you are unsure about any steps.

4.1 Pre-Installation

1. **Turn off power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where you will be installing the light fixture.
2. **Unpack contents:** Carefully remove all components from the packaging and inspect for any damage.
3. **Determine hanging height:** The fixture's height is adjustable using the included rods. Each lamp includes two 10-inch rods and two 6-inch rods, allowing for various configurations. The minimum hanging height is 16 inches, and the maximum is 42 inches.



Image: Dimensions and adjustable rod lengths for the pendant light.

4.2 Wiring and Mounting

1. **Attach mounting plate:** Secure the mounting plate to the junction box using the provided screws.
2. **Connect wires:**
    - Connect the fixture's black wire to the house's black (Live) wire using a wire nut.
    - Connect the fixture's white wire to the house's white (Neutral) wire using a wire nut.
    - Connect the fixture's ground wire to the house's ground wire (bare copper or green) or to the green grounding screw on the mounting plate.
3. **Tuck wires:** Carefully tuck all wires into the junction box.
4. **Attach canopy:** Align the canopy with the mounting plate and secure it with the provided screws or nuts.



Image: Step-by-step visual guide for connecting wires and assembling the light fixture.

4.3 Final Assembly

1. **Attach rods:** Screw the desired combination of 10-inch and 6-inch rods to the lamp holder and the canopy.
2. **Install glass shade:** Carefully attach the white linen frosted glass shade to the lamp holder by rotating it until secure. The open bottom design allows for easy bulb replacement.
3. **Install bulb:** Insert an E26 base bulb (not included) into the socket.
4. **Restore power:** Turn the power back on at the circuit breaker or fuse box.
5. **Test fixture:** Turn on the light switch to ensure the fixture is working correctly.

5. Operating Instructions

The Youroke Pendant Lights operate via a standard wall switch connected to your home's electrical system. Ensure the correct E26 base bulbs are installed.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the lights on or off.
- **Dimmable Functionality:** These fixtures are fully dimmable when used with compatible dimmable E26 bulbs and a dimmer switch (both sold separately).
- **Bulb Compatibility:** Compatible with a variety of incandescent, LED, CFL, and halogen E26 base bulbs.



Image: Compatible E26 bulb types for the Youroke Pendant Lights.

6. Maintenance

Regular cleaning and proper care will help maintain the appearance and functionality of your pendant lights.

- **Cleaning:**
  - Always disconnect power before cleaning.
  - Wipe the metal finish with a soft, dry cloth. Avoid abrasive cleaners or polishes that could damage the finish.
  - Clean the glass shades with a soft, damp cloth and a mild glass cleaner if necessary. Dry thoroughly.
- **Bulb Replacement:**
  - Ensure the fixture is cool before replacing bulbs.
  - Twist the glass shade to remove it, then unscrew the old bulb and screw in a new E26 base bulb.
  - Reattach the glass shade securely.

7. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	• Power is off at the circuit breaker. • Loose wire connections. • Faulty bulb. • Faulty wall switch.	• Check the circuit breaker and ensure power is on. • Verify all wire connections are secure (ensure power is off before checking). • Replace the bulb with a known good one. • Test or replace the wall switch.
Light flickers.	• Loose bulb. • Incompatible dimmer switch/bulb. • Loose wire connections.	• Tighten the bulb. • Ensure dimmer and bulb are compatible. • Check wire connections (ensure power is off before checking).
Glass shade is loose.	• Shade not properly secured.	• Gently twist the glass shade until it is firmly seated and locked into place.

8. Specifications

Feature	Detail
Brand	Youroke
Model Name	YOSLPL071-2
Color	White Linen Glass
Material	Metal, Glass
Style	Modern
Light Fixture Form	Pendant
Product Dimensions (L x W x H)	16"L x 3.9"W x 42"H (Max)
Indoor/Outdoor Usage	Indoor
Power Source	Electric (Hardwired)
Special Feature	Dimmable (with compatible bulb/switch)
Finish Type	Brushed Nickel

Feature	Detail
Number of Light Sources	3 (per pack)
Voltage	120 Volts
Bulb Base	E26
Wattage (Max)	60W per bulb
Assembly Required	Yes
Item Weight	6.14 pounds (total for 3-pack)

9. Warranty and Support

Youroke stands behind the quality of its products. For any damaged parts or questions regarding your 3-pack brushed nickel pendant lights, please contact our customer service team. We are committed to resolving your problem within 24 hours.

Please refer to your purchase documentation for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

Contact Information: Refer to the contact details provided on the product packaging or the Youroke official website for the most up-to-date support information.

© 2025 Youroke. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question