

AULA F2088 PRO

AULA F2088 Pro Mechanical Keyboard User Manual

Model: F2088 PRO | Brand: AULA

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your AULA F2088 Pro 108-Key Purple Mechanical Keyboard. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The AULA F2088 Pro is a versatile mechanical keyboard designed for both gaming and everyday use, featuring customizable RGB backlighting, durable red switches, and an ergonomic design.



Figure 1: AULA F2088 Pro Mechanical Keyboard with vibrant RGB backlighting.

PACKAGE CONTENTS

Ensure all items are present in the package:

- AULA F2088 Pro Mechanical Keyboard
- Keycap Puller
- User Manual (this document)

SETUP

1. Connecting the Keyboard

The AULA F2088 Pro keyboard uses a wired USB-A connection for reliable performance. Simply plug the USB-A cable from the keyboard into an available USB port on your computer.

- **Compatibility:** The keyboard is plug-and-play and compatible with Windows, Mac, and Linux operating systems. No additional drivers are required.

2. Adjusting Ergonomics

For enhanced comfort during extended use, the keyboard features two adjustable kickstands on the underside. These allow you to set the keyboard at an angle of up to 7°.

More Comfort with Ergonomic Design



Figure 2: Adjustable kickstands provide ergonomic comfort for typing.


To adjust the angle, gently pull out the kickstands located at the rear corners of the keyboard until they lock into position. Push them back in to return the keyboard to a flat position.

OPERATING THE KEYBOARD

1. Magnetic Top Cover and Style Switching

The AULA F2088 Pro features a removable magnetic top cover, allowing you to switch between recessed (with cover) and floating (without cover) keycap styles. The cover also helps protect the keyboard from dust.

AULA F2088PRO KEYBOARD



**WITH Magnetic Cover:
Office Mode**

ONE KEYBOARD, TWO MODES

**WITHOUT the Cover:
Gaming Mode
Floating Cover Panel**





Figure 3: The keyboard supports two distinct styles: "Office Mode" with the magnetic cover attached, and "Gaming Mode" with the cover removed, revealing floating keycaps.

To remove the cover, gently lift it from any edge. It will detach easily due to its magnetic attachment. To reattach, simply align it over the keyboard and it will snap into place.

2. RGB Backlighting and Media Control

The keyboard features vibrant RGB backlighting with 21 different effects. Control is managed via the rotary knob and dedicated media keys.

Backlighting & Media Control

One button, dual mode
Adjust the light & volume



Figure 4: The multi-function knob and dedicated buttons for backlighting and media control.

- **Knob Functionality:**

- **Short Press:** Toggles between 21 different lighting effects.
- **Rotate:** Adjusts the brightness of the backlighting or volume (depending on mode).

- **Dual Mode (Gaming/Office):** Long press the knob to switch between Gaming Mode and Office Mode.

- **Gaming Mode:** Short press the knob to cycle through lighting effects. Long press M1, M2, and M3 keys to set custom light effects.
- **Office Mode:** Short press the knob to mute/unmute audio. M1, M2, M3 keys switch to previous track, next track, or play/pause.

- **Multimedia Keys (FN Combinations):** The keyboard includes 12 multimedia keys accessible via the FN key.

- FN + ESC: Restore Factory Settings
- FN + F1: My Computer
- FN + F2: Search

- FN + F3: Calculator
- FN + F4: Player
- FN + F5: Previous One
- FN + F6: Next One
- FN + F7: Play/Pause
- FN + F8: Stop
- FN + F9: Mute
- FN + F10: Volume+
- FN + F11: Volume-
- FN + F12: Keyboard Lockout

Your browser does not support the video tag.

Video 1: Official AULA demonstration of the F2088 Pro keyboard's RGB backlighting effects and features.

3. Anti-Ghosting and Programmable Macros

The keyboard features full keys anti-ghosting, ensuring accurate registration of every keystroke, even during rapid multi-key presses. This is particularly beneficial for gaming.

All Keys Anti-ghosting

Easily perform any combination Of functions without conflicting keys



Figure 5: All keys anti-ghosting ensures precise input during complex commands.

The programming macro function allows you to customize keyboard functions to suit your specific needs, enhancing productivity and gaming performance.

MAINTENANCE

1. Cleaning the Keyboard

Regular cleaning helps maintain the keyboard's appearance and functionality. The removable magnetic top cover and floating keycaps make cleaning easier.

- **Keycap Removal:** Use the provided keycap puller to carefully remove individual keycaps for thorough cleaning of internal dirt.
- **Surface Cleaning:** Use a soft, damp cloth to wipe down the keycaps and keyboard surface. Avoid excessive moisture.

- **Dust Removal:** Use compressed air to blow away dust and debris from between the keys.



Figure 6: Floating keycaps design allows for easier cleaning and access to mechanical switches.

The durable ABS keycaps are designed to resist scratching and fading, ensuring long-lasting use.

TROUBLESHOOTING

If you encounter any issues with your AULA F2088 Pro keyboard, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Keyboard not responding	Loose USB connection, incorrect USB port, system error.	Ensure the USB cable is securely plugged into a working USB-A port. Try a different USB port or restart your computer.
Backlighting not working or incorrect	Lighting effect turned off, brightness too low, software glitch.	Short press the rotary knob to cycle through lighting effects. Rotate the knob to adjust brightness. Try FN + ESC to restore factory settings.
Keys not registering (ghosting)	Software conflict, extreme multi-key press beyond anti-ghosting limits (unlikely for full keys anti-ghosting).	Ensure no conflicting software is running. The keyboard features full keys anti-ghosting, so this should be rare. Restart your computer.
Multimedia keys not functioning	Incorrect mode, software issue.	Ensure you are in the correct mode (Gaming/Office) for the desired multimedia function. Check your operating system's media key settings.

If the issue persists after trying these solutions, please contact AULA customer support for further assistance.

SPECIFICATIONS

- **Model:** F2088 PRO
- **Number of Keys:** 108
- **Switch Type:** Mechanical Red Switches
- **Connectivity:** USB-A (Wired)
- **Backlighting:** RGB Rainbow Backlit (21 effects)
- **Keycap Material:** Durable ABS
- **Special Features:** Removable Magnetic Upper Cover, Aesthetic Media Control Knob, Programmable Macros, Full Keys Anti-Ghosting, Ergonomic Design (7° adjustable kickstands)
- **Dimensions (LxWxH):** 17.5 x 6.93 x 2.04 inches
- **Weight:** 2.25 pounds
- **Operating System Compatibility:** Windows, Mac, Linux
- **Color:** Purple

WARRANTY AND SUPPORT

AULA provides a comprehensive **48-month after-sales service** for the F2088 Pro keyboard. This service covers product quality problems and provides support for usage inquiries.

For warranty claims, technical support, or any questions regarding your product, please contact AULA Tech USA customer service. Refer to the contact information provided on the product packaging or the official AULA website.

Your satisfaction is our greatest pursuit!

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question