

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [YESHOMY](#) /

› [YESHOMY Corner Fireplace TV Stand for Televisions up to 55 inches, Model YH-TS23-0214-GYNEW](#)

YESHOMY YH-TS23-0214-GYNEW

YESHOMY Corner Fireplace TV Stand Instruction Manual

Model: YH-TS23-0214-GYNEW

Brand: YESHOMY

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your YESHOMY Corner Fireplace TV Stand. This unit is designed to accommodate televisions up to 55 inches, offering both media storage and an integrated electric fireplace for supplemental heating and ambiance. Please read all instructions carefully before assembly and use to ensure safe and proper operation.

IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines:

- Product color may vary slightly due to lighting and display settings.
- The item is delivered in two separate packages (TV console and electric fireplace insert). These packages may arrive at different times. Handle with care to prevent injury or damage during unpacking and assembly.
- Ensure all parts are tightly assembled for stability.
- Do not cover the fireplace unit's vents during operation.
- Keep flammable materials away from the electric fireplace.
- Always plug the fireplace directly into a wall outlet. Do not use extension cords or power strips.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Corner Fireplace TV Stand (main console components)
- 1 x Electric Fireplace Insert
- 1 x Tool Kit (for assembly)
- 1 x Installation and Usage Manual (this document)

Note: The TV console and fireplace are shipped in separate boxes and may arrive at different times.



SHIPPED IN TWO PACKAGES

May arrive at different times



Transport express delivery

Figure 1: Illustration of the two-package delivery process for the TV stand and fireplace.

SETUP AND ASSEMBLY

Assembly is required for this product. Follow the clear instructions provided in the included manual and use the provided tool kit. While assembly can be completed by one person, having a second person may simplify the process, especially when handling larger components.

1. Unpack all components and verify against the package contents list.
2. Identify all hardware and panels. The assembly utilizes cams and anchors.
3. Assemble the main TV stand frame according to the step-by-step diagrams.
4. Once the frame is assembled, carefully insert the electric fireplace unit into its designated opening.
5. Secure the fireplace unit as instructed.
6. Attach the glass-fronted cabinet doors and adjustable shelves.
7. Place the assembled unit in your desired corner location. Ensure proper ventilation around the fireplace.



Figure 2: Front view of the assembled TV stand with fireplace.



Figure 3: Front view of the assembled TV stand.

Detachable Fireplace

When you don't need the fireplace, you can remove the fireplace and replace it with board.



Figure 4: Side view of the assembled TV stand.

18"Electric: Fireplace with Remote

The fireplace can be used as a space heater with temperatures ranging from 60-82°F.



Timer Button
[0.5-9 hours]



Heater Button
[60-82°F / 99°F]



Flame Effect
[3D Flame]



Control Switch
[With Remote]



The fireplace and TV stand are divided into two packages.
So the delivery time may be different.

Figure 5: Rear view of the TV stand, illustrating cable access points.

OPERATING INSTRUCTIONS

Electric Fireplace Operation

The electric fireplace can be operated using the control panel on the unit or the included remote control. It features adjustable flame effects and a heating function.

- Power On/Off:** Press the power button on the unit or remote to turn the fireplace on or off.
- Flame Effect:** Adjust the 3D flame effect intensity (Low/Med/High) using the dedicated button. The flame effect can be used independently of the heating function.
- Heating Function:** The fireplace can function as a space heater with temperatures ranging from 60-82°F (or 99°F as indicated on some models). Activate the heater using the heater button.
- Timer:** Set an operating timer for 0.5 to 9 hours using the timer button.
- Digital Display:** The digital display on the unit will show current settings and will time out after a period of inactivity to maintain ambiance.

Your browser does not support the video tag.

Video 1: Demonstration of the YESHOMY Corner Fireplace TV Stand features, including flame effects, heating, and remote control operation.




Figure 6: Detail of the electric fireplace control panel and remote functions.

Storage and Design Features

- **Corner Design:** The unit's corner-fitting design optimizes space utilization in living rooms or bedrooms.
- **Multiple Storage Spaces:** Features two glass-fronted cabinets with adjustable shelves and open storage space above the fireplace for media devices, books, or decorative items.
- **Detachable Fireplace:** The electric fireplace insert is removable. A shelving piece can be installed in its place during warmer months if the heating function is not desired, converting the unit into a standard media console.
- **TV Compatibility:** Designed to accommodate televisions up to 55 inches.



Figure 7: The fireplace insert is detachable, allowing for alternative storage space.



Figure 8: The corner design effectively utilizes room space.



SHIPPED IN TWO PACKAGES

May arrive at different times



Transport express delivery

Figure 9: TV size compatibility up to 55 inches.

MAINTENANCE

- **Cleaning:** Wipe the wood surfaces with a soft, damp cloth. Avoid harsh chemicals that may damage the finish. For the fireplace glass, use a non-abrasive glass cleaner.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Fireplace Vents:** Ensure the air intake and outlet vents of the electric fireplace are kept clear of dust and obstructions to maintain proper airflow and prevent overheating.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.

TROUBLESHOOTING

- **Fireplace Not Turning On:**
 - Ensure the unit is properly plugged into a functional wall outlet.

- Check if the power switch on the unit is in the "ON" position.
- Verify that the remote control batteries are not depleted.

- **No Heat Output:**

- Confirm the heating function is activated via the control panel or remote.
- Check for any obstructions blocking the heater's air vents.

- **Unstable Unit:**

- Re-check all assembly fasteners and tighten any loose connections.
- Ensure the unit is placed on a flat, level surface.






SPECIFICATIONS

Feature	Detail
Brand	YESHOMY
Model Name	Corner Fireplace TV Stand
Item Model Number	YH-TS23-0214-GYNEW
Color	Brown
Product Dimensions	13.9"D x 47.2"W x 31.6"H
Item Weight	88 Pounds
Material	Wood
Finish Type	Rustic
Mounting Type	Floor Mount
Room Type	Living Room
Special Feature	Adjustable Shelf
Storage Options	Two cabinets, one open shelf, and five racks
Assembly Required	Yes
Included Components	Electric Fireplace, TV Stand, Technical Manual

WARRANTY AND SUPPORT

For any questions regarding product warranty, missing parts, or technical support, please contact YESHOMY customer service. Refer to your purchase documentation for specific warranty terms and contact information. General customer support information may be available through the [YESHOMY Store on Amazon](#).

Related Documents - YH-TS23-0214-GYNEW

	<p><u>YESHOMY TV Stand Assembly Instructions</u></p> <p>Comprehensive assembly guide for the YESHOMY TV Stand, featuring sliding barn doors and storage. Includes parts identification, hardware list, and step-by-step instructions for building your furniture.</p>
	<p><u>YESHOMY TV Stand Assembly Instructions</u></p> <p>Comprehensive assembly guide for the YESHOMY TV Stand, featuring sliding barn doors and storage. Includes parts identification, hardware list, and step-by-step instructions for building your furniture.</p>
	<p><u>VEVOR YH-MS050C3 Miter Saw Stand User Manual</u></p> <p>Official user manual for the VEVOR YH-MS050C3 Miter Saw Stand, providing setup, safety, and usage instructions. Learn about features and specifications for VEVOR tools.</p>
	<p><u>TURBRO SUBURBS TS23-C Electric Fireplace Stove User Manual</u></p> <p>Comprehensive user manual for the TURBRO SUBURBS TS23-C Electric Fireplace Stove, covering installation, operation, safety, maintenance, and troubleshooting.</p>
	<p><u>VEVOR YJX-SNJ-006 Stand Corner Shelf Assembly Instructions and Product Guide</u></p> <p>Official assembly instructions and product details for the VEVOR YJX-SNJ-006 Stand Corner Shelf. Learn how to safely assemble and use your new corner shelving unit.</p>
	<p><u>VEVOR 5-in-1 Multi-Function Work Station User Manual</u></p> <p>Comprehensive user manual for the VEVOR 5-in-1 Multi-Function Work Station, including models YH-MS055-1 and YH-MS055F-1. Covers safety guidelines, component identification, detailed assembly instructions, miter saw mounting procedures, folding and storage, functional descriptions, and technical specifications. Contact information for support is also provided.</p>

