

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [EasyKeys](#) /

› [EasyKeys Replacement Key for Arctic Cat C51006 Instruction Manual](#)

EasyKeys C51006

EasyKeys Replacement Key for Arctic Cat C51006 Instruction Manual

PRODUCT OVERVIEW

This manual provides instructions for the EasyKeys Replacement Key, model C51006. This key is designed for Arctic Cat vehicles and is also compatible with specific Suzuki and Yamaha models. It is cut on an X117 key blank.

Compatible Manufacturers:

- Arctic Cat
- Suzuki
- Yamaha
- Hyosung (GCODE / INSTACODE series)

The C51006 key is part of the Arctic Cat Key Series C50000 - C59999.

IDENTIFYING YOUR LOCK CODE

To ensure you have the correct replacement key, it is crucial to identify the lock code associated with your vehicle's ignition or lock. The lock code determines the specific cut of your key.

Where to find your lock code:

- **On the original key:** The code is often stamped directly on the key blade or head.
- **On the lock face:** For some locks, the code may be engraved on the face of the lock cylinder itself.
- **On a label:** The code might be found on a label inside or behind the lock mechanism, or on a cabinet/door label associated with the lock.

Where to Find Your Lock Code




On the Key



On the Lock Face



On a Label Inside/
Behind the Lock



On the
Cabinet/Door Label



Important Notes

- Order by Manufacturer → Lock codes are manufacturer-specific.
- Key Cuts Differ → Even if codes look similar, they vary by brand.

Figure 1: Common locations for identifying your lock code.

Important Notes:

- **Manufacturer Specificity:** Lock codes are often manufacturer-specific. Always verify that the manufacturer of your vehicle matches the intended use of the key.
- **Key Cut Variations:** Even if lock codes appear similar, the actual key cuts can vary significantly

between different brands.

KEY USAGE

This replacement key functions identically to your original key.

1. Insert the key fully into the lock cylinder.
2. Turn the key to engage the lock mechanism (e.g., to start the ignition or unlock a compartment).
3. Remove the key after use.



Figure 2: Example of an EasyKeys replacement key.

If the key does not turn smoothly, do not force it. Refer to the Troubleshooting section.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	EasyKeys
Model Name	C51006
Compatible Manufacturers	Arctic Cat, Suzuki, Yamaha, Hyosung
Material	Brass
Lock Type	Cam
Item Dimensions (L x W x H)	0.5 x 0.5 x 1 inches
Item Weight	0.25 Pounds (approx. 4 ounces)
Special Features	Custom Cut Key, Durable

TROUBLESHOOTING

If you encounter issues with your replacement key, consider the following:

- **Key does not insert fully:** Ensure there are no obstructions in the lock cylinder. Check for debris or

damage.

- **Key inserts but does not turn:**

- Verify that the lock code on your key matches the code for your lock. A mismatch will prevent the key from turning.
- Ensure the key is fully inserted.
- Try gently wiggling the key while applying slight turning pressure. Do not force it.
- The lock mechanism might be stiff or corroded. A small amount of graphite lubricant (not oil) can sometimes help.

- **Key is stuck:** Gently try to pull and wiggle the key. If it remains stuck, avoid excessive force to prevent breaking the key inside the lock.

If problems persist after attempting these steps, contact customer support.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical assistance, please contact EasyKeys customer support directly.

You can typically find contact information on the EasyKeys official website or through the retailer where the product was purchased.

For more information about EasyKeys products, visit the [EasyKeys Store on Amazon](#).