## Minthouz 16000Pa Car Vacuum Cleaner

# Minthouz 16000Pa Cordless Handheld Car Vacuum Cleaner Instruction Manual

Model: 16000Pa Car Vacuum Cleaner

## 1. Introduction

Thank you for choosing the Minthouz 16000Pa Cordless Handheld Car Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new device. Please read it thoroughly before first use and retain it for future reference.

This compact and portable vacuum cleaner is designed for versatile cleaning tasks in your car, home, or office, offering both vacuuming and blowing functionalities. Its cordless design ensures maximum flexibility and convenience.





**Image 1.1:** The Minthouz cordless vacuum offers superior portability compared to corded alternatives, allowing for flexible cleaning anywhere.

## 2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not use the vacuum cleaner near flammable or combustible liquids, gases, or explosive dust.
- Do not vacuum hot ashes, burning cigarettes, or sharp objects.
- Keep the vacuum cleaner away from water and do not immerse it in liquids.
- Ensure the filter is properly installed before operation.
- Do not allow children to operate the vacuum cleaner without supervision.
- Use only the provided charging cable and a compatible power adapter (5V).
- If the device is damaged, do not attempt to repair it yourself. Contact customer support.
- Avoid blocking the suction inlet or exhaust port during operation.

## 3. Package Contents

Please check the package for the following items:

- Minthouz 16000Pa Cordless Handheld Car Vacuum Cleaner
- Telescopic Crevice Nozzle
- Wide-Mouth Brush
- Mouthpiece (for blowing/inflating)
- USB Type-C Charging Cable
- Storage Bag
- HEPA Filter (pre-installed)
- Spare HEPA Filter
- Instruction Manual




**Image 3.1:** Contents of the Minthouz 16000Pa Car Vacuum Cleaner package, including the main unit, various attachments, charging cable, and storage bag.

## 4. Product Overview

Familiarize yourself with the main components of your Minthouz vacuum cleaner:

1. **Main Unit:** Contains the motor, battery, and control buttons.
2. **Dust Collection Cup:** Transparent container for collected debris.
3. **HEPA Filter:** High-efficiency particulate air filter for fine dust.

4. **Metal Filter:** Protects the motor from larger debris.
5. **Power Button/Mode Selector:** Controls power and suction levels.
6. **LED Light:** Illuminates dark areas during cleaning.
7. **Charging Port (Type-C):** For recharging the internal battery.
8. **Suction/Blowing Port:** Where attachments are connected for vacuuming or blowing.

## 5. Setup

### 5.1. Charging the Device

Before first use, fully charge the vacuum cleaner. The built-in 7500mAh lithium-ion battery supports Type-C fast charging.

1. Connect the USB Type-C charging cable to the charging port on the vacuum cleaner.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included), car charger, computer, or power bank.
3. The charging indicator will show the charging status. A full charge typically takes 3.5 to 4.5 hours.
4. Once fully charged, disconnect the charging cable.




**Image 5.1:** The Minthouz vacuum features Type-C fast charging and includes multiple safety protections for the battery,

such as over-voltage, over-current, over-temperature, over-charge, short-circuit, and over-discharge protection.

### 5.2. Attaching Accessories

To attach an accessory, align it with the suction/blowing port and push firmly until it clicks into place. Ensure a secure fit to maintain optimal performance.

- **Telescopic Crevice Nozzle:** Ideal for narrow gaps, corners, and hard-to-reach areas.
- **Wide-Mouth Brush:** Suitable for larger surfaces, upholstery, and removing pet hair.
- **Mouthpiece:** Used for the blowing function, such as inflating small items or clearing dust from surfaces.

## 6. Operating Instructions

### 6.1. Power On/Off and Suction Modes

The vacuum cleaner features two suction levels:

1. Press the power button once to turn on the vacuum in**ECO Mode (10,000Pa)**. This mode is suitable for light dust and hair.
2. Press the power button a second time to switch to**MAX Mode (16,000Pa)**. This mode provides powerful suction for stubborn dirt, crumbs, and sand.
3. Press the power button a third time to turn off the vacuum cleaner.




**Image 6.1:** Demonstration of the Minthouz vacuum's powerful suction, showing its effectiveness in ECO mode for hair and dust, and MAX mode for crumbs and sand.

### 6.2. Using the LED Light

The integrated LED light enhances visibility in dimly lit areas, ensuring no dirt is missed.

- The LED light automatically activates when the vacuum cleaner is turned on.
- Direct the light towards the area you are cleaning for improved visibility.




**Image 6.2:** The bright LED light on the Minthouz vacuum illuminates dark spaces, helping to identify and clean hidden dirt and debris.

### 6.3. Multifunctional Use (Vacuuming, Blowing, Inflating)

The Minthouz vacuum cleaner offers versatile applications:

- **Vacuuming:** Attach the telescopic crevice nozzle or wide-mouth brush to the suction port for cleaning car interiors, sofas, pet hair, and other surfaces.
- **Blowing:** Attach the mouthpiece to the exhaust port (opposite the suction port) to use the device as an air blower. This is useful for removing dust from keyboards, computer components, or air conditioner vents.
- **Inflating:** The mouthpiece can also be used to inflate small items like swimming rings, air beds, or balloons.




**Image 6.3:** The Minthouz cordless vacuum is multifunctional, serving as an air blower for dust removal (e.g., computers, keyboards, air conditioners), a vacuum cleaner for various surfaces (e.g., car, sofa, pet hair), and an air pump for inflating items (e.g., air beds, lifebuoys, balloons).

## 7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### 7.1. Emptying the Dust Collection Cup

1. Ensure the vacuum cleaner is turned off.
2. Locate the release button on the dust collection cup.
3. Press the button to detach the dust cup from the main unit.
4. Empty the collected debris into a trash bin.

### 7.2. Cleaning the Filters

The vacuum cleaner is equipped with a dual filtration system: a metal filter and a HEPA filter. Both are washable.

1. After emptying the dust cup, rotate the dust collection cup to separate the HEPA filter and metal filter assembly.

2. Carefully remove both the HEPA filter and the metal filter.
3. Rinse the filters under running water until clean. Do not use harsh detergents.
4. Allow the filters to air dry completely for at least 24 hours before reassembling. Do not use the vacuum with wet filters.
5. Reassemble the filters and dust cup, ensuring they are securely in place.




**Image 7.1:** The 2-step cleaning process for the Minthouz vacuum involves easily emptying the dust cup and then detaching and washing the HEPA and metal filters under running water.

**Note:** A spare HEPA filter is included, allowing you to use the vacuum while one filter is drying.

## 8. Troubleshooting

If you encounter issues with your Minthouz vacuum cleaner, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Vacuum does not turn on. | Battery is depleted. | Charge the vacuum cleaner fully. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Low suction power. | Dust cup is full. | Empty the dust cup. |
| | Filters are clogged. | Clean or replace the filters. Ensure they are completely dry before reinstallation. |
| | Nozzle/hose is blocked. | Remove any obstructions from the nozzle or suction port. |
| Charging not working. | Charging cable or adapter is faulty. | Try a different USB Type-C cable and power adapter. |
| | Charging port is dirty. | Gently clean the charging port with a dry, soft brush. |

If the problem persists after trying these solutions, please contact Minthouz customer support for assistance.

## 9. Specifications

| Feature | Specification |
|---|---|
| Brand | Minthouz |
| Model | 16000Pa Car Vacuum Cleaner |
| Suction Power | 10,000Pa (ECO Mode), 16,000Pa (MAX Mode) |
| Battery Type | Lithium-Ion |
| Battery Capacity | 7500mAh |
| Charging Time | 3.5 - 4.5 hours (Type-C Fast Charging) |
| Operating Time | Up to 35 minutes |
| Filter Type | HEPA Filter, Metal Filter |
| Dust Cup Capacity | 150 Milliliters |
| Item Weight | 1.1 Pounds (approximately 500g) |
| Special Features | Compact, Cordless, Portable, LED Light, Blowing Function |
| Power Source | Battery Powered |
| Voltage | 5 Volts |

## 10. Warranty and Support

Minthouz is committed to providing high-quality products and excellent customer service. For any

questions, concerns, or warranty claims regarding your Minthouz 16000Pa Cordless Handheld Car Vacuum Cleaner, please contact our customer support team.
Please retain your proof of purchase for warranty purposes.