

[Manuals.plus](#) /

> [VEVOR](#) /

> VEVOR BH-015 30.5W x 21H Stainless Steel BBQ Access Door User Manual

VEVOR BH-015

VEVOR BH-015 30.5W x 21H Stainless Steel BBQ Access Door User Manual

1. PRODUCT OVERVIEW

The VEVOR BH-015 BBQ Access Door is a high-quality, durable stainless steel door designed for outdoor kitchens, BBQ islands, and grill stations. This double door unit, measuring 30.5 inches wide by 21 inches high, provides convenient access to your outdoor cooking area while maintaining a sleek and modern aesthetic. Its robust construction ensures resistance to rust and water, making it ideal for outdoor environments.



Image 1.1: The VEVOR BBQ Access Door seamlessly integrated into an outdoor grill island.

Key Features:

- **High-Quality Stainless Steel:** Constructed from robust, rust-proof, and waterproof stainless steel for long-lasting durability.
- **Thickened Frame Structure:** Integrated thickened frame (1.2mm) provides enhanced strength and stability.
- **U-shaped Panel Design:** Unique U-shaped panels offer improved resistance and durability.
- **Secure Magnetic Closure:** Equipped with strong magnets at the top and bottom to ensure the doors remain securely closed.
- **Ergonomic Handles:** Delicate zinc alloy handles are enlarged for comfortable and easy opening.
- **Safe Edges:** Door frame edges are folded and thickened to prevent sharp corners and ensure safer use.
- **Removable Panel Structure:** Features an L-shaped quick disassembly structure, allowing hinges to be removed for convenient replacement or maintenance.



Image 1.2: Highlights of the VEVOR BBQ Access Door, emphasizing material quality and secure closure.

UPGRADE HUMANIZED DESIGN




Image 1.3: Comparison illustrating the humanized design improvements of the VEVOR door, including safer edges, larger handles, and stronger magnets.

2. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in injury or damage to the product.

- Always wear appropriate personal protective equipment, such as gloves and eye protection, during installation.
- Be cautious of the edges of the door frame during handling and installation, even though they are folded and thickened for safety.
- Ensure the installation surface is stable and capable of supporting the weight of the door.
- Keep children and pets away from the installation area.
- Do not attempt to modify the product in any way, as this may compromise its structural integrity and void the warranty.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- 1 x VEVOR Stainless Steel Outdoor Kitchen Door (30.5W x 21H)
- 2 x Handles
- 4 x Screws
- 1 x Triangular Screwdriver
- 1 x Cleaning Cloth



Image 3.1: Overview of product dimensions and included accessories.

4. SETUP AND INSTALLATION

The VEVOR BBQ Access Door is designed for integrated installation into an outdoor kitchen or grill island. Follow these steps for a secure and precise setup.

Required Tools (Not Included):

- Drill
- Measuring Tape
- Level
- Pencil or Marker

Installation Steps:

1. **Prepare the Opening:** The recommended installation size for this door is 27 inches (689 mm) wide by 18 inches (448 mm) high. It is advised to reserve an additional 0.08 inches (2 mm) around these dimensions for optimal fit and operation. Ensure the opening is clean, level, and structurally sound.
2. **Use the Installation Template:** The external packaging includes a 1:1 perforated CAD installation drawing. Carefully cut out this template.
3. **Position the Template:** Place the template precisely over the desired installation location on your outdoor kitchen or grill island. Use a level to ensure it is perfectly straight.
4. **Mark and Drill:** Mark the drilling points according to the template. Using a drill, create the necessary holes for mounting the door frame.
5. **Insert the Door:** Carefully insert the BBQ access door into the prepared opening. Ensure it fits snugly and is level.
6. **Secure the Frame:** Use the provided screws to secure the door frame to the wall or structure. Tighten the screws firmly but do not overtighten.
7. **Attach Handles:** Attach the two handles to the door panels using the provided screws and triangular screwdriver. Ensure they are securely fastened.
8. **Test Operation:** Open and close the doors several times to ensure smooth operation and proper magnetic closure. Adjust if necessary.

5. OPERATING INSTRUCTIONS

Operating the VEVOR BBQ Access Door is straightforward.

- **Opening the Doors:** Grasp the ergonomic zinc alloy handles and pull gently to open the doors. The strong magnets will release, allowing the doors to swing open smoothly.
- **Closing the Doors:** Push the doors closed until the integrated magnets engage, holding them securely in place.
- **Accessing Storage:** The doors provide access to the interior of your outdoor kitchen or grill island, allowing for storage of grilling tools, propane tanks, or other accessories.



Image 5.1: The VEVOR BBQ Access Door with one panel open, demonstrating ease of access.

6. MAINTENANCE

Regular maintenance will ensure the longevity and appearance of your VEVOR BBQ Access Door.

- **Cleaning:** Wipe the stainless steel surfaces with a soft, damp cloth and mild detergent. For stubborn stains, use a stainless steel cleaner. Always wipe in the direction of the grain to prevent streaks. The door is waterproof and can be cleaned thoroughly without leaving marks.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the stainless steel finish.
- **Hinge Maintenance:** The L-shaped quick disassembly structure allows for easy removal of hinges if replacement or detailed cleaning is needed. Ensure hinges are free of debris for smooth operation.
- **Check Magnets:** Periodically check the magnets to ensure they are clean and free of obstructions, maintaining a secure closure.

DETACHABLE DOOR PANEL STRUCTURAL

L-shaped insert quick disassembly structure,
easy to replace



Image 6.1: The detachable door panel structure, highlighting the quick dismantling design for easy maintenance or replacement.

7. TROUBLESHOOTING

If you encounter any issues with your VEVOR BBQ Access Door, refer to the following common solutions:

- **Doors not closing securely:** Check if any debris is obstructing the magnets or the door frame. Clean the magnets and surrounding area. Ensure the door frame is not bent or misaligned.
- **Doors difficult to open/close:** Inspect the hinges for any obstructions or damage. Ensure all screws are properly tightened.
- **Scratches on surface:** Use the provided cleaning cloth or a specialized stainless steel scratch repair kit for minor scratches. For deeper scratches, professional repair may be required.
- **Rust spots:** Although made of rust-proof stainless steel, prolonged exposure to harsh conditions or certain chemicals can cause surface rust. Clean immediately with a stainless steel cleaner and ensure proper drying.

8. SPECIFICATIONS

Feature	Specification
Model Number	BH-015
Overall Dimensions (L x W x H)	30.5 x 21 x 2 inches (774 x 533 x 45 mm)
Installation Size (W x H)	27 x 18 inches (689 x 448 mm)
Material	Stainless Steel
Color	Silver
Item Weight	10.14 lbs (4.6 kg)
Assembly Required	No (Integrated Installation)
Smart Home Compatibility	Not smart home compatible
UPC	197988385363
Country of Origin	China

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the VEVOR official website or contact their customer service directly. Keep your purchase receipt for warranty claims.