

[Manuals.plus](#) /

> [CHOEZON](#) /

> CHOEZON MCW10WL 39.4" Wooden Storage Trunk Instruction Manual

CHOEZON MCW10WL

CHOEZON MCW10WL 39.4" Wooden Storage Trunk Instruction Manual

Model: MCW10WL | Brand: CHOEZON

INTRODUCTION

Thank you for choosing the CHOEZON MCW10WL 39.4" Wooden Storage Trunk. This manual provides detailed instructions for the assembly, operation, and maintenance of your new storage chest. Please read this manual thoroughly before assembly and use to ensure safe and efficient operation.

IMPORTANT SAFETY INFORMATION

Caution: Ensure fingers are clear when closing the lid to prevent pinching. The safety hinge is designed to prevent sudden closure, but caution should always be exercised.

Always place the storage chest on a flat, stable surface. Do not overload the chest. The top surface supports up to 220 lbs (100 kg).

PRODUCT FEATURES

- **Generous Storage Capacity:** Dimensions of 39.4"L x 15.7"W x 19"H provide ample space for blankets, pillows, toys, and other daily items.
- **Sturdy Construction & Safety Hinge:** Crafted with premium engineered wood boards and metal fittings, supporting up to 220 lbs on its top. Features a safety hinge and U-shaped cutout to prevent finger pinching.
- **Versatile Usage:** Functions as a storage chest, living room organizer, or entryway shoe bench.
- **Farmhouse Style & Aesthetic:** Framed front design with a bi-color rustic charm (Walnut + White) that complements modern minimalist or country-style decor.
- **Effortless Setup & Mobility:** Designed with large panels for simplified assembly. Includes side handles for easy relocation.

ASSEMBLY INSTRUCTIONS

The CHOEZON MCW10WL storage trunk is designed for straightforward assembly. All necessary tools and hardware are typically included in the package. Follow the step-by-step instructions provided in the included manual.

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the parts list are present.
2. **Prepare Workspace:** Assemble the unit on a soft, clean surface to prevent scratches.
3. **Follow Manual:** Refer to the detailed diagrams and instructions in the provided assembly manual. Each piece is typically labeled for easy identification.
4. **Secure Connections:** Ensure all screws and fasteners are tightened securely, but do not overtighten.
5. **Install Safety Hinge:** Pay close attention to the installation of the safety hinge to ensure proper function and prevent accidental lid closure.

Estimated assembly time: Approximately 25-30 minutes.



Image: The fully assembled CHOEZON MCW10WL storage trunk in a home setting.



Image: Close-up of the safety hinge, designed to prevent the lid from slamming shut.

OPERATION AND USAGE

The CHOEZON MCW10WL storage trunk offers versatile functionality for various household needs.

- **Opening the Lid:** Gently lift the lid using the U-shaped cutout. The safety hinge will hold the lid open at various

angles, preventing it from falling unexpectedly.

- **Closing the Lid:** Apply gentle downward pressure on the lid. The safety hinge will allow it to close slowly and smoothly, minimizing the risk of finger pinching.
- **Storage:** Utilize the spacious interior for organizing items such as blankets, cushions, toys, books, or seasonal clothing.
- **Seating:** The sturdy top surface can serve as additional seating, supporting up to 220 lbs (100 kg). Ensure the lid is fully closed before using it as a bench.
- **Mobility:** Use the integrated side handles to easily move the storage chest when needed.

Secure Flip Top

Stays at any angle for your use.




Image: Illustration of the secure flip-top and dimensions of the storage trunk.




Image: The storage trunk used as a sturdy bench, supporting a person.

Your browser does not support the video tag.

Video: Official product video demonstrating the CHOEZON Storage Chest, 39.4" Toy Chest Storage. This video highlights the product's features and functionality.

CARE AND MAINTENANCE

- **Cleaning:** Wipe with a dry cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners, which may damage the finish.
- **Spills:** Promptly wipe up any spills with a soft, dry cloth to prevent staining or water damage.
- **Placement:** Avoid placing the chest in direct sunlight or near heat sources to prevent warping or fading.
- **Regular Checks:** Periodically check all fasteners and tighten if necessary to maintain stability.

PRODUCT SPECIFICATIONS

Product Dimensions	15.7"D x 39.4"W x 19"H
Color	Walnut + White
Material	Engineered Wood
Frame Material	Engineered Wood
Item Weight	35.5 pounds
Weight Capacity (Top)	220 lbs (100 kg)
Model Number	MCW10WL
Brand	CHOEZON

TROUBLESHOOTING

- **Lid not closing smoothly:** Check the safety hinges for proper alignment and ensure no obstructions are present. Re-tighten screws if necessary.
- **Wobbling/Instability:** Verify that all assembly screws are securely tightened. Ensure the chest is placed on a level surface.
- **Missing Parts:** If any parts are missing upon arrival, please contact customer support for assistance.

WARRANTY AND SUPPORT

For any questions, concerns, or warranty claims regarding your CHOEZON MCW10WL Storage Trunk, please refer to the contact information provided with your purchase or visit the official CHOEZON website for customer support details. Please retain your proof of purchase for any warranty-related inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question