QCY AilyBuds PRO+

QCY AilyBuds PRO+ Wireless Earbuds User Manual

Model: AilyBuds PRO+

1. What's in the Box

The QCY AilyBuds PRO+ package includes all necessary components to get started with your new wireless earbuds.

- 1 Pair of Wireless Earbuds (QCY AilyBuds PRO+)
- 1 Charging Station/Case
- 1 Type-C Charging Cable
- 1 User Manual (this document)



Image: The QCY AilyBuds PRO+ earbuds resting in their open charging case.

Your browser does not support the video tag.

Video: An official guide demonstrating the contents of the QCY AilyBuds PRO+ package and initial setup steps.

2. Setup

2.1 Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged. Connect the provided Type-C cable to the charging port on the case and a compatible USB power source. The earbuds will charge automatically when placed inside the case.

- Earbuds offer approximately 5 hours of listening time on a single charge (ANC off).
- The charging case extends total listening time to about 28 hours (ANC off).



Image: The earbuds and charging case illustrating their long battery life with and without Active Noise Cancellation.

2.2 Initial Pairing

1. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "QCY AilyBuds Pro+" in the list of available Bluetooth devices.
4. Select "QCY AilyBuds Pro+" to connect. A confirmation sound will indicate successful pairing.




Image: The earbuds and charging case displayed alongside a smartphone and tablet, highlighting the multipoint connection feature.

3. Operating the Earbuds

3.1 Wearing the Earbuds

Ensure proper fit for optimal sound quality and noise cancellation. The earbuds are designed with a 50-degree semi-in-ear angle for comfort and stability.

- Identify the left (L) and right (R) earbuds.
- Gently insert each earbud into the corresponding ear canal.
- Adjust the earbud so the microphone is pointed towards your mouth for clear calls.



Image: A person wearing one of the QCY AilyBuds PRO+ earbuds, demonstrating its comfortable semi-in-ear design.

3.2 Touch Controls

The QCY AilyBuds PRO+ feature intuitive touch controls on the earbud panels.

Action	Control
Play/Pause Music, Answer/End Call	Double touch either earbud
Next Track	Triple touch right earbud
Activate Voice Assistant	Triple touch left earbud
Reject Call / Power On	Long press for 1.5 seconds
Adaptive Audio / ANC ON/OFF	Long press right earbud (Adaptive Audio can only be disabled in the QCY App)

Action	Control
Low Latency ON/OFF (Gaming Mode)	Long press left earbud



Image: A visual guide detailing the touch control functions of the QCY AilyBuds PRO+ earbuds.

3.3 Active Noise Cancellation (ANC) and Adaptive Audio

The earbuds feature Adaptive ANC, which intelligently recognizes ambient sounds and adjusts noise cancellation. Long press the right earbud to toggle ANC. Adaptive Audio can be managed via the QCY App.



Image: A visual representation of how Adaptive Active Noise Cancellation works with the QCY AilyBuds PRO+ earbuds, showing noise reduction.

3.4 QCY App Features

Enhance your experience by downloading the QCY App. The app allows for extensive customization and access to advanced features:

- **Personalized EQ:** Adjust sound effects to your preference.
- **Noise Canceling Switch:** Manually control ANC modes.
- **Button Customization:** Reassign touch control functions.
- **Wind Noise Canceling:** Optimize for windy environments.
- **Gaming Mode:** Reduce audio latency for gaming (68ms).
- **Sleep Mode:** Specific audio settings for sleep.
- **Find Earbuds:** Locate misplaced earbuds.
- **Firmware Update:** Keep your earbuds updated with the latest features and improvements.



Image: Screenshots of the QCY App interface, demonstrating various customization and control options for the earbuds.

4. Maintenance

To ensure the longevity and optimal performance of your QCY AilyBuds PRO+ earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Moisture:** While the earbuds are IPX5 waterproof (resistant to splashes and sweat), avoid submerging them in water. Ensure they are dry before placing them back in the charging case.
- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) as this can affect battery life and overall performance.

5. Troubleshooting

If you encounter issues with your QCY AilyBuds PRO+, refer to the following common troubleshooting steps:

- **Earbuds not pairing/connecting:**
  - Ensure Bluetooth is enabled on your device and the earbuds are in pairing mode (open case lid).
  - Check if the earbuds and case have sufficient battery.
  - Try turning Bluetooth off and on again on your device.
  - Perform a "One-Touch Pairing": Place earbuds in the case, open the lid, and long-press the charging case button for 3 seconds until LEDs blink red once. Then try pairing again.
- **No sound or low volume:**
  - Check the volume levels on both your device and the earbuds.
  - Ensure the earbuds are properly seated in your ears.
  - Verify that the earbuds are connected to the correct device.
  - Clean any debris from the earbud speakers.
- **Active Noise Cancellation (ANC) not effective:**
  - Ensure the earbuds are worn correctly and create a good seal in your ear canal. Use the QCY App's "wearing effect" test to check fit.
  - Toggle ANC off and on again by long-pressing the right earbud.
  - Ensure the earbud firmware is updated via the QCY App.
- **Earbuds not charging:**
  - Ensure the charging cable is securely connected to both the case and the power source.
  - Check if the charging contacts on the earbuds and inside the case are clean and free of debris.
  - Try a different charging cable or power adapter.
- **Factory Reset:** If issues persist, a factory reset can resolve many problems.
  - Place both earbuds back into the charging case and keep the lid open.
  - Long-press the charging case button for 10 seconds until the LEDs blink red 5 times. This will clear all connectivity records.
  - After the reset, re-pair the earbuds with your device as described in section 2.2.

6. Specifications

Detailed technical specifications for the QCY AilyBuds PRO+ Wireless Earbuds:

Feature	Detail
Model Name	AilyBuds Pro+
Connectivity Technology	Wireless (Bluetooth 5.3)
Noise Control	Active Noise Cancellation (Adaptive ANC)
Audio Codec Support	LDAC, Hi-Res Audio Wireless
Microphones	6 built-in mics for clear calls

Feature	Detail
Battery Life (Earbuds)	Up to 5 hours (ANC off)
Battery Life (with Charging Case)	Up to 28 hours (ANC off)
Charging Time	Approx. 5 hours (full charge for case)
Water Resistance Level	IPX5 (Waterproof)
Control Type	Touch, App Control
Multipoint Connection	Yes, connect to 2 devices simultaneously
Audio Driver Size	13 Millimeters Dynamic Driver
Frequency Range	20 Hz - 40 kHz
Audio Latency	68 Milliseconds (Gaming Mode)
Earbud Weight	Approx. 4 Grams (each)
Charging Case Dimensions	51 x 51 x 28.2 mm
Charging Case Weight	134 Grams
Material	Plastic

7. Warranty and Support

QCY products are manufactured to high quality standards. For warranty information, technical support, or service inquiries, please refer to the official QCY website or contact their customer support directly. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, visit the official QCY Store on Amazon:QCY Amazon Store

© 2024 QCY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question