

- Manuals.plus /
- › KLARSTEIN /
- › KLARSTEIN Bahama Breeze 178 cm Silent Ceiling Fan User Manual Model 1004600

KLARSTEIN 1004600

KLARSTEIN Bahama Breeze 178 cm Silent Ceiling Fan User Manual

Model: 1004600

Installation

Operation

Safety Instructions
Maintenance

Components
Troubleshooting

Setup &
Specifications

Warranty & Support

INTRODUCTION

Thank you for choosing the KLARSTEIN Bahama Breeze Silent Ceiling Fan. This manual provides important information regarding the safe installation, operation, and maintenance of your new ceiling fan. Please read it thoroughly before use and keep it for future reference.

The KLARSTEIN Bahama Breeze ceiling fan, with its 178 cm span, is designed to provide optimal air circulation for rooms up to 35 m². It features a silent DC motor, six adjustable speeds, smart control via remote, voice, or app, and versatile summer/winter modes for year-round comfort.



Image Description: A full view of the KLARSTEIN Bahama Breeze 178 cm Silent Ceiling Fan with its wooden blades, mounted on a ceiling. This image provides an overall visual of the product.

Potente



El gran diámetro de 178 cm garantiza una temperatura ambiente agradable




Image Description: A diagram showing a room layout with the fan's coverage area. Text indicates 'Powerful' and 'The large diameter of 178 cm ensures a pleasant ambient temperature' for 'Up to 35 m².' This image demonstrates the fan's effective coverage for larger rooms.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions carefully before installation and operation.
- Ensure the power supply is disconnected before installation, cleaning, or maintenance.
- Installation must be performed by a qualified electrician in accordance with local electrical codes, or by a competent individual who strictly adheres to these instructions.
- The mounting structure must be capable of supporting the fan's weight (7 kg) plus dynamic load.
- Maintain a minimum clearance of 2.3 meters (7.5 feet) from the floor to the fan blades.
- Do not insert objects into the path of the rotating blades.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

PACKAGE CONTENTS & COMPONENTS

Before beginning installation, verify that all components are present and undamaged. Refer to the diagram below for identification.



Image Description: An overhead view of the KLARSTEIN Bahama Breeze ceiling fan, highlighting its wooden blades and central motor housing. Text overlays indicate 'High-quality ceiling fan with solid wood blades,' 'Smart control,' '6 wind speeds,' 'Timer function,' 'Silent operation,' and 'Two rotation directions.' This image illustrates the main features and aesthetic of the fan.

- Ceiling Fan Motor Unit
- Wooden Blades (3 pieces)

- Downrods (15 cm and 25 cm options)
- Mounting Bracket
- Remote Control
- Hardware Kit (screws, washers, wire nuts)
- User Manual

SETUP & INSTALLATION

This section details the steps for installing your KLARSTEIN Bahama Breeze ceiling fan. It is recommended that two people perform the installation for safety and ease.

1. Pre-Installation Checks

1. **Power Disconnection:** Ensure the main power supply to the installation area is turned off at the circuit breaker.
2. **Mounting Location:** Select a location where the fan blades will have at least 2.3 meters (7.5 feet) clearance from the floor and 30 cm (12 inches) from any walls or obstructions. The ceiling joist or support structure must be able to hold at least 7 kg.
3. **Dimensions:** Consider the fan's diameter of 178 cm.



Image Description: A diagram illustrating the dimensions of the KLARSTEIN Bahama Breeze ceiling fan. It shows a total diameter of 178 cm, a downrod length of 15 cm, and a total drop from the ceiling of 28 cm or 40 cm depending on the chosen downrod. This helps in planning the installation space.

2. Mounting the Bracket

1. Secure the mounting bracket to the ceiling outlet box or support structure using the provided screws and washers. Ensure it is firmly attached and can support the fan's weight.

3. Assembling the Fan

1. Attach the chosen downrod (15 cm or 25 cm) to the motor housing.
2. Carefully attach the wooden blades to the motor housing using the blade screws. Ensure all screws are tightened securely.

4. Wiring the Fan

1. Hang the fan assembly onto the mounting bracket.

2. Connect the electrical wires according to the wiring diagram in the full manual (typically black to black, white to white, and green/bare copper to ground). Use the provided wire nuts.
3. Tuck all wires neatly into the outlet box.

5. Securing the Canopy

1. Slide the canopy up to the ceiling and secure it to the mounting bracket with the canopy screws.

Following these instructions carefully can allow for installation within approximately one hour. Always prioritize safety and ensure all connections are secure.

OPERATION

Your KLARSTEIN Bahama Breeze ceiling fan offers multiple control options for convenience and comfort.

1. Remote Control Operation

The included remote control allows for easy adjustment of fan settings. Ensure batteries (not included) are correctly inserted into the remote.

- **Power Button:** Turns the fan ON/OFF.
- **Speed Control:** Adjusts between 6 fan speeds.
- **Timer Function:** Sets the fan to turn off after 1, 3, or 8 hours.
- **Summer/Winter Mode:** Toggles the blade rotation direction.

Ajuste individual & potente



6 velocidades
de viento



Función
de temporizador
de hasta 8 h



Caudal de aire máx.
12.300 m³/h



KLARSTEIN

Image Description: A close-up view of the fan blades with text indicating 'Individual & powerful adjustment.' It highlights '6 wind speeds,' 'Timer function up to 8 h,' and 'Max air flow 12,300 m³/h.' This image emphasizes the fan's performance capabilities.

2. Smart Control (App & Voice)

The fan supports IoT connectivity, allowing control via a smartphone app and voice assistants like Amazon Alexa and Google Home.

- **App Control:** Download the Klarstein Smart app from the App Store or Google Play. Follow the in-app instructions to pair your fan with your device and home network. The app provides full control over power, speed, timer, and modes.
- **Voice Control:** Once paired with the app, link your Klarstein account to your Amazon Alexa or Google Home account. You can then use voice commands to control the fan (e.g., "Alexa, turn on the ceiling fan," "Hey Google, set fan speed to 3").

Funcionamiento sencillo y cómodo



Control completo a través de la aplicación Klarstein y compatible con Amazon Alexa y Google Home




Image Description: A smartphone screen displaying the Klarstein Smart app interface for controlling the fan. The app shows current temperature, fan speed settings (Low, Medium, High), schedule, and countdown timer. The image also shows logos for App Store and Google Play, indicating where to download the app.

3. Summer/Winter Mode


The fan features a reversible motor for year-round comfort.

- **Summer Mode (Counter-clockwise rotation):** Blades rotate counter-clockwise, pushing cool air downwards to create a refreshing breeze.
- **Winter Mode (Clockwise rotation):** Blades rotate clockwise, drawing warm air up towards the ceiling and distributing it evenly throughout the room, helping to reduce heating costs.

Dos direcciones de giro


KLARSTEIN

En verano, el ventilador sopla el aire frío hacia abajo



En invierno, el aire caliente fluye hacia el suelo




Image Description: A diagram illustrating the two rotation directions of the ceiling fan. On the left, 'Summer mode' shows the fan blowing air downwards (blue arrows). On the right, 'Winter mode' shows the fan drawing air upwards, circulating warm air (orange arrows). This visually explains the function of the reversible motor.

The fan operates with a silent DC motor, ensuring quiet performance, ideal for bedrooms and living areas. Its noise level is approximately 47 dB, comparable to a quiet library (40 dB) and significantly quieter than a normal conversation (60 dB).



Funcionamiento silencioso

El silencioso motor de DC con núcleo inteligente de rodamientos de bolas garantiza una perfecta circulación del aire sin ruidos molestos

Image Description: A top-down view of the fan blades with a sound icon and text indicating 'Silent operation.' It compares the fan's noise level (47 dB) to a library (40 dB) and conversation (60 dB), emphasizing its quiet performance due to the DC motor and ball bearing core.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing regularly with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Tightness:** Periodically check that all blade screws are tight. Over time, they may loosen due to fan vibration.
- **Electrical Connections:** Annually, have a qualified electrician check all electrical connections for tightness and wear.
- **Lubrication:** The fan's DC motor is permanently lubricated and does not require additional oiling.

Always disconnect power before performing any cleaning or maintenance.

TROUBLESHOOTING

If you experience issues with your fan, consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Ensure all wires are securely connected; Replace remote control batteries.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) if necessary; Ensure mounting bracket is secure.
No response from remote/app	Remote battery low; Fan not paired; Wi-Fi connectivity issues.	Replace remote batteries; Re-pair fan with remote/app; Check Wi-Fi router and fan's connection.
Fan makes unusual noise	Loose screws; Obstruction in fan path; Motor issue.	Check and tighten all screws; Ensure no objects are near blades; If noise persists, contact customer support.

TECHNICAL SPECIFICATIONS

Feature	Detail
Model Number	1004600
Brand	KLARSTEIN
Dimensions (Diameter x Height)	178 cm x 38 cm (with shortest downrod)
Weight	7 kg
Power Source	DC power supply
Number of Speeds	6
Airflow Capacity	Up to 12,300 m³/h
Recommended Room Size	Up to 35 m²
Special Features	Remote control, App control, Voice control, Timer function, Summer/Winter mode, Silent DC motor
Mounting Type	Ceiling mount
Color	Walnut (Nogal)
Country of Origin	China

WARRANTY & SUPPORT

KLARSTEIN products are covered by a manufacturer's warranty. For specific warranty details and duration, please refer to the warranty card included with your product or visit the official KLARSTEIN website.

For technical support, spare parts, or any questions regarding your product, please contact KLARSTEIN customer

service. Contact information can typically be found on the official brand website or in the packaging materials.

Online Support: www.klarstein.es/support (Please note: This is an example link. Refer to your product documentation for the most accurate support information.)

© 2024 KLARSTEIN. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question