

[Manuals.plus](#) /

> [Yclty](#) /

> Yclty Outdoor Wood Garden Bench (120cm, Without Backrest) Instruction Manual

Yclty 120cm Without Backrest

Yclty Outdoor Wood Garden Bench (120cm, Without Backrest) Instruction Manual

Model: 120cm Without Backrest | Brand: Yclty

INTRODUCTION

Thank you for choosing the Yclty Outdoor Wood Garden Bench. This manual provides essential information for the safe assembly, operation, and maintenance of your new bench. Please read these instructions thoroughly before assembly and retain them for future reference.

SAFETY INFORMATION

- Ensure all components are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Assemble the bench on a soft, clean surface to prevent scratches.
- Tighten all bolts and screws securely, but do not overtighten to avoid stripping threads or damaging components.
- Regularly inspect the bench for loose fasteners or signs of wear. Tighten as needed.
- Do not exceed the maximum weight capacity of 800 lbs (approximately 363 kg).
- Keep children away from the assembly area and small parts.

PACKAGE CONTENTS

Verify that all the following components are included in your package:

- 1 x Garden Bench (Slatted Wood Seat)
- 2 x Cast Iron Legs
- 1 x Installation Kit (includes bolts, washers, nuts, and assembly tool)



Image: Underside view of the bench, illustrating the connection points for the legs and the slatted wood construction.

SETUP AND ASSEMBLY

Follow these steps to assemble your Yclty Outdoor Wood Garden Bench:

- 1. Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, flat surface to prevent damage.
- 2. Attach Legs to Seat:** Align one cast iron leg with the pre-drilled holes on one end of the wooden seat. Insert the provided bolts through the holes and secure them with washers and nuts. Hand-tighten initially. Repeat for the second leg on the opposite end of the seat.
- 3. Secure All Fasteners:** Once both legs are in place, use the included assembly tool to fully tighten all bolts and nuts. Ensure

all connections are firm and stable.

4. **Final Inspection:** Gently shake the assembled bench to confirm stability. If any wobbling occurs, re-check all fasteners and tighten as necessary.

Strong Load-Bearing



Aluminum Feet



Antiseptic Wood

Image: Detail of the cast iron legs and wood slats, highlighting the robust construction.

OPERATING INSTRUCTIONS

Your Yclty Outdoor Wood Garden Bench is designed for comfortable outdoor seating. Place the bench on a flat, stable surface in

your desired location, such as a patio, garden, or yard. The slatted design allows for proper drainage, making it suitable for various weather conditions.



Image: The assembled Yclty Outdoor Wood Garden Bench in an outdoor environment.

MAINTENANCE

Proper maintenance will extend the life and appearance of your garden bench:

- **Cleaning:** The waterproof surface of the wood slats can be easily cleaned with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all bolts and nuts for tightness. Re-tighten if any looseness is detected.
- **Wood Care:** While the wood is treated for outdoor use, applying a wood sealant or stain annually can further protect it from weathering and maintain its appearance.
- **Storage:** During extreme weather conditions or prolonged periods of non-use, consider covering the bench or storing it in a sheltered area to maximize its lifespan.



HIGH-QUALITY ANTI-CORROSION AND MOISTURE-PROOF SOLID WOOD MATERIAL



Image: Detail of the solid wood slats, emphasizing their quality and finish.

TROUBLESHOOTING

If you encounter any issues with your bench, refer to the following common solutions:

- **Bench is Wobbly:** Ensure all assembly bolts are fully tightened. Check that the bench is placed on a level surface.
- **Wood Discoloration:** Exposure to sun and rain can cause natural wood to change color over time. Regular application of a wood sealant can help mitigate this.
- **Rust on Cast Iron:** While the cast iron is painted for protection, prolonged exposure to moisture can lead to rust. Clean any rust spots with a wire brush and apply a rust-inhibiting paint.

SPECIFICATIONS

Model	120cm Without Backrest
--------------	------------------------

Brand	Yclty
Material	Solid Wood, Cast Iron
Overall Dimensions (L x W x H)	120 cm x 42 cm x 40 cm (47.2 in x 16.5 in x 15.7 in)
Weight Capacity	800 lbs (approx. 363 kg)
Item Weight	39.7 lbs (approx. 18 kg)
Assembly Required	Yes



Image: Dimensional diagram of the bench, indicating length, width, and height.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer's policy or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

