

[Manuals.plus](#) /

› [Leitmotiv](#) /

› Leitmotiv Alma Cone Table Lamp LM2168BR User Manual

Leitmotiv LM2168BR

Leitmotiv Alma Cone Table Lamp LM2168BR User Manual

Model: LM2168BR

1. INTRODUCTION

Thank you for choosing the Leitmotiv Alma Cone Table Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before installation and retain them for future reference.



Figure 1: The Leitmotiv Alma Cone Table Lamp, featuring a distinctive caramel brown ceramic base and a complementary light-colored fabric lampshade. The design emphasizes unique materials and focused lighting.

2. SAFETY INSTRUCTIONS

- Always disconnect the lamp from the power supply before cleaning or replacing the bulb.
- Do not use bulbs with a wattage exceeding the maximum specified on the lamp holder.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Keep the lamp away from water and moisture. This lamp is intended for indoor use only.
- Do not attempt to modify or repair the lamp yourself. Contact qualified personnel for service.
- Keep the power cord away from heat sources and sharp edges.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged:

- 1 x Alma Cone Table Lamp Base (Caramel Brown Ceramic)

- 1 x Cylindrical Lampshade (Light-colored fabric)
- 1 x Power Cord with Integrated On/Off Switch

Note: Light bulb is typically not included and must be purchased separately. Refer to the lamp holder for the correct bulb type and maximum wattage.

4. SETUP

The Leitmotiv Alma Cone Table Lamp requires no assembly. Follow these steps for initial setup:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Placement:** Choose a suitable, stable location for the lamp, ensuring it is away from direct sunlight, heat sources, and moisture.
3. **Bulb Installation:** If a bulb is not pre-installed, gently screw the appropriate light bulb (not included) into the lamp holder. Ensure the bulb type and wattage comply with the lamp's specifications.
4. **Connect to Power:** Insert the power plug into a standard electrical outlet.



Figure 2: The Alma Cone Table Lamp positioned on a wooden surface, demonstrating its integration into a living space. This image highlights suitable placement for optimal lighting and aesthetic appeal.

5. OPERATING INSTRUCTIONS

To operate the lamp:

- **Turning On:** Locate the integrated on/off switch on the power cord. Press the switch to the 'ON' position to illuminate the lamp.
- **Turning Off:** Press the switch to the 'OFF' position to turn off the lamp.



Figure 3: A detailed view of the inline rotary switch located on the lamp's power cord. This switch controls the power to the lamp, allowing for easy on and off operation.

6. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your lamp.

- **Cleaning:** Disconnect the lamp from the power supply before cleaning. Wipe the ceramic base with a soft, dry cloth. For the lampshade, use a lint-free cloth or a soft brush to remove dust. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down completely. Unscrew the old bulb and replace it with a new one of the correct type and wattage.




Figure 4: A close-up image revealing the subtle texture and weave of the light-colored fabric lampshade. This detail is important for understanding cleaning requirements and maintaining the lamp's aesthetic.

7. TROUBLESHOOTING

If your lamp is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power to the outlet.	Check if the outlet is working by plugging in another device. Check circuit breaker.
Lamp does not turn on.	Bulb is loose or burnt out.	Ensure the bulb is screwed in tightly. Replace the bulb if it is burnt out.
Lamp does not turn on.	Switch is in the 'OFF' position.	Ensure the inline switch is pressed to the 'ON' position.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Leitmotiv
Model Number	LM2168BR
Product Dimensions (L x W x H)	23 x 23 x 32.5 cm (9.06 x 9.06 x 12.8 inches)
Item Weight	1.1 Kilograms (2.43 lbs)
Material	Ceramic
Special Feature	Unique materials and focused lighting
Assembly Required	No

9. WARRANTY AND SUPPORT

Information regarding specific warranty terms for the Leitmotiv Alma Cone Table Lamp LM2168BR is not provided in this manual. For warranty details, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly.

For technical support or further assistance, please reach out to the seller or Leitmotiv customer service through their official channels.