

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BUFF](#) /

› [BUFF Handheld Vacuum Cordless BF01 User Manual](#)

## BUFF BF01

# BUFF Handheld Cordless Vacuum Cleaner BF01 User Manual

Model: BF01

## INTRODUCTION

---

This manual provides instructions for the safe and efficient use of your BUFF Handheld Cordless Vacuum Cleaner, Model BF01. Please read this manual thoroughly before operating the device and retain it for future reference.

## SAFETY INFORMATION

---

Observe the following safety precautions to prevent injury or damage to the device:

- Do not immerse the vacuum cleaner in water or other liquids.
- Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Ensure the vacuum is fully charged before first use.
- Use only the provided charging cable.
- Do not operate the vacuum without the dust bin and filter properly installed.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:

- BUFF Handheld Cordless Vacuum Cleaner (BF01)
- Crevice Tool
- Brush Attachment
- Flex-Tube Hose
- Filter Cleaning Brush
- Spare Filter
- USB-C Charging Cable
- Storage Bag
- User Manual (this document)



**Figure 1:** BUFF Handheld Cordless Vacuum Cleaner and its accessories, including the crevice tool, brush, flex-tube hose, filters, and charging cable.

## PRODUCT OVERVIEW

Familiarize yourself with the components of your vacuum cleaner.

1. Power Button
2. LED Flashlight Button
3. Dust Bin Release Latch
4. Dust Bin
5. Filter Assembly
6. Charging Port (USB-C)
7. Battery Level Indicator Lights

## SETUP

### 1. Charging the Vacuum

1. Connect the USB-C charging cable to the charging port on the vacuum cleaner.
2. Plug the other end of the USB-C cable into a compatible USB power adapter (not included).
3. The battery level indicator lights will illuminate to show charging status. A full charge takes approximately 3.5 hours.
4. Disconnect the charger once fully charged.




**Figure 2:** Connecting the USB-C charging cable to the vacuum cleaner. The battery indicator lights show charging progress.

## 2. Attaching Accessories

The vacuum comes with various attachments for different cleaning tasks.

- **Crevice Tool:** Ideal for narrow gaps and hard-to-reach areas. Insert the crevice tool firmly into the vacuum's nozzle.
- **Brush Attachment:** Suitable for upholstery, carpets, and delicate surfaces. Attach the brush tool to the crevice tool or directly to the vacuum nozzle.
- **Flex-Tube Hose:** Provides extended reach and flexibility. Connect one end to the vacuum nozzle and the desired attachment to the other end.



## INCLUDED:

FLEX-TUBE HOSE

BRUSH TOOL

CREVICE TOOL

**Included attachments are  
perfect for any cleaning need.**

Figure 3: The included flex-tube hose, brush tool, and crevice tool for versatile cleaning.

## OPERATING THE VACUUM

### 1. Powering On/Off

- Press the Power Button once to turn the vacuum cleaner on.
- Press the Power Button again to turn the vacuum cleaner off.



Figure 4: The vacuum cleaner effectively removing dirt from a surface.

## 2. Using Attachments

- Select the appropriate attachment for your cleaning task.
- Attach it firmly to the vacuum nozzle or flex-tube hose.
- For example, use the crevice tool for tight spaces in a car interior.



**Crevice tool makes for easy  
cleaning in hard-to-reach spaces.**

**Figure 5:** The crevice tool is effective for cleaning debris from narrow spaces, such as between sofa cushions.

LIGHTWEIGHT AND ERGONOMIC



Handheld portability that's perfect to tidy up your car.

Figure 6: The compact design allows for easy cleaning of vehicle interiors.

### 3. Using the LED Flashlight

- Press the LED Flashlight Button to turn the light on.
- Use the flashlight to illuminate dark areas, such as under furniture or in car footwells, to ensure thorough cleaning.
- Press the LED Flashlight Button again to turn the light off.




Figure 7: The integrated LED flashlight helps to identify and clean debris in dimly lit environments.

## MAINTENANCE

### 1. Emptying the Dust Bin

1. Ensure the vacuum is turned off.
2. Press the Dust Bin Release Latch to detach the dust bin from the main unit.
3. Carefully empty the contents of the dust bin into a waste receptacle.
4. Reattach the dust bin until it clicks securely into place.

### 2. Cleaning the Filter

Regular filter cleaning maintains optimal suction performance.

1. After emptying the dust bin, remove the filter assembly.
2. Use the provided filter cleaning brush to gently remove dust and debris from the filter.
3. For a more thorough clean, the filter can be rinsed under running water. Ensure the filter is completely dry before reinserting it into the vacuum.
4. Replace the filter assembly and reattach the dust bin.

### 3. Cleaning Attachments and Main Unit

- Wipe the exterior of the vacuum cleaner and attachments with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Ensure all parts are dry before storage or next use.

### 4. Storage

Store the vacuum cleaner and its accessories in the provided storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum cleaner fully.
Low suction power.	Dust bin is full or filter is clogged.	Empty the dust bin and clean the filter. Ensure the filter is dry before reinserting.
Attachments do not fit securely.	Incorrect attachment or not fully inserted.	Ensure the correct attachment is used and pushed firmly onto the nozzle or hose.
LED flashlight not working.	Flashlight button not pressed or battery low.	Press the flashlight button. If still not working, charge the vacuum.

## SPECIFICATIONS


<b>Model Name</b>	BF01
<b>Brand</b>	BUFF
<b>Power Source</b>	Battery Powered (Cordless)
<b>Battery Voltage</b>	11.1V
<b>Battery Energy</b>	22.2Wh
<b>Charging Time</b>	Approximately 3.5 hours
<b>Run Time</b>	Up to 20 minutes
<b>Dust Bin Capacity</b>	350 ml
<b>Filter Type</b>	High-Efficiency
<b>Noise Level</b>	75 dB
<b>Product Dimensions</b>	13.58"L x 3.81"W x 4.25"H
<b>Item Weight</b>	1.57 pounds
<b>Certifications</b>	cETL approved





### [Model 515 Flow Computer Operation Manual](#)

This operation manual provides detailed information on the Contrec Model 515 Flow Computer, including its features, specifications, installation, operation, and maintenance. It covers batch/flow control for frequency flowmeters and application BF01.



### [Reid Buff 2-Piece Sectional with Right Arm Facing Corner Chaise Assembly Instructions](#)

Assembly instructions for the Living Spaces Reid Buff 2-Piece Sectional with Right Arm Facing Corner Chaise (Model 313431), detailing parts and step-by-step assembly.



### [FANMU Music Player BF01 User Manual](#)

Comprehensive user manual for the FANMU Music Player BF01, detailing features, operation instructions, system settings, specifications, and service policy. Includes information on playback modes, recording, e-book reading, radio, Bluetooth, and charging.



### [Shutterbug Expert Photo Techniques Guide 2015](#)

Explore expert photography techniques with the Shutterbug Expert Photo Techniques Guide 2015. This comprehensive resource offers practical advice, tips, and tutorials from leading photographers on lighting, composition, capturing specific subjects like wildlife and waterfalls, and mastering digital workflows.



### [Celestial 500WS Flash Unit: What's in the Box and How It Works](#)

An overview of the 500WS Celestial Flash Unit, detailing its package contents, control scheme, screen layout, and FCC compliance information.