

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FOCHEW](#) /

› [FOCHEW 13800mAh Portable Charger with Built-in Cables and Wall Plug \(Model HX100M9\) - Instruction Manual](#)

FOCHEW HX100M9

FOCHEW 13800mAh Portable Charger with Built-in Cables and Wall Plug

Model: HX100M9 | Brand: FOCHEW

1. INTRODUCTION

Thank you for choosing the FOCHEW 13800mAh Portable Charger. This device is designed to provide convenient and efficient power on the go for a wide range of electronic devices. Featuring built-in charging cables and a foldable AC wall plug, it eliminates the need for carrying multiple accessories, making it an ideal travel companion.

2. SAFETY INFORMATION

- Do not expose the power bank to extreme temperatures (heat or cold), direct sunlight, or fire.
- Avoid dropping, disassembling, or attempting to repair the device yourself.
- Keep away from water and high humidity.
- Do not use if the device is damaged or swollen.
- Keep out of reach of children.
- Dispose of the power bank responsibly according to local regulations.

3. PRODUCT OVERVIEW

The FOCHEW Portable Charger is an all-in-one solution for your charging needs. It integrates essential charging components into a compact design.

3.1 Key Features

- **Built-in Cables:** Includes a Type-C cable and a cable for iPhone, ensuring compatibility with most modern smartphones.
- **Foldable AC Wall Plug:** Allows direct recharging of the power bank from any standard wall outlet

without external adapters.

- **Multiple Outputs:** Features 2 built-in cable outputs, 1 Type-C input/output port, and 1 USB-A output port, supporting simultaneous charging of up to 4 devices.
- **Digital LED Display:** Shows the remaining battery percentage for easy monitoring.
- **Compact and Lightweight:** Designed for portability, making it suitable for travel and daily use.

3.2 Package Contents

- FOCHEW 13800mAh Portable Charger x1
- User Manual x1

3.3 Product Diagram



Figure 1: Overview of the 5-in-1 Portable Charger with all ports and cables labeled.

Slim Size and Light Weight Design



Weight: 220g



Figure 2: The portable charger's slim design and compact dimensions.

4. SETUP AND INITIAL CHARGING

Before first use, fully charge your FOCHEW Portable Charger.

1. **Using the Built-in Wall Plug:** Fold out the integrated AC wall plug from the side of the power bank. Plug the power bank directly into a standard wall outlet. The LED display will show the charging progress.
2. **Using the USB-C Port:** Alternatively, connect a USB-C cable (not included) to the power bank's Type-C input/output port and then to a compatible USB wall adapter (not included).

The LED display will blink while charging and show '100' when fully charged. A full charge typically takes approximately 3 hours via USB-C port or 5 hours via wall plug.

All in One Portable Charger

13800mAh Power Bank
with AC Wall Plug and Cables



Foldable AC
Wall Plug



Other Cable
for iPhone



USB-C Charging
Cable



USB-A Output



USB-C
Input/Output



LCD Display



Figure 3: Recharging options for the power bank.

5. OPERATING INSTRUCTIONS

The FOCHEW Portable Charger offers multiple ways to charge your devices.

5.1 Charging Devices

1. **Using Built-in Cables:** Pull out the appropriate built-in cable (Type-C or for iPhone) and connect it to your device. The power bank will automatically begin charging.
2. **Using USB-A Output Port:** Connect your device's USB-A charging cable (not included) to the USB-A output port on the power bank.
3. **Using USB-C Input/Output Port:** Connect your device's USB-C charging cable (not included) to the Type-C port on the power bank. This port supports 15W PD fast charging.

The LED display will show the remaining battery percentage of the power bank during charging. You can charge up to 4 devices simultaneously.

Charging 4 Devices Simultaneously



Figure 4: Charging multiple devices simultaneously.

5.2 Compatibility

This portable charger is widely compatible with a variety of devices:

- **For iPhones/iPad Series:** Compatible with iPhone 17/17 Pro/17 Pro Max/Air/16/16 Plus/16 Pro/16 Pro Max/15/15 Plus/15 Pro/15 Pro Max/14/14 Plus/14 Pro/14 Pro Max, iPhone 13/13 Pro/13 Pro Max/12/12 Pro/12 Pro Max, iPhone 11/XR/XS Max/8/8 Plus/7/7Plus/6/6s/6Plus, iPad Air, iPad Pro, Apple AirPods Pro/AirPods.
- **For Samsung/Android:** Compatible with Galaxy S25/S24/S22/S23/S21 Series, Google Pixel, LG, Moto, tablets, and other Android devices.

Strong Compatibility

For iPhones/iPad Series



iPhone 15/15 Plus/15 Pro/15 Pro Max
/ 14/13/12/11/X/SE/8 Plus



iPad Air 9.7"/10.5"/10.9"/
iPad Pro 10.5"/10.9"



Apple AirPods Pro/
AirPods...

For Samsung/Android



Samsung S22/S21/S20/S10/S9/
Z Fold2/Note20/Note10



Googole Pixel P5/
P4/P4a/P3/P3XL



LG G6/G7/
V30/V40



Other USB-C
Devices



Figure 5: Wide device compatibility.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use liquid cleaners or aerosols.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the power bank at least once every three months, even if not in regular use.

7. TROUBLESHOOTING

- **Power bank not charging:** Ensure the wall plug is fully inserted into a live outlet or the USB-C cable is properly connected to a power source. Check if the outlet is functional.
- **Device not charging from power bank:** Ensure the power bank has sufficient charge. Verify that the charging cable is securely connected to both the power bank and your device. Try a different cable or port.

- **Slow charging:** Ensure your device and cable support fast charging if expecting high speeds. Charging multiple devices simultaneously may reduce individual charging speeds.
- **LED display not working:** If the power bank is charging or discharging, the display should be active. If it remains off, try recharging the power bank. If the issue persists, contact customer support.

8. SPECIFICATIONS

Model Number	HX100M9
Battery Capacity	13800mAh
Input (Wall Plug)	AC 100-240V, 50/60Hz
Input (USB-C)	15W PD (Power Delivery)
Output (Built-in Type-C Cable)	3.0A High-Speed Charging
Output (Built-in for iPhone Cable)	Standard Charging
Output (USB-A Port)	Standard Charging
Output (USB-C Port)	15W PD (Power Delivery)
Dimensions	5.9 x 2.7 x 0.7 inches
Weight	9.6 ounces (220g)

9. WARRANTY AND SUPPORT

Your FOCHEW Portable Charger comes with a worry-free **24-month warranty** and **lifetime technical support**. If you encounter any issues or have questions, please contact our friendly customer service team for assistance.

For customer service, please refer to the contact information provided on the product packaging or our official website.