Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- efperfect /
- efperfect Modern 3 Lights Glass Pendant Light EF1408736001 Instruction Manual

efperfect EF1408736001

efperfect Modern 3 Lights Glass Pendant Light Instruction Manual

Model: EF1408736001 Brand: efperfect

Introduction

Thank you for purchasing the efperfect Modern 3 Lights Glass Pendant Light, model EF1408736001. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.

This pendant light features three distinct smoky gray glass lampshades, designed to enhance various indoor spaces with a blend of modern and vintage aesthetics.



Figure 1: The efperfect Modern 3 Lights Glass Pendant Light, showcasing its design in a bright room.



Figure 2: The pendant light enhancing a dining room setting.



Figure 3: The pendant light providing illumination in a bedroom.

SAFETY INFORMATION

- **WARNING:** To avoid electric shock, always disconnect power at the main circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Ensure the fixture is securely mounted to a structural component of the ceiling.
- Do not exceed the maximum wattage specified for the bulbs.
- Handle glass components with care to prevent breakage.
- This fixture is designed for indoor use only.

PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- · Ceiling Canopy with integrated wiring
- 3 Glass Lampshades (various shapes and sizes)
- Mounting Hardware (crossbar, mounting screws, wire connectors)
- Adjustable Hanging Wires (pre-attached to canopy and lamp holders)
- Instruction Manual

Note: E26 light bulbs are not included and must be purchased separately.

SPECIFICATIONS

Feature	Detail
Brand	efperfect
Model Number	EF1408736001
Color	Smoke Gray (Shades), Black (Canopy)
Material	Glass, Metal
Style	Modern, Vintage
Light Fixture Form	Pendant
Product Dimensions	12"L x 12"W x 45"H (Adjustable height)
Voltage	110-120 Volts (AC)
Bulb Base	E26
Number of Light Sources	3
Max Wattage per Bulb	60W
Dimmable	Yes (with compatible dimmable bulbs and dimmer switch, not included)
Installation Type	Semi Flush Mount (Ceiling Mount)
Shade Material	Glass
Item Weight	9.43 pounds

SETUP AND INSTALLATION

Professional installation is recommended. Ensure power is OFF at the circuit breaker before proceeding.

1. Prepare for Installation

- 1. Turn off electricity at the main fuse box or circuit breaker.
- 2. Carefully unpack all components and inspect for any damage.
- 3. Gather necessary tools (screwdriver, wire strippers, electrical tape, ladder).

2. Mount the Crossbar

Attach the mounting crossbar to the junction box in your ceiling using the provided screws. Ensure it is



Figure 4: Installation diagram illustrating the mounting process and electrical connections.

3. Wire Connections

- 1. Connect the fixture's ground wire (usually bare copper or green) to the house ground wire.
- 2. Connect the fixture's neutral wire (usually white) to the house neutral wire (white).
- 3. Connect the fixture's live wire (usually black) to the house live wire (black).
- 4. Secure all connections with wire connectors and wrap with electrical tape for added safety.



Figure 5: Detailed view of the ceiling canopy and wiring points before final installation.

4. Secure the Ceiling Canopy

Carefully tuck all wires into the junction box. Align the ceiling canopy with the mounting screws on the crossbar and secure it with the provided decorative nuts or screws.

5. Adjust Hanging Wires

The hanging wires for each glass globe are adjustable. To adjust the length, gently push the small pin on the canopy where the wire enters, then pull or push the wire to the desired length. Release the pin to lock the wire in place. Ensure the wires are taut and the globes hang evenly or as desired.




Figure 6: The three distinct glass shades with adjustable hanging wires, allowing for customized arrangement.

6. Install Light Bulbs

Screw E26 base bulbs (not included) into each lamp holder. Ensure bulbs are fully seated. The fixture supports incandescent, LED, CFL, and halogen bulbs up to 60W each. For dimming functionality, use dimmable E26 bulbs and a compatible dimmer switch (not included).



Figure 7: Detail of an E26 bulb correctly installed within a glass shade.

7. Attach Glass Shades

Carefully attach each glass lampshade to its respective lamp holder according to the design. Ensure they are securely fastened but do not overtighten.



Figure 8: The efperfect pendant light installed, demonstrating its aesthetic appeal in a living space.

OPERATING INSTRUCTIONS

- Turning On/Off: Once installed and power is restored, operate the light fixture using your wall switch.
- **Dimming Functionality:** If you have installed dimmable E26 bulbs and a compatible dimmer switch, you can adjust the light intensity by using the dimmer switch.



Figure 9: Visual representation of the dimmable feature and potential light color temperatures when using compatible bulbs.

MAINTENANCE

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture and glass shades with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **Bulb Replacement:** Ensure power is off. Allow bulbs to cool completely before attempting to replace them. Unscrew the old bulb and screw in a new E26 bulb of the appropriate wattage (max 60W).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Power is off at the circuit breaker.Loose wire connection.Faulty bulb.	 Check the circuit breaker and ensure power is on. Verify all wire connections are secure (with power off). Replace the bulb with a new one.

Light flickers.	 Loose bulb. Incompatible dimmer switch or bulb. Loose wire connection. 	 Tighten the bulb. Ensure dimmable bulbs are used with a compatible dimmer. Check wire connections (with power off).
Glass shade is loose.	Shade not properly secured.	Gently tighten the shade onto the lamp holder. Do not overtighten.

WARRANTY INFORMATION

efperfect offers a 60-day return service for any damaged or defective product. Additionally, free replacement is provided for any non-working or broken part within five years of purchase. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your efperfect Modern 3 Lights Glass Pendant Light, please contact our customer support team. We aim to respond to inquiries within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official efperfect store online.

Thank you for choosing efperfect.

Related Documents - EF1408736001



EFPERFECT DS-SQ57 Pendant Light Installation Guide

Comprehensive installation guide for the EFPERFECT DS-SQ57 contemporary 5-light pendant light, detailing mounting steps, electrical connections, and essential maintenance precautions for 110V systems.



EFPERFECT DS-DY123 Modern Ceramic Chandelier Installation Instructions

Detailed installation guide for the EFPERFECT DS-DY123 modern ceramic petal design chandelier. Includes safety precautions, step-by-step assembly, and technical specifications for professional installation.



EFPERFECT DS-DR67 Tiffany Style Pendant Light Installation Instructions

Step-by-step installation guide for the EFPERFECT DS-DR67 Tiffany Style Pendant Stained Glass Ceiling Light. Includes component list and assembly instructions.



EFPERFECT DS-DR61 Tiffany Style Pendant Light Installation Instructions

Step-by-step installation guide for the EFPERFECT DS-DR61 Tiffany Style Stained Glass Pendant Light. Includes component identification and assembly procedures.



EFPERFECT DS-DR60 Tiffany Style Pendant Light Installation Instructions

Detailed installation guide for the EFPERFECT DS-DR60 Tiffany Style Pendant Stained Glass Lamp Shade Ceiling Light Chandelier Fixture, including step-by-step instructions and component identification.



EFPERFECT Chandelier Installation Guide and Diagram | SKU DS-SZ42-1408458001

Detailed product installation diagram and step-by-step instructions for the EFPERFECT DS-SZ42-1408458001 chandelier, including precautions and a parts list.