

W&P WP-BUN-SKSET16-CM

W&P Sustainable Kitchen Set 14-Piece Instruction Manual

Model: WP-BUN-SKSET16-CM

1. INTRODUCTION

This instruction manual provides essential information for the proper use and care of your W&P Sustainable Kitchen Set. This 14-piece set is an all-in-one food storage system designed to reduce single-use plastic in your kitchen. It includes a variety of containers and wraps crafted from premium, food-grade silicone and durable borosilicate glass.

2. PRODUCT OVERVIEW: WHAT'S INCLUDED

Your W&P Sustainable Kitchen Set includes the following 14 pieces:

- 2 Seal Tight Glass Bowls (16 oz, 24 oz)
- 3 Reusable Silicone Bags (10 oz, 34 oz, 46 oz)
- 6 Reusable Stretch Lids (2.5", 3.8", 4.5", 5.7", 6.5", 8")
- 3 Reusable Stretch Wraps (7x8", 10x11", 13x14")

Clean up your kitchen with the Sustainable Kitchen Set! Whether you're getting organized, meal prepping or storing leftovers, this all-in-one food storage set includes the reusable, 100% non-toxic solutions you need to replace harmful single-use plastics at home. That's better for you, and the planet.

What's Inside:



Scan to see how we're transforming kitchens for a healthier future



Better For You & The Planet



Created by W&P
New York, NY 10003
wandp.com

WP-BUN-SKSET16-CM



MADE IN CHINA

Figure 2.1: Contents of the 14-Piece Sustainable Kitchen Set. This diagram illustrates the various components and their sizes.

For more information about W&P products, visit their official website: wandp.com. The UPC for this product is 810074419222.

3. SETUP & FIRST USE

Before initial use, wash all components of the W&P Sustainable Kitchen Set with warm, soapy water or place them in the dishwasher. Ensure all items are thoroughly dry before storing or using them with food.

4. OPERATING INSTRUCTIONS

4.1. Seal Tight Glass Bowls

The glass bowls are designed for storing various food items. To seal, place the silicone lid firmly over the rim of the bowl, ensuring a snug fit. The flexible silicone creates an airtight seal to keep food fresh.

4.2. Reusable Silicone Bags

These silicone bags are ideal for snacks, fruits, cereals, and other small food items. To use, open the bag by pulling apart the top seal. Fill with desired contents and press the seal firmly together to create an airtight closure. The transparent front allows for easy visibility of contents.

4.3. Reusable Stretch Lids

The stretch lids are versatile covers for bowls and containers of various shapes and sizes. Select a lid size slightly smaller than the container for optimal stretch and seal. Stretch the lid over the container, ensuring the edges are securely wrapped around the rim to create an airtight barrier.

Your browser does not support the video tag.

Video 4.3.1: Demonstration of W&P Reusable Stretch Lids. This video illustrates how to apply and use the stretch lids on various containers to create a secure seal.

4.4. Reusable Stretch Wraps

These wraps are designed to replace single-use plastic wrap. Stretch the wrap over cut fruits, vegetables, or small dishes, pressing down to create a tight seal. The grippy silicone material adheres to itself and smooth surfaces, providing an effective cover.



Figure 4.4.1: The W&P Sustainable Kitchen Set in action, showcasing silicone bags and stretch wraps preserving food items.

5. CARE & MAINTENANCE

All components of the W&P Sustainable Kitchen Set are designed for easy cleaning and long-term use.

- **Dishwasher Safe:** All items are dishwasher safe. Place them on the top rack for best results.
- **Microwave Safe:** The glass bowls, silicone bags, lids, and wraps are microwave safe. Use caution when heating, as contents may be hot.
- **Freezer Safe:** All components are freezer safe, making them suitable for long-term food storage.
- **Hand Washing:** For hand washing, use warm water and mild dish soap. Rinse thoroughly and allow to air dry completely before storing to prevent moisture buildup.
- **Avoid Sharp Objects:** To prevent damage to the silicone components, avoid using sharp utensils or abrasive cleaners.

Your browser does not support the video tag.

Video 5.1.1: W&P Cup Cubes Freezer Molds. This video demonstrates the use of W&P freezer-safe containers for organizing frozen foods,

highlighting their stackable design and clear visibility.

6. TROUBLESHOOTING

- **Lid not sealing properly:** Ensure the rim of the bowl or container is clean and dry. Stretch the lid evenly over the entire rim.
- **Silicone bags difficult to open/close:** Ensure the sealing edges are clean and free from food debris. A small amount of cooking oil can be applied to the edges if needed for smoother operation.
- **Stains or odors:** For stubborn stains or odors, soak silicone items in a mixture of white vinegar and water for a few hours, then wash as usual.

7. SPECIFICATIONS

Feature	Specification
Product Dimensions	11.1"L x 4.8"W x 13.35"H
Recommended Uses	Food storage, snacks, meal prep
Special Feature	Dishwasher Safe, Microwave Safe, Freezer Safe, Non-Toxic, Reusable
Closure Type	Snap (for bags), Stretch (for lids/wraps)
Item Package Quantity	1
Item Volume	90 Fluid Ounces (total capacity)
Unit Count	14.0 Count
Item Form	Seal Tight Bowl, Silicone Bag, Stretch Lid, Stretch Wrap
Manufacturer	W&P
Number of Items	14
Set Name	14-Piece Sustainable Kitchen Set
Material	Silicone, Borosilicate Glass
Color	Cream



Figure 7.1: The W&P Sustainable Kitchen Set provides versatile storage solutions for your kitchen.

8. WARRANTY & SUPPORT

For any questions regarding your W&P Sustainable Kitchen Set, please contact the manufacturer directly. Specific warranty information may be available on the product packaging or the official W&P website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question