

Manuals.plus /

- › Ronson /
- › Ronson Comet Turbo Gas Lighter RL13001Silver User Manual

Ronson RL13001Silver

Ronson Comet Turbo Gas Lighter User Manual

Model: RL13001Silver

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Ronson Comet Turbo Gas Lighter, model RL13001Silver. Please read this manual thoroughly before operating the device and retain it for future reference. This modern lighter features a turbo 'windproof' flame, designed for reliable ignition.





The Ronson Comet Turbo Gas Lighter features a sleek design with a silver top and a red body, accented by a black grip. The Ronson logo is visible on the side.

SAFETY INFORMATION

- **WARNING:** Keep out of reach of children. This product contains flammable gas under pressure.
- Do not expose to heat above 120°F (49°C) or prolonged sunlight.
- Do not puncture or incinerate the lighter.

- Ensure the lighter is completely extinguished before storing.
- Use only in well-ventilated areas, away from open flames or ignition sources.
- Avoid contact with skin and eyes during fueling procedures.
- Do not attempt to disassemble or repair the lighter yourself. Refer to qualified personnel.

SETUP

Unpacking

Carefully remove the Ronson Comet Turbo Gas Lighter from its packaging. Inspect the lighter for any visible damage. Retain the packaging for future reference or transport.

Fueling Instructions

The Ronson Comet Turbo Gas Lighter uses Liquefied Petroleum Gas (butane) as fuel. For optimal performance and safety, use high-quality butane fuel.

1. **Prepare for Refueling:** Ensure the lighter is completely cool and extinguished. Work in a well-ventilated area, away from open flames, sparks, or other ignition sources.
2. **Invert the Lighter:** Turn the lighter upside down to expose the fuel refill valve, which is typically located at the base.
3. **Insert Butane Nozzle:** Firmly press the nozzle of a high-quality butane gas canister into the refill valve. Hold for approximately 5-10 seconds. You may hear a slight hiss as the gas transfers.
4. **Check Fuel Level:** If your lighter has a visible fuel window, observe the fuel level. Do not overfill. Stop when the fuel level is adequate or when gas begins to escape from the valve.
5. **Allow to Stabilize:** After refueling, wait a few minutes (e.g., 2-3 minutes) for the gas to stabilize and reach room temperature before attempting to ignite the lighter. This helps prevent irregular flames.

OPERATING INSTRUCTIONS

Ignition

1. **Prepare for Ignition:** Ensure the lighter is adequately fueled and has stabilized after refueling.
2. **Press the Ignition Button:** Locate the ignition button or lever, typically on the side of the lighter. Press it down firmly to activate the turbo flame.
3. **Release to Extinguish:** Release the ignition button to extinguish the flame. Ensure the flame is fully out before placing the lighter down or storing it.

Flame Adjustment

The Ronson Comet Turbo Gas Lighter allows for flame height adjustment to suit various needs.

1. **Locate Adjustment Valve:** The flame adjustment valve is usually located on the bottom of the

lighter. It may be a small screw slot.

2. **Adjust Flame Height:** Use a small flat-head screwdriver or a suitable tool to turn the adjustment screw.

- Turn clockwise (towards '-') to decrease the flame height.
- Turn counter-clockwise (towards '+') to increase the flame height.

• **Test and Refine:** Adjust gradually and test the flame after each adjustment until the desired height is achieved. Avoid setting the flame too high, as this can consume fuel quickly and pose a safety risk.

MAINTENANCE

Cleaning

- Periodically clean the lighter's exterior with a soft, dry cloth to remove dust and fingerprints.
- Ensure the burner nozzle is free from debris. If necessary, use a small, soft brush or a puff of compressed air to clear any obstructions, taking care not to damage the nozzle.

Refueling

Refer to the Fueling Instructions section for detailed steps on how to refill your lighter with butane gas.

Storage

- Store the lighter in a cool, dry place, away from direct sunlight, extreme temperatures, and heat sources.
- If storing for an extended period or when traveling by air, it is recommended to empty the lighter of fuel.

TROUBLESHOOTING

Problem	Solution
Lighter does not ignite	Check fuel level and refill if necessary. Ensure the ignition mechanism is clean and free of debris.
Flame is weak or inconsistent	Refill with high-quality butane. Adjust flame height using the adjustment screw. Purge any air from the fuel tank by pressing the refill valve with a small tool until no more gas escapes, then refuel.
Gas leaks during refueling	Ensure the butane canister nozzle is properly aligned and pressed firmly into the refill valve. Use a butane canister with the correct adapter if multiple are provided.
Lighter produces a large, uncontrolled flame	Immediately extinguish the flame. Adjust the flame height screw clockwise to decrease the flame. Ensure the lighter is not overfilled.

SPECIFICATIONS

Feature	Detail
Brand	Ronson
Model Number	RL13001Silver
Color	Silver
Style	Modern
Fuel Type	Liquefied Petroleum Gas (Butane)
Product Dimensions	2.76"L x 0.79"W x 0.79"Th
Number of Items	1
Manufacturer	Ronson
ASIN	B0D17S5VVR
Date First Available	April 9, 2024

WARRANTY AND SUPPORT

For specific warranty information and customer support inquiries regarding your Ronson Comet Turbo Gas Lighter, please refer to the product packaging or contact Ronson customer service directly through their official website or contact channels.