

[Manuals.plus](#) /

› [Leitmotiv](#) /

› Present Time Leitmotiv Rabbit LED Table Lamp User Manual

Leitmotiv 17103

Present Time Leitmotiv Rabbit LED Table Lamp User Manual

Model: 17103

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Present Time Leitmotiv Rabbit LED Table Lamp, Model 17103. This decorative LED lamp is designed for indoor use and is suitable for various settings, including children's rooms. Please read this manual thoroughly before operating the lamp and retain it for future reference.

2. SAFETY INSTRUCTIONS

- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not expose the lamp to water or excessive moisture. This product is for indoor use only.
- Keep the lamp away from direct heat sources, open flames, and flammable materials.
- Do not attempt to disassemble or modify the lamp. There are no user-serviceable parts inside.
- Use only the provided power cable. If the cable is damaged, discontinue use immediately and contact customer support.
- Unplug the lamp from the power outlet before cleaning or when not in use for extended periods.
- This lamp is not a toy. Keep out of reach of small children unless supervised by an adult.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Present Time Leitmotiv Rabbit LED Table Lamp (1 unit)
- Power Cable (integrated or separate, for electrical connection)



Image 1: Front view of the Rabbit LED Table Lamp. The lamp features a pink rabbit-shaped base with a mushroom-like shade, and a power button is visible on the rabbit's chest.

4. SETUP

1. **Unpack the Lamp:** Carefully remove the lamp and all components from the packaging.
2. **Placement:** Choose a suitable indoor location for the lamp. Ensure it is on a stable, level surface and away from

edges where it could fall.

3. **Connect Power:** Insert the power cable plug into a standard electrical outlet.



Image 2: The Rabbit LED Table Lamp illuminated and placed on a wooden shelf, demonstrating a typical setup in a room environment.

5. OPERATING INSTRUCTIONS

1. **Power On/Off:** Locate the power button on the front of the rabbit's body. Press the button once to turn the lamp on. Press it again to turn the lamp off.
2. **Light Source:** The lamp utilizes an integrated LED light source, providing efficient and long-lasting illumination.



Image 3: A detailed view showing the warm glow of the LED light emanating from beneath the lamp's shade.

6. MAINTENANCE AND CARE

- **Cleaning:** To clean the lamp, first unplug it from the power outlet. Use a soft, dry, or slightly damp cloth to wipe the surface. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the plastic material.
- **LED Light Source:** The LED light source is integrated and not designed for user replacement. If the LED light fails, please contact customer support.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	◦ Power cable not properly connected. ◦ Power outlet is not functioning. ◦ Internal fault.	◦ Ensure the power cable is securely plugged into both the lamp and the wall outlet. ◦ Test the outlet with another device. ◦ Contact customer support if the issue persists.
Light is flickering.	◦ Unstable power supply. ◦ Internal component issue.	◦ Try plugging the lamp into a different power outlet. ◦ Contact customer support.

8. SPECIFICATIONS

- **Brand:** Leitmotiv
- **Manufacturer:** Present Time
- **Model Number:** 17103
- **Product Dimensions (L x W x H):** 17 x 22 x 27 cm
- **Item Weight:** 200 g
- **Material:** Plastic
- **Light Source Type:** LED
- **Number of Light Sources:** 1
- **Power Source:** Electric Cable
- **Wattage:** 3.0 W
- **ASIN:** B0D1816614

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer where the product was purchased or contact the manufacturer directly. Please retain your proof of purchase for any warranty claims.

- **Spare Parts Availability:** Information regarding the availability of spare parts is not provided.
- **Software Updates:** This product does not require software updates.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question