

## sweeek ICCSOFACRVVKAK

# sweeek Ida Reversible Corner Sofa Bed - Instruction Manual

Model: ICCSOFACRVVKAK

## 1. INTRODUCTION

This manual provides essential instructions for the assembly, operation, maintenance, and troubleshooting of your sweeek Ida Reversible Corner Sofa Bed. Please read this manual thoroughly before assembly and use to ensure safe and correct operation. Keep this manual for future reference.

**Important Safety Information:** All materials used could pose a fire risk if exposed to high heat sources. Professional cleaning methods are recommended to ensure user safety.

## 2. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. Refer to the parts list provided in the packaging for a complete inventory.



Image 1: Overview of the sweeek Ida Reversible Corner Sofa Bed. This image displays the sofa bed in its standard configuration, featuring a corner chaise lounge and three seating cushions, all upholstered in kaki corduroy fabric.

### 3. SETUP AND ASSEMBLY

---

Assembly is required for this product. It is recommended to have at least two people for assembly. Ensure you have adequate space and all tools specified in the assembly guide (usually included in the packaging).

#### 3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Place all parts on a soft, clean surface to prevent scratches.
3. Verify all parts against the included parts list.

#### 3.2 Assembly Steps

Follow the step-by-step instructions provided in the separate assembly manual. Key steps typically include:

- Attaching legs to the sofa frame.
- Connecting the main sofa section to the chaise lounge section.
- Placing cushions and pillows.




Image 2: Dimensional diagram of the sofa bed. This illustration provides key measurements including total length (219 cm), height (68 cm), depth (84 cm), seat depth (68 cm), and chaise length (132.5 cm), useful for planning placement.

#### 3.3 Reversible Chaise Configuration

The chaise lounge section is reversible, allowing it to be positioned on either the left or right side of the main sofa. Consult the assembly manual for specific instructions on how to reconfigure the chaise.



Image 3: Depiction of the sofa bed's reversible chaise feature. This image shows two configurations, demonstrating how the chaise can be moved to either the left or right side of the sofa to suit room layout preferences.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Sofa to Bed Conversion

To convert the sofa into a bed:

1. Remove any loose cushions or pillows from the sofa.
2. Locate the pull-out mechanism beneath the main seating area.
3. Gently pull the mechanism forward and lift to extend the bed platform.
4. Ensure the bed platform is fully extended and stable before use.




Image 4: The sofa bed in the process of converting from a sofa to a bed. This image illustrates the pull-out mechanism being extended from beneath the main seating area, revealing the bed platform.

## 4.2 Bed to Sofa Conversion

To convert the bed back into a sofa:

1. Lift the extended bed platform slightly.
2. Push the platform back into the sofa frame until it locks securely.
3. Replace cushions and pillows.





Image 5: The sweeek Ida Sofa Bed fully extended into its bed configuration. This view shows the complete sleeping surface, ready for use.

### 4.3 Storage Compartment

The chaise lounge section includes a storage compartment. To access it, lift the top of the chaise. Ensure the lid is securely closed before sitting or placing items on it.



Image 6: The storage compartment located within the chaise lounge section of the sofa bed. The image shows the top of the chaise lifted, revealing the interior storage space.

## 5. MAINTENANCE AND CARE

---

Proper maintenance ensures the longevity and appearance of your sofa bed.

### 5.1 Cleaning the Fabric

- **Regular Cleaning:** Vacuum the fabric regularly using an upholstery attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain.
- **Deep Cleaning:** Professional cleaning methods are recommended for thorough cleaning to ensure safety and preserve the fabric. Avoid harsh chemicals or abrasive cleaners.



Image 7: A detailed close-up of the kaki corduroy fabric upholstery. This image highlights the texture and color of the material, which requires specific care.

## 5.2 Frame and Mechanism Care

- Periodically check all bolts and screws to ensure they are tight. Retighten as necessary.
- Ensure the sofa bed mechanism operates smoothly. If it becomes stiff, a small amount of silicone-based lubricant can be applied to moving parts (avoiding fabric).
- Avoid exposing the sofa bed to direct sunlight or extreme temperatures, which can damage the fabric and frame.





Image 8: Close-up details of various sofa bed components. This composite image shows the sofa feet, the wheels on the pull-out bed mechanism, a zipper detail on a cushion, and the interior of the storage compartment, illustrating key areas for maintenance checks.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Sofa bed mechanism is stiff or difficult to operate.	Lack of lubrication; obstruction; misaligned parts.	Check for obstructions. Apply a small amount of silicone-based lubricant to moving metal parts. Ensure all assembly bolts are tight.
Squeaking noises during operation.	Loose connections; friction between metal parts.	Tighten all visible bolts and screws. Lubricate moving parts as described above.



Problem	Possible Cause	Solution
Fabric appears stained or dirty.	Accumulated dirt; spills.	Refer to the "Cleaning the Fabric" section (5.1). For persistent stains, consider professional cleaning.

## 7. SPECIFICATIONS

Feature	Detail
Brand	sweeek
Model	ICCSOFACRVVKAK
Type	Convertible Corner Sofa Bed
Upholstery Fabric	Corduroy
Color	Kaki
Dimensions (L x W x H)	219 cm x 84 cm x 68 cm
Seat Depth	68 cm
Weight	71 kg
Maximum Load Capacity	110 kg
Assembly Required	Yes

## 8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official sweeek website. Keep your proof of purchase for any warranty claims.

**Contact Information:** For further assistance, please contact sweeek customer service through their official channels. You can often find contact details on the brand's website or through your retailer.

*Note: This manual is for informational purposes only. The manufacturer reserves the right to make changes to the product without prior notice.*



