

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ONN](#) /

> [ONN 10.1" Tablet Pro User Manual](#)

### ONN ONN 10.1" Tablet Pro (Model: 796575180925)

# ONN 10.1" Tablet Pro User Manual

MODEL: 796575180925

## INTRODUCTION

---

This manual provides essential information for the setup, operation, and maintenance of your ONN 10.1" Tablet Pro. Designed for versatility and performance, this tablet features a 10.1-inch FHD display, a 2GHz Octa-Core Processor, 3GB RAM, and 32GB of internal storage, running on Android 10. Please read this manual thoroughly to ensure proper use and to maximize your tablet's capabilities.



Image: The ONN 10.1" Tablet Pro, showcasing its vibrant Full HD display and user interface.

## WHAT'S IN THE BOX

---

Verify that all items are present upon unboxing:

- 1 x ONN 10.1" Tablet Pro
- 1 x USB Charging Cable
- 1 x Power Adapter
- Quick Start Guide (if included)

## SETUP

---

### 1. Charging the Tablet

Before first use, fully charge your tablet. Connect the USB charging cable to the tablet's charging port and the other end to the power adapter. Plug the adapter into a wall outlet. The battery indicator on the screen will show charging status.

### 2. Powering On/Off

- **To Power On:** Press and hold the Power button (usually located on the side or top edge) for a few seconds until the ONN logo appears.

- **To Power Off:** Press and hold the Power button until the power options menu appears. Select "Power off" and confirm.

### 3. Initial Setup

Upon first power-on, the tablet will guide you through the initial setup process:

1. **Language Selection:** Choose your preferred language.
2. **Wi-Fi Connection:** Select your Wi-Fi network from the list and enter the password. A stable internet connection is required for updates and Google account setup.
3. **Google Account:** Sign in with an existing Google account or create a new one. This is necessary to access the Google Play Store and other Google services.
4. **Date & Time:** Set your time zone and confirm date and time settings.
5. **Security:** Set up a screen lock (PIN, pattern, or password) for security.

## OPERATING THE TABLET

---

### 1. Basic Navigation

The ONN Tablet Pro uses touch gestures for navigation:

- **Tap:** To select an item or open an app.
- **Swipe:** To scroll through pages or menus.
- **Pinch-to-Zoom:** To zoom in or out on images or web pages.
- **Long Press:** To access contextual menus or move app icons.



# 10.1 Pulgadas

## Pantalla LCD Full HD

Image: The tablet's 10.1-inch screen provides ample space for content viewing.

## 2. Connecting to Wi-Fi

To connect or change Wi-Fi networks:

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi ON.
3. Select your desired network from the list and enter the password if prompted.

## 3. Using the Camera

The tablet is equipped with a 5 MP rear camera for capturing photos and videos. Open the Camera app from your home screen or app drawer. Tap the shutter button to take a photo or switch to video mode to record.



Camara de  
**5 MPX**

Image: The tablet's camera is suitable for video calls and capturing moments.

#### 4. Storage Management

Your tablet comes with 32GB of internal storage. You can expand this storage using a microSD card (sold separately). To manage storage, go to **Settings** > **Storage**. Here you can see storage usage and free up space.

# android 10



**+10**  
Batería de 3.8v/6600mAh

**32 GB**  
DE ALMACENAMIENTO

**2 GHz**  
PROCESADOR OCTA-CORE



ALMACENAMIENTO  
EXPANDIBLE


Image: Key features of the tablet, including its Android 10 operating system, battery life, storage, and processor.

## 5. Battery Life

The tablet offers an average battery life of 12 hours under typical usage conditions. Battery life may vary based on usage patterns, screen brightness, and running applications.

## 6. Google Space Kids

For families, the tablet supports Google Space Kids, providing a safe and curated environment for children to explore apps, books, and videos. This feature helps manage content access and screen time for younger users.



## Google Space Kids

Contenido seguro y divertido, ¡hecho a medida para niños!

Image: Google Space Kids offers a child-friendly interface for safe content consumption.

## MAINTENANCE

---

### 1. Cleaning

To clean your tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the screen or internal components.

### 2. Software Updates

Regularly check for software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to **Settings** > **System** > **System update** to check for and install available updates.

### 3. Storage Optimization

To maintain optimal performance, periodically manage your tablet's storage:

- Uninstall unused applications.
- Clear cached data for apps (**Settings** > **Apps & notifications** > select app > **Storage & cache** > **Clear cache**).
- Transfer large files (photos, videos) to cloud storage or an external microSD card.

## TROUBLESHOOTING

---

### Tablet Won't Turn On

- Ensure the tablet is charged. Connect it to the charger and wait a few minutes before attempting to power on.
- Press and hold the Power button for at least 10-15 seconds to perform a forced restart.

### Slow Performance

- Close unnecessary background applications.
- Clear app caches and free up storage space.
- Restart the tablet.
- Check for system updates.

### Wi-Fi Connection Issues

- Ensure Wi-Fi is enabled on the tablet.
- Restart your Wi-Fi router.
- Forget the network and reconnect (**Settings** > **Network & internet** > **Wi-Fi** > tap network > **Forget**).

### Battery Draining Fast

- Reduce screen brightness.
- Disable Wi-Fi, Bluetooth, and GPS when not in use.
- Close background apps.
- Check battery usage in **Settings** > **Battery** to identify power-hungry apps.

## SPECIFICATIONS

---



Image: Rear view of the ONN Tablet Pro, displaying its brand and model details.

Feature	Specification
Brand	ONN
Model Name	ONN 10.1" Tablet Pro
Item Model Number	796575180925
Screen Size	10.1 Inches
Screen Resolution	1920 x 1200 pixels (FHD)
Processor	2 GHz Octa-Core Processor (MediaTek Chipset)
RAM	3 GB
Hard Drive / Storage	32 GB (Flash Memory Size)
Operating System	Android 10

Feature	Specification
Rear Webcam Resolution	5 MP
Average Battery Life	12 Hours
Item Weight	1.52 pounds
Package Dimensions	11.77 x 8.82 x 2.24 inches

## WARRANTY AND SUPPORT

---

As an Amazon Renewed product, this ONN 10.1" Tablet Pro is backed by the Amazon Renewed Guarantee. This typically provides a 90-day refund or replacement policy if the product does not work as expected. For specific details regarding your purchase's warranty and return policy, please refer to your order details on Amazon.com or contact Amazon customer support directly.

For technical support or further assistance, please visit the Amazon Renewed support page or contact Amazon customer service.