

## Forrovenco QX-522 With Light

# Forrovenco 60 Inch Ceiling Fan with Lights Remote Control

MODEL: QX-522 WITH LIGHT

### Introduction

Welcome to the user manual for your new Forrovenco 60 Inch Ceiling Fan with Lights Remote Control. This manual provides detailed instructions for safe installation, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your product. Please read this manual thoroughly before installation and use, and retain it for future reference.

### Important Safety Information

To reduce the risk of electric shock, fire, or injury to persons, read and follow all instructions carefully.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes. Consult a qualified electrician if you are unsure about wiring.
- The fan must be mounted with a minimum of 7.6 feet (2.3 meters) clearance from the floor to the blades.
- The mounting bracket must be securely fastened to a ceiling joist or a suitable support structure capable of supporting the fan's weight.
- Do not insert objects into the path of the fan blades while the fan is operating.
- This fan is suitable for both indoor and covered outdoor/patio use. Do not expose to direct rain or uncovered outdoor conditions.

### Package Contents

Carefully unpack your ceiling fan and ensure all components are present and undamaged. Refer to the installation video for a visual guide to the parts list.

- Motor Housing
- 5 Solid Wood Blades
- LED Light Kit
- Remote Control
- Mounting Bracket
- 3 Downrods (5", 10", 15")
- Canopy
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual

## Installation Guide

---

Follow these steps for proper installation. For a visual demonstration, please watch the embedded installation video.

### 1. Mounting Bracket Installation

Secure the mounting bracket to a ceiling joist or a suitable support structure using the provided screws. Ensure it is firmly attached and can support the fan's weight.

### 2. Blade Assembly


Attach each of the 5 solid wood blades to the motor housing using the provided screws. Ensure all screws are tightened securely.

### 3. Downrod Attachment

Select the appropriate downrod (5", 10", or 15") for your ceiling height. Insert the wire harness through the downrod, then attach the downrod to the motor housing, securing it with the pin and screws.

# Dimension

5"/10"/ 15" down rod included



## Mounting Option



Downrod Mount



Sloped Ceiling Mount(Up to 15 degrees)

## Ideal for Room

12ft.x12ft.to  
18ft.x18ft.



Image: Downrod options and fan dimensions.

## 4. Wiring Connections

Connect the receiver wires to the ceiling wires according to the color-coded instructions. Ensure all connections are secure using wire nuts. Connect the fan's wires to the receiver.

## 5. Canopy Installation

Slide the canopy up to the ceiling and secure it to the mounting bracket with the provided screws, covering all wiring connections.

## Installation Video Guide

Your browser does not support the video tag.

Video: Step-by-step guide on how to install the Forrovenco Ceiling Fan with Lights.

## Operating Instructions

Your Forrovenco ceiling fan is operated using the included remote control. Ensure 2 AAA batteries (not included) are installed in the remote.

### Remote Control Overview



Bedroom



Covered Patio Porch



Sloped Ceiling



Outdoor/Uncovered

Image: Remote control and fan with reversible function arrows.

- **ALL OFF:** Turns off both fan and light.
- **LIGHT ON/OFF:** Toggles the light on or off.
- **FAN ON/OFF:** Toggles the fan on or off.
- **1-6:** Adjusts fan speed from 1 (lowest) to 6 (highest).
- **F/R:** Controls the reversible function (Forward/Reverse).
- **1H/2H/4H:** Sets the fan timer for 1, 2, or 4 hours.

## Fan Speed Control

The fan offers 6 adjustable speeds to suit your comfort needs. Speeds 1-2 are ideal for sleeping, 3-4 for working or general comfort, and 5-6 for sports or maximum airflow.




Image: Fan speed recommendations for different activities.

## Light Control

The integrated LED light offers 3 color temperature settings: Warm Light (3000K), Natural Light (4500K), and Cold Light (6000K). Cycle through these settings using the light button on the remote.

## CEILING FAN WITH LIGHT




### 3 COLOR TEMPERATURE LIGHT KIT



Warm Light

Natural Light

White Light



3000K

4500K

6000K

1

2

3

4

5

6



Image: Three color temperature light kit options.

### Reversible Function (Summer/Winter Mode)

The fan features a reversible DC motor. In summer, set the fan to downdraft mode (forward rotation) to create a cooling breeze. In winter, switch to updraft mode (reverse rotation) to circulate warm air trapped near the ceiling, helping to reduce heat loss.



Image: Summer and Winter mode operation.

Timer Function

Use the 1H, 2H, or 4H buttons on the remote to set the fan to automatically turn off after the selected duration.

Product Feature Overview

Your browser does not support the video tag.

Video: Overview of the Forrovenco 5 Blades Solid Wood Ceiling Fan with Lights, highlighting key features.

Maintenance

Regular maintenance helps ensure the long-term performance and appearance of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Periodically check the blade screws for tightness. Loose screws can cause wobbling and noise.
- **Light Cover:** Ensure the light cover is securely attached.
- **Motor:** The DC motor is designed for quiet operation and requires no lubrication.

Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

| Problem             | Possible Cause                                                          | Solution                                                                                                      |
|---------------------|-------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| Fan does not start  | No power to the fan; Loose wiring; Remote control battery dead.         | Check circuit breaker; Verify all wire connections; Replace remote control batteries.                         |
| Fan wobbles         | Loose blade screws; Improperly balanced blades; Loose mounting bracket. | Tighten all blade screws; Use a balancing kit (not included) if necessary; Ensure mounting bracket is secure. |
| Light does not work | Loose wiring; LED board issue.                                          | Check light kit wiring connections; Contact customer support if LED board is faulty.                          |

| Problem                    | Possible Cause                     | Solution                                                                                                                |
|----------------------------|------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Remote control not working | Dead batteries; Remote not paired. | Replace batteries; Refer to remote pairing instructions (if applicable, usually automatic).                             |
| Fan is noisy               | Loose screws; Motor issue.         | Check and tighten all screws; Ensure blades are not hitting anything; Contact customer support if motor noise persists. |

### Product Specifications

| Feature              | Detail                                 |
|----------------------|----------------------------------------|
| Brand                | Forrovenco                             |
| Model Name           | QX-522 With Light                      |
| Size                 | 60 inch                                |
| Color                | Yellow Walnut                          |
| Power Source         | DC Motor                               |
| Number of Blades     | 5                                      |
| Fan Speeds           | 6                                      |
| Light Type           | LED                                    |
| Color Temperature    | 3 Adjustable (3000K, 4500K, 6000K)     |
| Timer Intervals      | 1H, 2H, 4H                             |
| Motor Type           | Reversible Quiet DC Motor (under 25dB) |
| Downrod Options      | 5", 10", 15"                           |
| Voltage              | 120 Volts                              |
| Wattage              | 15 watts                               |
| Certifications       | ETL, FCC                               |
| Indoor/Outdoor Usage | Indoor, Covered Outdoor                |

### Warranty and Support

Forrovenco stands behind the quality of its products. This ceiling fan comes with **3-Year Worry-Free Warranty**.

For any questions, technical assistance, or warranty claims, please contact Forrovenco customer support. We offer **24H Service** to assist you with your needs.

Please visit the [Forrovenco Store](#) for more information or to contact support.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question