

Xdobo Xdobo Beast 1982

Xdobo Beast 1982 Portable Bluetooth Speaker User Manual

Model: Xdobo Beast 1982 | Brand: Xdobo

1. INTRODUCTION

Thank you for purchasing the Xdobo Beast 1982 Portable Bluetooth Speaker. This powerful 120W speaker is designed to deliver high-quality audio with deep bass and clear treble, perfect for various indoor and outdoor activities. With its IPX6 waterproof rating, long battery life, and karaoke function, it's an ideal companion for parties, gatherings, and personal entertainment. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Keep the speaker away from strong magnetic fields.
- Do not disassemble, repair, or modify the device yourself. Refer to qualified personnel for service.
- Ensure the charging port cover is securely closed when using the speaker near water to maintain its IPX6 rating.
- Use only the provided charging cable and a compatible 5V/3A adapter.
- Avoid dropping or subjecting the speaker to strong impacts.

3. PACKAGE CONTENTS

- Xdobo Beast 1982 Portable Bluetooth Speaker
- Wireless Microphone
- Type-C Charging Cable
- 3.5mm AUX Audio Cable
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Image: The Xdobo Beast 1982 speaker with its integrated handle and included wireless microphone.

Controls and Ports:

- **Power Button:** Press and hold to turn on/off.
- **Bluetooth Button:** Press to enter Bluetooth pairing mode.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Play/Pause Button:** Press to play or pause music.
- **EQ Mode Button:** Press to cycle through sound equalization modes.
- **Type-C Charging Port:** For charging the speaker.
- **USB Port:** For U disk playback.
- **TF Card Slot:** For TF card playback.

- **AUX-in Port (3.5mm):** For wired audio connection.
- **Microphone Input (6.35mm):** For wired microphone connection (in addition to the wireless mic).

5. SETUP

5.1 Charging the Speaker

1. Connect the provided Type-C charging cable to the speaker's charging port.
2. Connect the other end of the cable to a 5V/3A power adapter (not included).
3. The charging indicator light will illuminate. It takes approximately 5 hours for a full charge.
4. The indicator light will turn off or change color once fully charged.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power button for 2-3 seconds until you hear an audible prompt.
- **To Power Off:** Press and hold the Power button for 2-3 seconds until you hear an audible prompt.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

CD-level shocking sound quality

4 playback modes · get rid of shackles · intimate companion



Bluetooth 5.3



U disk



AUX audio



TF Card playback



Black gray

Beast 1982

Image: The speaker supports Bluetooth 5.3, U disk, AUX audio, and TF card playback.

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED.
2. Enable Bluetooth on your device (smartphone, tablet, computer, etc.).
3. Search for "Xdobo Beast 1982" in the list of available Bluetooth devices.
4. Select it to connect. Once connected, the LED will turn solid blue, and you will hear a confirmation sound.
5. If pairing fails, turn off the speaker and your device's Bluetooth, then repeat the steps.

6.2 Connecting via AUX

1. Connect one end of the 3.5mm AUX audio cable to the speaker's AUX-in port.
2. Connect the other end to the audio output jack of your device (e.g., TV, PC, MP3 player).
3. The speaker will automatically switch to AUX mode.

6.3 Using TF Card / U Disk

1. Insert a TF card (MicroSD) into the TF card slot or a U disk (USB flash drive) into the USB port.
2. The speaker will automatically detect the storage device and begin playing audio files.

6.4 Karaoke Function (Microphone)

The speaker comes with a wireless microphone for karaoke. It also has a 6.35mm input for a wired microphone.

1. Ensure the speaker is powered on.
2. Turn on the wireless microphone. It should automatically connect to the speaker.
3. Adjust the microphone volume on the microphone itself or through the speaker's main volume controls.
4. For a wired microphone, plug it into the 6.35mm microphone input port.

6.5 EQ Modes



Image: The speaker's internal components, highlighting its 120W power output for dynamic bass and treble. The Xdobo Beast 1982 features 3 distinct EQ modes to optimize your listening experience:

- **Vocal Mode:** Enhances vocal clarity, ideal for podcasts or speeches.
- **Full Frequency Mode:** Provides a balanced sound profile for general listening.
- **Super Bass Mode:** Boosts low frequencies for a more impactful bass, perfect for music genres with heavy bass.

Press the EQ Mode button repeatedly to cycle through these modes.

6.6 IPX6 Waterproof Rating

IPX6 Waterproof

Don't care about the weather for outdoor use



Image: The Xdobo Beast 1982 demonstrating its IPX6 waterproof capability, suitable for outdoor use.

The speaker is rated IPX6 waterproof, meaning it can withstand high-pressure water jets from any direction. This makes it suitable for use outdoors, by the pool, or at the beach. However, it is **not** designed to be submerged in water.



Portable Design

Ergonomic all-in-one handle design makes the speaker can be easily lifted with one hand to take it anywhere

Image: The ergonomic handle design allows for easy portability of the speaker with one hand.

Outdoor Party Atmosphere Artifact



From slow to dynamic, from slow rock to DJ.
Experience the clarity of the human voice,
the surge of the original sound,
and create a private party.



Image: The Xdobo Beast 1982 enhances outdoor party atmospheres, providing clear and powerful sound for various activities.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, charge the speaker at least once every three months if not used regularly.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Bluetooth disabled on device; too far from device.	Ensure speaker is in pairing mode. Enable Bluetooth on your device. Move speaker closer to device (within 10m).
No sound from speaker.	Volume too low; incorrect input mode; audio cable not connected properly.	Increase volume. Check if the correct input mode (Bluetooth, AUX, TF, USB) is selected. Ensure cables are securely connected.
Microphone not working.	Microphone off; low battery in mic; incorrect mic input.	Ensure microphone is turned on. Check microphone battery. Ensure wireless mic is paired or wired mic is in the correct 6.35mm input.
Sound distortion.	Volume too high; audio source issue.	Lower the volume. Try a different audio source or file.

9. SPECIFICATIONS

Feature	Detail
Model Name	Xdobo Beast 1982
Bluetooth Version	5.3
Output Power	120W RMS
Frequency Response	20Hz - 20KHz
Sound Pressure Level (SPL)	100dB
Charging Time	Approx. 5 hours
Power Input	Type-C 5V/3A
Playback Time	Over 8 hours (varies by volume and content)
Dimensions (L x W x H)	399 x 159 x 215 mm (15.7 x 6.3 x 8.5 inches)

Feature	Detail
Weight	3490 grams (7.69 lbs)
Waterproof Rating	IPX6
Connectivity	Bluetooth, AUX, TF Card, USB
Special Features	Portable, Shockproof, Dustproof, Waterproof, USB Playback, Karaoke Function, 3 EQ Modes



Notice:

**Beast 1982 don't have TWS functions ,
The package boxes are misprinted by factory.
If you mind , please consider it before order.
Thanks for your understanding.**

Important Notice: The Xdobo Beast 1982 does NOT have TWS (True Wireless Stereo) functions. The packaging may contain misprinted information regarding TWS. Please consider this before purchase.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided on the product packaging or the official Xdobo website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Xdobo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question