

[Manuals.plus](#) /

› [EnHomee](#) /

› EnHomee Tall Nightstands (Set of 2) with Charging Station and LED Light - Instruction Manual

## EnHomee Night Stand

# EnHomee Tall Nightstands (Set of 2) with Charging Station and LED Light - Instruction Manual

### INTRODUCTION

---

Thank you for choosing the EnHomee Tall Nightstands. This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new nightstands. Designed for versatility, these nightstands feature five fabric drawers, a convenient charging station with AC outlets and USB ports, and integrated LED lighting. Please read this manual thoroughly before assembly and use to ensure safe and optimal performance.



Image: Two EnHomee Tall Nightstands positioned beside a bed, highlighting their design and features.

## SAFETY INFORMATION

**Caution:** Use anti-toppling devices to prevent tipping. Keep fingers away from drawer openings to avoid injury. Ensure stability on uneven surfaces. Always follow assembly instructions carefully.

- Always place the nightstand on a flat, stable surface.
- Do not overload drawers; adhere to the maximum weight recommendation of 80 pounds for the entire unit.
- Keep electrical components (charging station, LED lights) away from water or excessive moisture.
- Ensure all screws and fasteners are securely tightened during assembly and periodically check for looseness.
- Supervise children around the nightstand, especially when drawers are open or electrical devices are connected.

## PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or

damaged, please contact customer support.

- 5 Dresser Drawers (for each nightstand)
- Assembly Guide
- Installation Tool (e.g., screwdriver)
- L-shaped hooks (2 per side table)
- Side bag (1 per side table)
- LED Nightstands with Ports & Outlets (main frame components)

## SETUP AND ASSEMBLY

---

Assembly of the EnHomee Tall Nightstands is designed to be straightforward, typically completed within 20 minutes by one person. All necessary hardware, tools, and a detailed assembly manual are included. Please follow the step-by-step instructions provided in the included guide for a smooth setup process.

Your browser does not support the video tag.

Video: Demonstrates the quick and easy assembly process for the EnHomee Nightstand.

### Assembly Tips:

- Lay out all parts and hardware before starting.
- Do not overtighten screws during initial assembly; tighten fully once the frame is stable.
- Ensure the charging station and LED light strip are correctly positioned before securing.



Image: Detailed dimensions of the nightstand and its components, useful for assembly planning.

## OPERATING INSTRUCTIONS

### Charging Station:

Each EnHomee nightstand is equipped with a built-in charging station featuring 2 standard AC outlets (125V 12A) and 2 Type-A USB ports (5V 2A). This allows you to conveniently charge your electronic devices such as phones, tablets, and lamps directly from the nightstand, eliminating the need for additional extension cords.

Your browser does not support the video tag.

Video: Showcases the functionality of the integrated USB ports and AC outlets for charging devices.



Image: The nightstand's top surface with the charging station in use, demonstrating its convenience.

### LED Light:

The integrated LED light strip provides soft ambient lighting for your room. It features 20 RGB LED colors and various dynamic modes, allowing you to customize the atmosphere. Control the LED light using the provided remote control.

# RGB LED Light Strip

## 20 Dynamic Modes



Image: The LED light strip displaying multiple color options and dynamic effects.

### Storage Features:

Each nightstand offers ample storage with five fabric drawers, ideal for organizing clothes, blankets, and other personal items. An extra side bag provides convenient access for phones, glasses, and remotes. Additionally, L-shaped hooks are included for hanging headphones, bags, or other accessories.

Your browser does not support the video tag.

Video: Highlights the side bag and hooks for additional storage and organization.

Large Storage Space



Image: The nightstand's drawers open, illustrating the spacious storage for various items.


# Tall Nightstand Details



**Extra Side Bag**



**L-shaped Hooks**



**Easy-pull Handles**



**Stable Adjustment Feet**

Image: Detailed view of the side bag, hooks, drawer handles, and adjustable feet.

## MAINTENANCE

- **Cleaning:** Wipe the metal frame and wooden top with a soft, damp cloth. Avoid harsh chemicals. The fabric drawers can be spot cleaned with a mild detergent and air-dried.
- **Drawer Care:** The fabric drawers are designed for lightweight items. Avoid placing excessively heavy objects in them to prevent sagging or damage.
- **Electrical Components:** Ensure the charging station and LED light connections are secure. Do not attempt to repair electrical components yourself; contact qualified personnel if issues arise.
- **Stability Check:** Periodically check all screws and fasteners to ensure they remain tight. Adjust the leveling feet as needed to maintain stability on uneven floors.

## TROUBLESHOOTING

| Problem                                            | Possible Cause                                                          | Solution                                                                                                                                                                          |
|----------------------------------------------------|-------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Nightstand is wobbly.                              | Uneven floor; loose screws.                                             | Adjust the leveling feet at the bottom of the nightstand. Tighten all assembly screws.                                                                                            |
| Charging station not working.                      | Power cord not plugged in; faulty outlet; damaged charging unit.        | Ensure the power cord is fully plugged into a working wall outlet. Check if the charging unit itself is securely connected. If issues persist, contact customer support.          |
| LED light not turning on or remote not responding. | LED strip not connected; remote battery dead; remote signal obstructed. | Ensure the LED light strip is properly connected to its power source. Replace the remote control battery. Ensure there is no obstruction between the remote and the LED receiver. |
| Drawers slide out too easily.                      | This is a design characteristic of fabric drawers not on tracks.        | Exercise caution when opening and closing drawers. Avoid sudden movements.                                                                                                        |

## SPECIFICATIONS

**Brand:** EnHomee

**Model Name:** Nightstand

**Product Dimensions:** 11.8"D x 15.7"W x 37.5"H

**Item Weight:** 18 pounds

**Maximum Weight Recommendation:** 80 pounds

**Frame Material:** Metal, Wood

**Material Type:** Metal, heavy-duty woven cloth fabric, thickened wood

**Color:** Rustic Brown

**Number of Drawers:** 5

**Special Features:** Charging Station (2 AC outlets, 2 USB ports), LED Light, Space Saving, Storage

**Recommended Number of People for Assembly:** 1

**Recommended Uses:** Bedroom, Living Room, Closet, Home Office, Entryway, Study Room

## WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your EnHomee Tall Nightstands, please refer to the contact information provided in your purchase documentation or reach out to EnHomee customer support directly. Please retain your proof of purchase for warranty claims.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0D1CD8JNR>

More documents and user manuals: <https://manuals.plus/>