

120x42x191 cm, white/Fonnes white

PLATSA Wardrobe Instruction Manual

Model: 120x42x191 cm, white/Fonnes white

Brand: Generic

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your new PLATSA wardrobe. Designed for versatile storage, this wardrobe features six doors and ample internal space, making it an ideal solution for organizing clothes, linens, and other household items.

Please read this manual carefully before beginning assembly or use to ensure safe and proper installation and long-term enjoyment of your product.

PRODUCT OVERVIEW



Image: The PLATSA wardrobe with its top-left door open, showcasing the interior layout with three adjustable shelves and robust door hinges. This view highlights the functional design and storage capacity.



Image: The PLATSA wardrobe positioned in an entryway, demonstrating its integration into a home environment. It stands beside a coat rack and shoe storage, illustrating its utility for organizing outerwear and footwear.



Image: The PLATSA wardrobe situated in a bedroom, showcasing its adaptability to various room types. It complements the bedroom furniture, providing significant storage without dominating the space.



Image: The PLATSA wardrobe frame without its doors, illustrating the modularity and internal storage possibilities. The compartments are shown with various items like boxes, bags, and luggage, highlighting its versatile storage potential.

SETUP AND ASSEMBLY

Assembly of the PLATSA wardrobe requires two people and basic tools (not included). Ensure all parts are present before beginning.

Required Tools:

- Screwdriver (Phillips head)
- Hammer
- Measuring tape
- Level

Assembly Steps:

1. **Unpack and Verify:** Carefully unpack all components and compare them against the parts list provided in the

packaging. Report any missing or damaged parts immediately.

2. **Assemble Frame:** Connect the side panels, top, and bottom panels using the provided cam locks and dowels. Ensure all connections are secure and the frame is square.
3. **Install Back Panel:** Slide the back panel into the grooves on the frame. Secure it with small nails or screws as indicated in the specific assembly diagram.
4. **Attach Legs:** Screw the base legs into the designated points on the bottom panel of the wardrobe. Adjust for stability.
5. **Insert Shelves:** Place the shelf pins into the desired holes on the side panels. Slide the shelves onto the pins. The wardrobe includes 3 shelves, and additional shelves can be purchased separately.
6. **Mount Hinges:** Attach the hinges to the wardrobe frame and the doors according to the diagrams. Ensure they are aligned correctly for smooth door operation.
7. **Attach Doors:** Carefully lift and attach each of the six doors to the mounted hinges. Adjust the hinges as needed to ensure doors are level and close properly.
8. **Secure to Wall (Recommended):** For safety, especially in homes with children or pets, it is highly recommended to secure the wardrobe to a wall using the anti-tip hardware provided. This prevents accidental tipping.

Refer to the detailed graphical instructions included in your product packaging for precise step-by-step diagrams.

OPERATING INSTRUCTIONS

The PLATSA wardrobe is designed for easy and efficient storage. Its six doors provide convenient access to different sections.

Storage Recommendations:

- **Shelves:** Utilize the adjustable shelves for folded clothes, linens, shoes, or storage boxes.
- **Weight Distribution:** Distribute weight evenly across shelves to maintain stability and prevent warping. Avoid placing excessively heavy items on a single shelf.
- **Door Operation:** Open and close doors gently to prevent wear on hinges. If doors become misaligned, adjust the hinge screws as per the assembly guide.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your PLATSA wardrobe.

Cleaning:

- Wipe clean with a damp cloth and a mild cleaner.
- Wipe dry with a clean cloth.
- Avoid abrasive cleaners or harsh chemicals, as they can damage the finish.

General Care:

- Periodically check all screws and fittings to ensure they are tight. Retighten if necessary.
- Keep the wardrobe away from direct sunlight and excessive moisture to prevent material degradation.
- If moving the wardrobe, empty it first and lift it carefully to avoid stressing the joints. Do not drag.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	Hinges are loose or improperly adjusted.	Adjust the screws on the hinges. Refer to the assembly manual for hinge adjustment instructions. Ensure the wardrobe is level.
Wardrobe feels wobbly or unstable.	Screws are loose; legs are uneven; not secured to wall.	Tighten all assembly screws. Adjust the leveling feet on the legs. Ensure the wardrobe is secured to the wall using the anti-tip hardware.
Shelves sag or bow.	Overloaded shelf; uneven weight distribution.	Reduce the weight on the shelf. Redistribute items evenly. Consider adding additional shelf supports if available.

SPECIFICATIONS

- Model:** PLATSA Wardrobe w 6 doors
- Dimensions (Assembled):** Width: 120 cm, Depth: 42 cm, Height: 191 cm
- Color:** White / Fonnes White
- Material:** Engineered Wood
- Number of Doors:** 6
- Number of Shelves:** 3 (adjustable)
- Mounting Type:** Floor Mount, Freestanding (wall attachment recommended)
- Assembly Required:** Yes
- Recommended Uses:** Linens, Clothes, Shoes, Towels
- Manufacturer:** ProTuning
- ASIN:** B0D1CP5C91

WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the documentation provided with your purchase or contact the retailer directly. Keep your proof of purchase for any warranty claims.

For additional assistance or to order replacement parts, please contact the manufacturer, ProTuning, or your point of purchase.