

[Manuals.plus](#) /

› [VAPPEBY](#) /

› VAPPEBY Bluetooth Speaker User Manual

## VAPPEBY Gen 3 (IK.495.378.39)

# VAPPEBY Bluetooth Speaker User Manual

Model: VAPPEBY Gen 3 (IK.495.378.39)

## 1. INTRODUCTION

---

Thank you for choosing the VAPPEBY Bluetooth Speaker. This user manual provides essential information for setting up, operating, and maintaining your new speaker system. The VAPPEBY Bluetooth speaker is designed for ease of use, delivering clear and powerful sound for your audio enjoyment.

### Package Contents

- 2 x VAPPEBY Bluetooth Speakers
- Power Cables
- User Manual (this document)



Image 1.1: The VAPPEBY Bluetooth Speaker set, featuring two black speakers with integrated handles, ready for use.

## 2. IMPORTANT SAFETY INFORMATION

---

Please read all safety instructions carefully before using the product. Keep this manual for future reference.

- Do not expose the speaker to water or excessive moisture.
- Do not place the speaker near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

## 3. SETUP GUIDE

---

### 3.1 Unpacking and Placement

Carefully remove the speakers from their packaging. Place the speakers on a stable, flat surface. Ensure there is adequate ventilation around the speakers.



Image 3.1: Example of VAPPEBY speakers placed on a shelf, demonstrating suitable placement in a home environment.

### 3.2 Power Connection

Connect the power cable to the power input port on the back of each speaker. Plug the other end of the power cable into a suitable wall outlet. Ensure the power source matches the speaker's voltage requirements.



Image 3.2: Illustrates the connection point on the rear of the speaker, where the power module or battery is inserted.

### 3.3 Initial Power On and Bluetooth Pairing

1. Press and hold the power button (usually located on the top or back) until the indicator light illuminates.
2. Once powered on, the speaker will automatically enter Bluetooth pairing mode (indicated by a blinking light).
3. On your device (smartphone, tablet, computer), go to Bluetooth settings and select "VAPPEBY Speaker" from the list of available devices.
4. Once connected, the indicator light will become solid, and you will hear a confirmation sound.

## 4. OPERATING INSTRUCTIONS

### 4.1 Power On/Off

- To turn on: Press and hold the power button until the indicator light turns on.
- To turn off: Press and hold the power button until the indicator light turns off.

### 4.2 Volume Control

Adjust the volume using the rotary knob located on the top panel of the speaker. Turn clockwise to increase volume and counter-clockwise to decrease.



Image 4.1: Detailed view of the speaker's top controls, including the power button and the volume adjustment knob.

### 4.3 Bluetooth Connection Management

- **Reconnecting:** The speaker will automatically attempt to reconnect to the last paired device when powered on.
- **Pairing New Device:** If the speaker does not connect automatically, or if you wish to pair a new device, press and hold the Bluetooth pairing button (if available, otherwise power cycle) until the indicator light blinks, then follow step 3 from section 3.3.
- **Disconnecting:** Disconnect the speaker from your device's Bluetooth settings.

## 5. MAINTENANCE

### 5.1 Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may

damage the finish. Avoid spraying liquids directly onto the speaker.

## 5.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speaker	Speaker is off; Volume is too low; Not paired correctly; Device volume is low.	Ensure speaker is on and charged/powerd. Increase speaker and device volume. Re-pair the Bluetooth device.
Cannot pair with Bluetooth device	Speaker not in pairing mode; Device Bluetooth off; Too far from speaker; Interference.	Ensure speaker is in pairing mode (blinking light). Turn Bluetooth on your device. Move device closer to speaker. Turn off other Bluetooth devices nearby.
Sound distortion	Volume too high; Weak Bluetooth signal; Audio source issue.	Lower the volume on both speaker and device. Move device closer to speaker. Try a different audio source.

## 7. SPECIFICATIONS

Feature	Detail
Model	VAPPEBY Gen 3 (IK.495.378.39)
Power Output	39 W
Dimensions (H x W x D)	20 cm x 20 cm x 8 cm
Connectivity	Bluetooth
Color	Black

## 8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. This product is manufactured by ProTuning.

For technical support or inquiries, please contact the customer service department of your retailer or the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.