

IK.291.765.84

MALM Bed Frame with Storage (180x200 cm) - User Manual

1. PRODUCT OVERVIEW

This manual provides essential information for the assembly, operation, and maintenance of your MALM Bed Frame with Storage. Designed for comfort and practicality, this bed frame features integrated storage solutions to maximize your bedroom space.

The MALM bed frame, high, with 2 storage boxes, measures 180x200 cm and comes in a white stained oak veneer/Luröy finish. Ample storage space is neatly hidden under the bed in 2 large drawers, perfect for storing duvets, pillows, and bedding.



Figure 1.1: The MALM bed frame with storage, shown in a complete bedroom setup.



Figure 1.2: The MALM bed frame highlighting the integrated storage drawer.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the bed frame or drawers.
- Distribute weight evenly on the bed frame.
- Use the bed frame only for its intended purpose.

3. COMPONENTS LIST

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Bed Frame Structure
- Headboard
- Footboard
- Side Rails
- Bed Slats (Luröy)
- 2 x Drawers (Storage boxes)
- Assembly Hardware (screws, dowels, brackets, etc.)
- Installation Manual (this document)




Figure 3.1: Detail of the Luröy bed slats, providing mattress support.

4. SETUP AND ASSEMBLY

Assembly of the MALM bed frame is required. It is recommended that two people assemble this product. Please follow the detailed instructions provided in the separate installation manual included with your purchase. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hammer) before starting.

General Assembly Steps:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Assemble the headboard and footboard sections according to the specific instructions.
3. Attach the side rails to the headboard and footboard, ensuring all connections are secure.
4. Install the Luröy bed slats onto the side rails.
5. Assemble the two storage drawers separately, following the instructions for drawer construction and wheel attachment.
6. Slide the assembled drawers into position under the bed frame.
7. Place your mattress on the bed slats.



Figure 4.1: The assembled MALM bed frame, ready for use.

5. OPERATION

The MALM bed frame is designed for easy use and integrated storage. The two large drawers slide smoothly on wheels, providing convenient access to your stored items.

Using the Storage Drawers:

- To open a drawer, gently pull the front panel outwards. The wheels will allow it to glide smoothly from under the bed.
- To close a drawer, push the front panel inwards until it is fully recessed under the bed frame.
- Avoid overloading the drawers to ensure smooth operation and prevent damage to the drawer mechanism or the bed frame.
- Do not force the drawers if they encounter resistance; check for obstructions.



Figure 5.1: An open storage drawer, demonstrating its capacity for bedding or clothing.



Figure 5.2: A detailed view of the storage drawer, highlighting its functionality.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your MALM bed frame.

- **Cleaning:** Wipe clean with a damp cloth and a mild cleaner. Wipe dry with a clean cloth.
- **Dusting:** Regularly dust the surfaces with a soft, dry cloth.
- **Inspection:** Periodically check all assembly fittings and re-tighten them if necessary to ensure the bed frame remains stable.
- **Avoid:** Do not use abrasive cleaners, strong chemicals, or harsh scrubbing pads, as these can damage the finish.

7. TROUBLESHOOTING

If you encounter any issues with your MALM bed frame, refer to the following common troubleshooting tips:

- **Squeaking Noises:** Check all bolts and screws. Tighten any loose fittings. Ensure the bed slats are correctly

seated and not rubbing against the frame.

- **Drawers Not Sliding Smoothly:** Check if the drawers are overloaded. Inspect the wheels for any obstructions or damage. Ensure the drawer runners are clean and free of debris.
- **Instability/Wobbling:** Verify that the bed frame is assembled on a flat, level surface. Re-check all connections and tighten any loose hardware.
- **Damaged Parts:** If any part is damaged during assembly or use, cease using the product and contact customer support for replacement parts.

8. SPECIFICATIONS

Detailed specifications for the MALM Bed Frame with Storage:

Feature	Detail
Brand	Generic
Model	IK.291.765.84
Color	White Stained Oak Veneer
Compatible Mattress Size	European double (200x180 cm)
Assembly Required	Yes
Assembled Length	209 cm
Assembled Width	196 cm
Assembled Height	100 cm
Headboard Height	100 cm
Footboard Height	38 cm
Internal Drawer Height	15 cm
Internal Drawer Width	97 cm
Internal Drawer Depth	59 cm



Figure 8.1: Side profile of the MALM bed frame, illustrating its dimensions.

9. WARRANTY AND SUPPORT

For information regarding warranty coverage, please refer to the purchase documentation or contact the retailer from whom you purchased this product. If you require assistance with assembly, missing parts, or have any questions not covered in this manual, please contact the seller directly for support.

Seller: Fast Shipping Tuning

Please have your model number (IK.291.765.84) and purchase date available when contacting support.