

MHPRO DJCG00001

MHPRO 21V Cordless Screwdriver Charger Instruction Manual

Model: DJCG00001

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your MHPRO 21V Cordless Screwdriver Charger, model DJCG00001. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INSTRUCTIONS

Always observe the following safety precautions to prevent electric shock, fire, or serious injury:

- Use only with compatible 21V MHPRO cordless screwdriver batteries.
- Do not expose the charger to rain or wet conditions.
- Do not use the charger if the cord or plug is damaged.
- Unplug the charger from the power outlet when not in use or before cleaning.
- Do not attempt to disassemble or modify the charger. Refer all servicing to qualified personnel.
- Ensure adequate ventilation during charging. Do not cover the charger.
- Keep out of reach of children.

PRODUCT OVERVIEW

The MHPRO 21V Cordless Screwdriver Charger is designed to efficiently recharge 21V lithium-ion batteries for MHPRO cordless screwdrivers. It features a compact design and an indicator light for charging status.



Image 1: MHPRO 21V Cordless Screwdriver Charger. This image shows the black charger unit with its integrated power cord and barrel connector. The charger has a textured surface and a small indicator light on its front face.

SETUP

1. **Unpack the Charger:** Carefully remove the charger from its packaging. Inspect for any signs of damage.
2. **Choose a Location:** Place the charger on a stable, flat, non-flammable surface in a well-ventilated area, away from direct sunlight and moisture.
3. **Connect to Power:** Plug the charger's power cord into a standard 220-240V AC electrical outlet. The indicator light on the charger may illuminate briefly.

OPERATING INSTRUCTIONS

1. **Insert Battery:** Connect the barrel connector of the charger to the charging port on your MHPRO 21V cordless screwdriver battery. Ensure a secure connection.
2. **Charging Indicator:** The indicator light on the charger will typically illuminate red during charging.
3. **Charging Complete:** Once the battery is fully charged, the indicator light will usually change to green. Charging time varies depending on the battery's charge level and capacity.

- 4. **Remove Battery:** Disconnect the charger from the battery once charging is complete.
- 5. **Unplug Charger:** Unplug the charger from the wall outlet when not in use.

Note: Do not leave batteries on the charger for extended periods after they are fully charged, as this can reduce battery life.

MAINTENANCE

- **Cleaning:** Disconnect the charger from the power supply before cleaning. Use a soft, dry cloth to wipe the exterior of the charger. Do not use abrasive cleaners or solvents.
- **Storage:** Store the charger in a dry, cool place when not in use. Avoid extreme temperatures.
- **Cord Inspection:** Regularly inspect the power cord and connector for any signs of damage. If damaged, discontinue use and replace the charger.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Charger indicator light does not illuminate.	No power to the charger; faulty outlet; damaged charger.	Check power outlet; ensure charger is securely plugged in; try a different outlet. If problem persists, the charger may be faulty.
Battery not charging.	Battery not properly connected; battery is faulty; charger is faulty.	Ensure battery is securely connected to the charger; test with a different compatible battery if available.
Charger gets warm during use.	Normal operation; poor ventilation.	It is normal for the charger to get slightly warm. Ensure it is in a well-ventilated area and not covered. If it becomes excessively hot, discontinue use.

SPECIFICATIONS

- **Brand:** MHPRO
- **Model:** DJCG00001 (MR5805T)
- **Input Voltage:** 220-240V AC (Standard European/Belgian outlet)
- **Output Voltage:** 21V DC
- **Compatibility:** MHPRO 21V Cordless Screwdriver Batteries
- **ASIN:** B0D1FL5PJX

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your MHPRO cordless screwdriver or visit the official MHPRO website. Please have your model number (DJCG00001) and purchase details available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question