

[Manuals.plus](#) /

> [TehanId](#) /

> TehanId 3.2 Cu.Ft Beverage Fridge (Model TehanId001) Instruction Manual

TehanId TehanId001

TehanId 3.2 Cu.Ft Beverage Fridge (Model TehanId001) Instruction Manual

Comprehensive guide for setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the TehanId 3.2 Cu.Ft Beverage Fridge (Model TehanId001). This manual provides essential information for the safe and efficient use of your new appliance. Please read all instructions carefully before installation and operation, and retain this manual for future reference.






Image 1.1: Front view of the Tehanld 3.2 Cu.Ft Beverage Fridge, showcasing its capacity for various beverages.

2. IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces immediately after plugging in.
- Ensure the appliance is unplugged for 6-12 hours before initial use to allow refrigerant to settle.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- This appliance is intended for household use only.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials. It is recommended to keep the original packaging for future transport or service needs. Remove any protective film from the refrigerator before use.

3.2 Placement

Place the appliance on a flat, stable surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit. The external dimensions are approximately 18.5"D x 17.5"W x 32.7"H.



Image 3.1: Visual representation of the beverage fridge's dimensions and capacity, showing it can hold 26 bottles or 128 cans.

3.3 Leveling

The appliance features an adjustable leg to adapt to uneven ground. Ensure the fridge is level to optimize cooling performance and door sealing.

Customized your Containers for Freshness.



Image 3.2: Interior view of the fridge highlighting the adjustable shelves and the adjustable leveling leg at the bottom.

3.4 Initial Power-On

After placement, allow the fridge to stand unplugged for 6-12 hours before connecting it to a 115 Volts (AC) power outlet. This allows the refrigerant to settle, aiding in cooling and extending the fridge's lifespan.

4. OPERATING INSTRUCTIONS

4.1 Control Panel

The beverage fridge is equipped with a user-friendly touch panel for temperature adjustment and light control. The temperature range is 35-65°F (2-18°C).



Image 4.1: Detailed view of the touch control panel, showing buttons for light, temperature adjustment, and mode selection.

4.2 Temperature Adjustment

Use the '+' and '-' buttons on the touch panel to set your desired temperature. The display will show the current temperature. Press the 'MODE' button to toggle between Fahrenheit (°F) and Celsius (°C).

4.3 Interior LED Light

Press the light bulb icon on the control panel to turn the interior blue LED light on or off. This light is designed not to degrade beverages.

Your browser does not support the video tag.

Video 4.1: A short demonstration showing the adjustable temperature settings and the interior LED lights of the beverage fridge.

4.4 Shelf Configuration

The fridge comes with 3 removable shelves and 5 optional slots, allowing you to customize the interior space to accommodate various bottle and can sizes.

5. MAINTENANCE AND CARE

5.1 Cleaning

Regularly clean the interior and exterior of the fridge with a mild detergent and soft cloth. Ensure the appliance is unplugged before cleaning. Do not use abrasive cleaners or solvents.

5.2 Defrosting

This appliance features a frost-free defrost system, minimizing the need for manual defrosting.

5.3 Door Seal

The glass door is equipped with a low-e coating and a high-density door seal to prevent cold air from escaping and warm air from entering. Regularly inspect the door seal for any damage and ensure it is clean for optimal efficiency.

5.4 Door Reversal (if applicable)

The door hinges can be reversed to open from the opposite side if needed. Refer to the detailed instructions in the full user manual for this procedure.

Your browser does not support the video tag.

Video 5.1: A demonstration of the door replacement process, which can be used for reversing the door swing direction.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; circuit breaker tripped; temperature set too high.	Ensure plug is secure; reset circuit breaker; lower temperature setting.
Temperature is not cold enough.	Door opened too frequently; door not closed properly; poor ventilation; excessive items.	Minimize door openings; check door seal; ensure proper clearance; do not overfill.
Appliance is noisy.	Appliance not level; loose parts; normal operating sounds.	Adjust leveling leg; check for loose items; gurgling/hissing sounds are normal.
Interior light not working.	Light switch off.	Press the light button on the control panel to turn it on.

7. SPECIFICATIONS

- **Brand:** TehanId
- **Model:** TehanId001
- **Capacity:** 3.2 Cubic Feet (approx. 128 cans or 26 wine bottles)
- **Dimensions (D x W x H):** 18.5" x 17.5" x 32.7"
- **Item Weight:** 54 pounds
- **Temperature Range:** 35-65°F (2-18°C)
- **Voltage:** 115 Volts (AC)
- **Annual Energy Consumption:** 181 Kilowatt Hours Per Year
- **Noise Level:** Less than 36 decibels
- **Defrost System:** Frost Free
- **Shelves:** 3 removable wire shelves
- **Door Material:** Glass
- **Certification:** ETL

8. WARRANTY AND CUSTOMER SUPPORT

TehanId provides at least a one-year after-sales service guarantee for this product. If you encounter any issues or have questions during

usage, our 24-hour online customer service team is available to assist you.

To contact customer service:

1. Log in to your Amazon account.
2. Select "Your Orders".
3. Find the order ID for your Tehanld Beverage Fridge.
4. Click "Contact Seller".

Please note: If initiating a return, a prepaid return label will be provided. Do not return the item yourself, as we are not responsible for any incurred costs.