

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK 120 x 60 cm Electric Height Adjustable Desk User Manual

SANODESK B0D1FRQW5V

SANODESK 120 x 60 cm Electric Height Adjustable Desk User Manual

Model: B0D1FRQW5V

IMPORTANT SAFETY INFORMATION

Please read this manual carefully before using the desk. Failure to follow these instructions may result in injury or damage to the product.

- Ensure the desk is assembled correctly and all fasteners are tightened before use.
- Do not overload the desk. The maximum load capacity is 60 kg.
- Keep children and pets away from the desk during operation to prevent accidents.
- Ensure there are no obstructions in the desk's path when adjusting height.
- Do not sit or stand on the desk.
- Disconnect power before cleaning or performing any maintenance.

PRODUCT OVERVIEW

The SANODESK 120 x 60 cm Electric Height Adjustable Desk is designed to promote a healthy work environment by allowing seamless transitions between sitting and standing positions. It features a robust construction, flexible height adjustment, and quiet operation.



Image: The SANODESK electric height adjustable desk, showcasing its spacious black tabletop and sturdy black legs, equipped with a control panel for height adjustments. Various office items like a laptop, monitor, headphones, and a bag are displayed on and around the desk.



Image: A SANODESK electric height adjustable desk positioned in a modern home office. The desk is black, with two monitors, a keyboard, and a mouse. A white filing cabinet is to the left, and a plant is to the right, illustrating the desk's integration into a living space.

SETUP INSTRUCTIONS

Follow these steps to assemble your SANODESK electric height adjustable desk:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packing list are present and undamaged.
2. **Assemble Legs:** Attach the desk legs to the tabletop according to the provided diagrams. Ensure all screws are securely fastened.
3. **Install Control Panel:** Mount the control panel to the underside of the desk in the designated area. Connect the motor and power cables to the control panel.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.
5. **Initial Calibration:** Perform the initial calibration as described in the operating instructions to ensure proper height adjustment functionality.

OPERATING INSTRUCTIONS

Your SANODESK features an intuitive control panel for easy height adjustment and memory functions.



Image: A close-up view of the SANODESK desk's control panel, showing an LED display indicating the current height (75.6 units). Buttons for UP/DOWN, Sit/Stand, Child Lock, and Memory Function are clearly visible, highlighting the manual control for personalized workspace.

Control Panel Functions:

- **LED Display:** Shows the current height of the desk.
- **UP/DOWN Buttons (▲ / ▼):** Press and hold to manually adjust the desk height up or down.
- **Sit/Stand Button:** Quickly switch between pre-set sitting and standing heights.
- **Child Lock:** Activates or deactivates the child lock feature to prevent accidental adjustments.
- **Memory Function (1, 2, 3, 4):** Save up to four preferred height settings. To save a height, adjust the desk to the desired height, then press the 'M' button followed by the desired number (1-4). To recall a saved height, simply press the corresponding number button.

Height Adjustment:

The desk can be adjusted between 73 cm and 122 cm to accommodate various user heights and preferences.



Image: An illustration depicting the smooth and quiet movement of the desk. Red arrows indicate upward movement, emphasizing the effortless height adjustment feature.

Quiet Operation:

The SANODESK is equipped with silent motors, ensuring noise levels are below 40 decibels during operation. This allows for a peaceful work environment without disturbance.

I Reliable Support Up To **60kg**



Image: A graphic illustrating the low noise level of the SANODESK desk (50dB) compared to a normal voice (60dB) and city traffic (80dB). A cat sleeping peacefully on the desk further emphasizes the quiet operation.

Weight Capacity:

The desk is designed to support a maximum load of 60 kg, making it suitable for various setups including multiple monitors and office equipment.




Image: The SANODESK desk demonstrating its reliable support capacity, with three kettlebells and a dumbbell placed on its surface, indicating a total weight of 60kg.

MAINTENANCE

To ensure the longevity and optimal performance of your SANODESK desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surface and legs with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Management:** Periodically check and organize cables to prevent tangles and ensure smooth operation of the height adjustment mechanism.
- **Fastener Check:** Occasionally check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Obstruction Clearance:** Always ensure there are no objects obstructing the desk's movement path, especially underneath the desk, to prevent damage to the motor or items.

TROUBLESHOOTING

If you encounter any issues with your SANODESK electric height adjustable desk, refer to the following common troubleshooting tips:

- **Desk Not Moving:**
 - Check if the power cord is securely plugged into both the desk and the wall outlet.
 - Ensure the child lock is not activated.
 - If an error code appears on the LED display, consult the specific error code section (if available in a more detailed manual) or contact customer support.
- **Uneven Movement:**
 - Ensure the desk is not overloaded beyond its 60 kg capacity.
 - Check for any obstructions under the desk or along the legs.
 - Perform a recalibration if the issue persists (refer to specific recalibration steps if provided with the product).
- **Unusual Noises:**
 - Verify that all screws and bolts are tightened.
 - Ensure no cables or objects are rubbing against moving parts.

If the problem persists after attempting these solutions, please contact SANODESK customer support for further assistance.

SPECIFICATIONS

Feature	Specification
Brand	SANODESK
Model	B0D1FRQW5V
Color	Black
Product Dimensions	60 x 120 x 73 cm (Depth x Width x Min Height)
Adjustable Height Range	73 cm to 122 cm
Material	Engineered Wood (Tabletop), Alloy Steel (Base)
Weight Capacity	60 kg
Item Weight	20.4 Kilograms
Special Features	Electric, Adjustable, Memory Function, Child Lock, Quiet Operation (<40dB)
First Available Date	16 April 2024

WARRANTY AND SUPPORT

For warranty information and customer support, please contact the seller, FLEXISPOT GmbH, directly through your Amazon purchase history or their official website. Keep your proof of purchase for any warranty claims. For general inquiries or technical assistance, you may also visit the official SANODESK website or refer to the contact information provided with your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question