



Manuals+



[Manuals.plus](#) /

› [Urban Deco](#) /

› Urban Deco Premium Aluminum Bike Repair Stand User Manual - Model UD-350ZXCXLT-slv-1pk

Urban Deco UD-350ZXCXLT-slv-1pk

Urban Deco Premium Aluminum Bike Repair Stand User Manual

Model: UD-350ZXCXLT-slv-1pk

INTRODUCTION

Thank you for choosing the Urban Deco Premium Aluminum Bike Repair Stand. This stand is designed to provide a stable and convenient platform for all your bicycle maintenance and repair needs. Constructed from robust aluminum alloy, it supports bicycles up to 50 kg (110 lbs) and features an adjustable height, a 360° rotating clamp, and an integrated tool tray for an efficient and comfortable working experience.



Image: The Urban Deco Bike Repair Stand with a bicycle securely mounted, demonstrating its stability and readiness for maintenance tasks.



Image: The repair stand demonstrating its capacity to support bicycles up to 110 lbs (50 kg).

SAFETY INSTRUCTIONS

- Always ensure the stand is placed on a flat, stable, and non-slip surface before mounting a bicycle.
- Do not exceed the maximum weight capacity of 50 kg (110 lbs). Overloading can cause instability and damage.
- Ensure the bicycle is securely clamped before performing any work. Check the clamp's tightness regularly.
- Keep hands and clothing clear of moving parts, especially when adjusting height or rotating the clamp.
- Do not leave children or pets unattended near the repair stand.
- Always wear appropriate safety gear, such as gloves and eye protection, when performing maintenance.
- When folding or unfolding the stand, be mindful of pinch points.

PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Main Stand Assembly (pre-assembled base and vertical pole)
- Bicycle Clamp Head
- Tool Tray
- Anti-Rolling Handlebar Rod
- Assembly Hardware (bolts, knobs)
- User Manual

SETUP

Follow these steps to assemble your Urban Deco Bike Repair Stand:

1. **Unfold the Base:** Carefully unfold the legs of the stand until they are fully extended and locked into position, forming a stable tripod or quad-pod base.
2. **Attach the Clamp Head:** Insert the bicycle clamp head into the top of the main vertical pole. Secure it using the provided knob or bolt, ensuring it is tight and stable.
3. **Install the Tool Tray:** Slide the tool tray onto the vertical pole at a convenient height. Secure it with its locking mechanism, typically a quick-release lever or screw.
4. **Attach Handlebar Rod (Optional):** If desired, attach the anti-rolling handlebar rod to the main pole and the bicycle's handlebars once the bike is mounted.

Urban Deco Bike Repair Stand

Your Essential Bike Maintenance Partner!



Image: A fully assembled Urban Deco Bike Repair Stand with a bicycle mounted, illustrating the complete setup.

Foldable Design

Easy Storage & Space Efficient!



Image: The bike repair stand in its folded configuration, demonstrating its compact design for easy storage.

OPERATING INSTRUCTIONS

Mounting Your Bicycle

1. **Adjust Clamp Opening:** Open the clamp jaws by rotating the adjustment knob until they are wide enough to accommodate your bicycle's frame or seat post.
2. **Position Bicycle:** Carefully lift your bicycle and position its frame or seat post between the open clamp jaws.
3. **Secure Clamp:** Close the clamp jaws and tighten the adjustment knob until the bicycle is held firmly and securely. Do not overtighten, as this can damage the frame. Ensure the bike is balanced.

Ergonomic Design, 360° Rotation

Maintenance Made Easy & Comfortable!



Image: A bicycle mounted on the stand, highlighting the 360° rotating clamp feature for versatile positioning.

Adjusting Height

The stand features an adjustable height mechanism for ergonomic working positions:

- Loosen the quick-release lever or knob on the vertical pole.
- Raise or lower the upper section of the stand to your desired working height (up to 160 cm / 63 inches).
- Securely tighten the quick-release lever or knob to lock the height in place.

Height Adjustable up to 63 inches

No More Bending or Squatting!



Image: A visual representation of the stand's adjustable height feature, reaching up to 63 inches (160 cm) for comfortable use.

Using the 360° Rotating Clamp

The clamp head can rotate 360° to allow access to all parts of your bicycle:

- With the bicycle securely clamped, loosen the rotation knob located on the clamp head.
- Rotate the bicycle to the desired angle.
- Tighten the rotation knob firmly to lock the bicycle in position.

Utilizing the Integrated Tool Tray

The attached tool tray keeps your tools and small parts organized and within easy reach:

- Place screws, nuts, wrenches, and other small items in the designated compartments of the tray.
- Some trays may feature magnetic sections to prevent small metal parts from rolling away.

Handy Tool Tray

Keep Your Tools Organized and Within Reach!



Image: A detailed view of the integrated tool tray, showing its compartments filled with various bicycle repair tools and small components.

Using the Anti-Rolling Handlebar Rod

The handlebar rod prevents the front wheel and handlebars from turning during maintenance, providing greater stability:

- Extend the handlebar rod to the appropriate length.
- Attach one end to the main vertical pole of the stand and the other end to your bicycle's handlebars or front fork.
- Ensure it is securely fastened to prevent unwanted movement.

Anti-Rolling Handlebar Rod

Quicker repairs. No more bike wobbling.



Image: Illustrations demonstrating the proper attachment of the anti-rolling handlebar rod to both the bicycle and the repair stand for enhanced stability.

MAINTENANCE

- **Cleaning:** Wipe down the stand with a damp cloth after each use to remove dirt, grease, and grime. Avoid abrasive cleaners.
- **Lubrication:** Periodically apply a light lubricant to the height adjustment mechanism and clamp rotation points to ensure smooth operation.
- **Inspection:** Regularly inspect all bolts, knobs, and quick-release levers for tightness. Tighten any loose fasteners. Check for any signs of wear or damage to the aluminum frame or plastic components.
- **Storage:** When not in use, fold the stand for compact storage in a dry, clean area to prolong its lifespan.

TROUBLESHOOTING

- **Stand is unstable:**
 - Ensure all legs are fully extended and locked.
 - Verify the stand is on a flat, level surface.
 - Check that the bicycle's weight does not exceed the 50 kg (110 lbs) capacity.
 - Ensure the bicycle is balanced in the clamp.
- **Clamp not holding bicycle securely:**
 - Tighten the clamp adjustment knob further.
 - Ensure the clamp jaws are clean and free of grease.
 - Avoid clamping on irregular or delicate frame parts; use the seat post or a robust frame tube.
- **Height adjustment is stiff:**
 - Loosen the quick-release lever completely before adjusting.
 - Clean the inner and outer poles to remove any dirt.
 - Apply a small amount of silicone-based lubricant to the sliding surfaces.

SPECIFICATIONS

Model Number:	UD-350ZXCXLT-slv-1pk
Material:	Aluminum Alloy
Maximum Load Capacity:	50 kg (110 lbs)
Adjustable Height:	Up to 160 cm (63 inches)
Clamp Rotation:	360 degrees
Item Weight:	5.79 kg (12.76 lbs)
Dimensions (L x W x H):	101.6 x 81.3 x 160 cm (40 x 32 x 63 inches)
Color:	Silver
Special Features:	360° Rotating Support, Integrated Tool Tray, Ergonomic Height Adjustment

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Urban Deco customer service through the retailer where the product was purchased. Please have your model number (UD-350ZXCXLT-slv-1pk) and purchase details ready.

For further assistance, you may visit the [Urban Deco brand page](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D1FS8M36>

More documents and user manuals: **<https://manuals.plus/>**