Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > BoyKeep /
- > BoyKeep 2K Wi-Fi Indoor Camera User Manual

BoyKeep K30

BoyKeep 2K Wi-Fi Indoor Camera User Manual

Model: K30 | Brand: BoyKeep

1. Introduction

This manual provides detailed instructions for setting up, operating, and maintaining your BoyKeep 2K Wi-Fi Indoor Camera. Designed for indoor surveillance, this camera offers high-resolution video, two-way audio, motion detection, and versatile storage options, making it ideal for monitoring pets, babies, or general home security.



Figure 1: BoyKeep 2K Wi-Fi Indoor Camera (White model).

2. PACKAGE CONTENTS

- BoyKeep 2K Wi-Fi Indoor Camera (Model K30)
- Power Adapter
- USB Power Cable
- Mounting Accessories
- User Manual (this document)

3. SETUP GUIDE

3.1 Initial Power-Up

- 1. Unpack the camera and all accessories.
- 2. Connect the USB power cable to the camera's power port and the power adapter.
- 3. Plug the power adapter into a standard electrical outlet. The camera will power on and initiate its self-test.
- 4. Wait for the camera's indicator light to flash, indicating it is ready for connection.

3.2 App Installation and Account Creation

- 1. Download the "BoyKeep" app from your smartphone's app store (available for Android and iOS).
- 2. Open the app and follow the on-screen instructions to create a new account or log in if you already have one.

3.3 Connecting to Wi-Fi

- 1. In the BoyKeep app, tap the "+" icon to add a new device.
- 2. Select your camera model from the list.
- 3. Follow the app's instructions to connect the camera to your Wi-Fi network. The camera supports both 2.4 GHz and 5 GHz Wi-Fi bands.
- 4. Ensure your smartphone is connected to the same Wi-Fi network you intend to connect the camera to.
- 5. Scan the QR code displayed on your phone screen with the camera lens when prompted. Hold the phone approximately 15-20 cm (6-8 inches) from the camera.
- 6. Once connected, the camera's indicator light will turn solid, and you will hear a confirmation sound.



Figure 2: Illustrates the camera's 355° horizontal pan and 95° vertical tilt capabilities, along with key features like motion tracking, two-way audio, 2K video, and night vision.

4. OPERATING INSTRUCTIONS

4.1 Live View and Pan/Tilt Control

- Open the BoyKeep app and select your camera from the device list to access the live view.
- Use the directional controls within the app to pan the camera horizontally (355°) and tilt it vertically (95°) to adjust the viewing angle.



Figure 3: The camera offers a wide 360-degree coverage, allowing comprehensive monitoring of your space.

4.2 Two-Way Audio

- From the live view, tap the microphone icon to speak through the camera's speaker.
- Tap the speaker icon to listen to audio from the camera's surroundings.



Figure 4: The camera supports two-way audio, enabling communication with individuals near the camera.

4.3 Motion Detection and Alerts

- Enable motion detection in the app settings to receive real-time alerts on your smartphone when motion is detected.
- Adjust sensitivity levels and set specific monitoring zones to minimize false alarms.
- The camera can automatically track detected motion and record video clips.



Controlla il collegamento al Cloud

Vai su [lo] -> [Il mio servizio cloud] per verificare lo stato.

2 Abilita la registrazione su Cloud

Vai su [Impostazioni] -> [Memoria] e abilita [Registra su Cloud].

3 Imposta la sorgente video

Scegli la sorgente dati in [Impostazioni] -> [Memoria], oppure clicca sul pulsante della scheda SD nella pagina live.

Figure 5: The camera features intelligent AI detection and tracking for people and pets, capturing key moments.

4.4 Night Vision

- The camera automatically switches to night vision mode in low-light conditions using its infrared LEDs.
- This provides clear black-and-white video footage up to 10 meters in complete darkness.




Figure 6: The camera provides clear 24-hour crystal-clear vision, including effective night vision.

4.5 Recording and Storage Options

- Cloud Storage: The camera offers free cloud storage for 12-second event clips over the last 24 hours (requires activation in the app). This provides a secure backup.
- Micro SD Card Storage: Insert a Micro SD card (up to 128 GB, not included) into the camera's slot for continuous recording or event-triggered recording.




Figure 7: Overview of versatile storage options, including free cloud storage for 12-second event clips and 24/7 recording support via Micro SD card (up to 128GB, not included).

4.6 Enabling Cloud Recording (App Instructions)

- 1. Open the BoyKeep app and select your camera.
- 2. Go to [I] \rightarrow [My Cloud Service] to check the status.
- 3. Navigate to [Settings] \rightarrow [Memory] and enable [Record to Cloud].
- 4. Choose your video source from [Settings] \rightarrow [Memory], or click the SD card button on the live page.

Your browser does not support the video tag.

Video 2: Shows the BoyKeep indoor camera in action, highlighting its features and functionality.

5. MAINTENANCE

- Cleaning: Gently wipe the camera lens and body with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Software Updates:** Regularly check the BoyKeep app for firmware updates to ensure optimal performance and security.
- **Placement:** Ensure the camera is placed on a stable surface or securely mounted to prevent accidental falls. Avoid placing it in direct sunlight or near heat sources.

6. TROUBLESHOOTING

Issue	Possible Cause / Solution
Camera offline	Check Wi-Fi connection, ensure camera is powered on, restart camera and router.
Cannot connect to Wi-Fi	Ensure correct Wi-Fi password, camera is within router range, and you are connecting to a supported 2.4GHz or 5GHz network. Try resetting the camera.
Poor video quality	Check network speed, ensure lens is clean, adjust camera placement for better lighting.
Motion alerts not received	Verify motion detection is enabled in app settings, check notification settings on your phone, ensure app is running in the background.
Two-way audio not working	Check microphone and speaker settings in the app, ensure volume is up on your phone and camera.

7. SPECIFICATIONS

Feature	Detail
Model Number	K30
Resolution	2K (1296p)
Pan Angle	355°
Tilt Angle	95°
Connectivity	Wi-Fi (2.4GHz & 5GHz)
Night Vision Range	Up to 10 meters
Storage Options	Cloud Storage, Micro SD Card (up to 128GB)

Feature	Detail
Power Source	Wired Electric (5V, 3W)
Dimensions (LxWxH)	8.38 x 8.38 x 16.26 cm
Weight	310 g
Usage	Indoor

8. WARRANTY AND SUPPORT

BoyKeep provides a 24-month warranty for this product. For any issues, questions, or suggestions, please contact BoyKeep customer support. They aim to provide 100% satisfactory solutions within 3 working days. You can typically find support contact information within the BoyKeep app or on the official BoyKeep website.

© 2024 BoyKeep. All rights reserved.

Related Documents - K30



BoyKeep Wi-Fi Smart Camera Manual Guide

A comprehensive manual guide for the BoyKeep Wi-Fi Smart Camera, covering app download, account login, device setup via scanning code and AP hotspot, features, FAQs, and important notes.



BoyKeep Smart Wi-Fi Camera User Manual

A comprehensive user manual for the BoyKeep Smart Wi-Fi Camera, detailing setup, connection, features, FAQs, and important notes for optimal usage.



Boykeep K30 Pet Camera: Instruction Manual and Setup Guide

Comprehensive instruction manual for the Boykeep K30 Pet Camera. Learn how to download the BoyKeep app, log in, add your device via QR code or Bluetooth, use live view features, understand reset procedures, safety precautions, FAQs, and warranty information.



BoyKeep K30 Pet Camera User Manual

User manual for the BoyKeep K30 Pet Camera, detailing app download, device setup via Wi-Fi hotspot or QR code scanning, features, troubleshooting, and important notes.

