

[manuals.plus](#) /› [MoKo](#) /› **MoKo Portable Blender User Manual****MoKo Portable Blender**

# MoKo Portable Blender User Manual

Model: Portable Blender

Brand: MoKo

## INTRODUCTION

Thank you for choosing the MoKo Portable Blender. This powerful and versatile personal blender is designed for convenience, allowing you to prepare fresh shakes and smoothies wherever you are. With its 300W motor, 6-blade system, and USB-rechargeable battery, it's perfect for a healthy lifestyle on the go. Please read this manual carefully before use to ensure safe and optimal operation.



Image: The MoKo Portable Blender, black in color, filled with various fruits and ice cubes, surrounded by splashes of water and fresh produce, highlighting its blending capabilities.

## IMPORTANT SAFETY PRECAUTIONS

To reduce the risk of injury or damage, always follow basic safety precautions when using electrical appliances, including the following:

- Read all instructions before using the blender.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- Keep hands and utensils out of the container while blending to prevent severe injury to persons or damage to the blender.
- The blender features a magnetic sensor safety mechanism. It will only operate when the lid is properly installed and securely tightened. Ensure the lid is fully aligned and tightened before attempting to blend.
- Do not blend hot liquids, as pressure buildup may cause the lid to eject and result in burns.
- Do not overfill the blender. Always adhere to the MAX FILL line indicated on the cup.

- This product is BPA-free, ensuring safe drinking.
- Keep out of reach of children.

## PRODUCT COMPONENTS

Familiarize yourself with the parts of your MoKo Portable Blender:



Image: An exploded diagram showing the individual components of the MoKo Portable Blender, including the base with power button and Type-C charging port, 6 stainless steel blades, food-grade PCTG 800ml cup, drinking mouth, to-go cap, and removable silicone straw.

- **Base:** Contains the 300W motor, power button, and Type-C charging port.
- **6 Stainless Steel Blades:** Durable blades designed for efficient blending.
- **Food Grade PCTG 800ml Cup:** The main blending container, made from BPA-free material.

- **Food Grade PCTG Handle:** Integrated into the cup for easy portability.
- **To-go Cap:** Secure lid for the cup, featuring a drinking mouth.
- **Removable Silicone Straw:** For convenient drinking directly from the cup.

## SETUP AND FIRST USE

Before first use, ensure the blender is fully charged and all components are clean. Follow these steps to set up your blender:

1. **Charge the Blender:** Connect the included Type-C charging cable to the charging port on the base and a suitable power source (laptop, power bank, car charger). The indicator light will show charging status. A full charge provides approximately 15 blending cycles.
2. **Clean Components:** Wash the cup, lid, and straw with warm soapy water. Rinse thoroughly. The base should only be wiped with a damp cloth.
3. **Assemble:** Ensure the blades are securely attached to the base.

## Preparing for Blending:



Image: A five-step visual guide demonstrating how to prepare the blender: 1. Add fruit or protein powder to the blender. 2. Pour in milk or water (do not exceed the MAX volume line). 3. Tighten blender cover, double-click the button to start. 4. Turn it over and shake. 5. Enjoy directly or through the included straw.

1. **Add Ingredients:** Place your desired fruits, vegetables, or protein powder into the blending cup. For best results, cut ingredients into small pieces (approx. 1 inch or less).
2. **Add Liquid:** Pour in milk, water, or other liquid. *Do not exceed the MAX FILL line (28 oz / 800ml)* to prevent overflow and ensure proper blending.
3. **Secure the Lid:** Align the lid with the cup and twist it securely until it clicks into place. The magnetic sensor ensures the blender will not operate unless the lid is correctly installed.

## OPERATING INSTRUCTIONS

Your MoKo Portable Blender is equipped with a powerful 300W motor and 6 stainless steel blades,

capable of reaching 22000 RPM for efficient blending.

## Blending Process:

1. After adding ingredients and securing the lid, double-click the power button on the base to start blending.
2. For optimal blending, especially with ice or frozen fruits, turn the blender upside down or tilt it gently during operation to ensure all ingredients come into contact with the blades.
3. The blending cycle typically lasts for a set duration (e.g., 30 seconds) or until you double-click the power button again to stop it.
4. Once blending is complete, you can drink directly from the cup using the included straw or pour your beverage into another container.

## Official Product Video:

Your browser does not support the video tag.

Video: This official product video demonstrates the MoKo Portable Blender in action, showcasing its ability to blend various ingredients into smooth beverages. It highlights the ease of use and portability of the device.

## Versatile Usage:

- **Smoothies & Shakes:** Easily create creamy fruit smoothies and rich milkshakes.
- **Ice Crushing:** The powerful motor and blades can turn ice cubes into snow for refreshing iced drinks.
- **Protein Shakes:** A great companion for fitness enthusiasts to prepare protein drinks after workouts.
- **Juices:** Quickly make fresh, healthy juices.



### Yummy & Creamy Smoothies

Make delicious smoothies for your loved ones with the MoKo Blender. Make family time more enjoyable and memorable

Image: A family enjoying delicious smoothies made with the MoKo Blender, emphasizing its role in making family time more enjoyable and memorable.

## MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your MoKo Portable Blender.

### Self-Cleaning Function:

## Easy to Clean, Save Your Time




Image: A three-step visual guide demonstrating the self-cleaning function: 1. Add a drop of soap. 2. Pour in some water. 3. Start the blender for self-cleaning.

1. Add a small amount of water and a drop of dish soap to the blending cup.
2. Secure the lid and double-click the power button to activate the self-cleaning cycle.
3. Rinse the cup thoroughly with clean water.

### Manual Cleaning:

- The blending cup and lid are IP67 waterproof, allowing them to be rinsed directly under water.
- Do not immerse the motor base in water. Wipe it clean with a damp cloth.
- Use the provided straw cleaning brush to keep the straw clean.
- Ensure all parts are completely dry before storing.

## TROUBLESHOOTING

If you encounter issues with your MoKo Portable Blender, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Lid not securely tightened.	Ensure the lid is fully aligned and twisted until it clicks into place. The magnetic sensor prevents operation if not properly sealed.
Blender does not start.	Insufficient battery charge.	Charge the blender for at least 2-3 hours until fully charged.
Ingredients are not blending smoothly.	Too many ingredients or large pieces.	Do not exceed the MAX FILL line. Cut ingredients into smaller pieces (approx. 1 inch). Add more liquid if necessary.
Blender stops during operation.	Overload protection activated.	Remove some ingredients, add more liquid, or cut ingredients smaller. Restart the blender.

Problem	Possible Cause	Solution
Leaking from the lid.	Lid not properly sealed or gasket misplaced.	Ensure the lid is tightly screwed on and the silicone gasket is correctly seated in the lid.

## SPECIFICATIONS

**Brand:** MoKo

**Model:** Portable Blender

**Color:** Black

**Special Feature:** Portable, 300W, USB Rechargeable, Ergonomic Handle, 28 OZ

**Capacity:** 800 Milliliters (28 oz)

**Product Dimensions:** 3"D x 3"W x 6"H

**Included Components:** 1 \* Personal Blender

**Style:** Modern

**Recommended Uses:** Blending

**Power Source:** Battery Powered

**Number of Speeds:** 1

**Voltage:** 7.4 Volts

**Controls Type:** Touch

**Material Type Free:** BPA Free

**Blade Material:** Stainless Steel

**Item Weight:** 1.65 pounds

**UPC:** 840401435212

**Date First Available:** April 11, 2024


## WARRANTY AND CUSTOMER SUPPORT

MoKo is committed to providing professional after-sales service. If you have any questions or concerns regarding your MoKo Portable Blender, please do not hesitate to contact our customer service team. We are available 24/7 to assist you.

For support, please refer to the contact information provided with your purchase or visit the official MoKo website.

## Related Documents - Portable Blender

 <p>Please keep this User Manual for future use (This is very important)</p>	<p><a href="#">Portable Blender User Manual: Operation, Assembly, and Troubleshooting</a></p> <p>Comprehensive user manual for portable blenders, covering product structure, assembly, usage instructions, troubleshooting common malfunctions, and warranty information. Learn how to use your portable blender safely and effectively.</p>
<p><b>HOW TO CLEAN</b></p> <p><b>CAUTION</b> Make sure the blade stop running before cleaning</p> <p><b>CAUTION DO NOT</b> immerse the motor base into any other liquid</p> <ol style="list-style-type: none"><li>1. Separate/renew all parts from each other.</li><li>2. Clean the water base with a damp cloth and wipe dry.</li><li>3. Wash the cup by filling the cup to the MAX fill line with warm water and a few drops of dish detergent, place the cup on assembly onto the motor base, aligning the tabs on the cup onto the motor base. Turn on the power switch and the blade will start to spin. Turn base to start for a few seconds. Do not fill the cup more than MAX fill line or the blade will stop if it will overflow.</li><li>4. Once clean, remove the cup from the motor base. Rinse the cup, attachment and lid under running water. Allow all the parts to dry before storing.</li></ol> <p><b>HOW TO STORE</b></p> <p>Store the blender upright. Since the cups and the rest of the parts are fragile, store the parts in a place where they will not be damaged and won't cause a hazard.</p> <p>Place the product in a ventilated and dry place to avoid direct sunlight.</p>	<p><a href="#">USB Portable Blender: User Manual and Safety Guide</a></p> <p>Comprehensive instructions for operating, cleaning, and storing your USB Portable Blender, including essential safety warnings and product features for nutrient extraction.</p>
 <p>Model:H3</p> <p>MOKO TECHNOLOGY LTD. MOKO TECHNOLOGY LIMITED <a href="http://www.mokotech.com">www.mokotech.com</a></p>	<p><a href="#">MOKO H3 Bluetooth Beacon: Datasheet and Technical Specifications</a></p> <p>Detailed datasheet for the MOKO H3 Bluetooth Beacon, featuring a 3-axis accelerometer, iBeacon/Eddystone compatibility, long battery life, and configurable parameters for IoT applications. Includes physical characteristics, FCC statement, and technical support.</p>
 <p>Product Specification L03 Anchor Pro Version 1.0</p>	<p><a href="#">MOKO L03 Anchor Pro Bluetooth Beacon Product Specification</a></p> <p>Comprehensive product specification for the MOKO L03 Anchor Pro Bluetooth beacon, detailing hardware, installation, operation, and package information for MOKO's IoT location tracking devices.</p>
 <p>LW008-MTE User Guide Version 1.0</p>	<p><a href="#">LW008-MTE User Guide - MOKO TECHNOLOGY LTD.</a></p> <p>Comprehensive user guide for the MOKO LW008-MTE LoRaWAN Tracker. Learn about product features, specifications, installation, app configuration, communication protocols, and troubleshooting.</p>



## [MOKO LW005-MP APP Configuration Guide](#)

This guide provides detailed instructions on how to configure the MOKO LW005-MP LoRaWAN smart plug using the MKLoRa application. It covers installation, connection, LoRaWAN parameters, general settings, Bluetooth configuration, and device information.