Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo CT2305-WH

ChooChoo Modern LED Coffee Table (Model CT2305-WH) - Instruction Manual

For models: CT2305-WH (White)

1. Product Overview

This manual provides detailed instructions for the assembly, operation, and maintenance of your ChooChoo Modern LED Coffee Table, Model CT2305-WH. This rectangular coffee table features a high-gloss finish, integrated LED lighting, and a sliding storage drawer, designed for use in living rooms and bedrooms.



Image 1.1: The ChooChoo Modern LED Coffee Table (Model CT2305-WH) in a living room environment, showcasing its design and LED lighting.

2. Safety Information

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Always follow the assembly instructions carefully to avoid injury.
- Keep the table away from heat sources and do not expose it to direct sunlight or outdoor elements.
- Ensure the table is stable and properly anchored to prevent tipping or collapse.
- Do not place heavy objects on the table that could exceed its weight limit.
- Keep small parts and packaging materials away from children to prevent choking hazards.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Table panels (top, base, side supports)
- Drawer components
- LED light strip and remote control
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly tools (e.g., screwdriver)
- Instruction manual

4. Assembly Instructions

Assembly typically requires two people and takes approximately 1-2 hours. All necessary tools are included. Follow the numbered steps in the separate assembly guide provided with your product.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in your assembly guide to identify each piece.
2. **Assemble the Base Structure:** Begin by connecting the base panels according to the diagrams. Ensure all connections are secure.
3. **Install Drawer Rails:** Attach the drawer slides to the designated sections of the table base. Pay attention to the orientation of the rails.
4. **Assemble the Drawer:** Construct the drawer box using the provided hardware. Install the push-to-open latch mechanism.
5. **Insert Drawer:** Carefully slide the assembled drawer into the installed rails. Test the push-to-open function.
6. **Attach Support Pillars and Top Panel:** Secure the support pillars (often glass or acrylic) that elevate the top panel. Then, attach the main top panel to complete the table structure.
7. **Install LED Lighting:** Adhere the LED light strip to the designated area, typically under the top panel or within the open storage section. Connect it to the power source.
8. **Final Checks:** Ensure all screws are tightened, and the table is stable.




Image 4.1: Dimensions of the ChooChoo Modern LED Coffee Table (43.3"L x 22.6"W x 16.1"H) and material information (Thickened MDF, High gloss acrylic).



Image 4.2: Detail of the drawer and its sliding mechanism, which is part of the assembly process.

5. Operating Instructions

5.1. LED Lighting System

The integrated LED lighting system offers customizable ambiance.

- **Power On/Off:** Use the power button on the remote control to turn the LED lights on or off.
- **Color Selection:** The remote allows you to choose from 16 different colors. Press the corresponding color button to change the light color.
- **Flashing Modes:** Select from 4 flashing modes: Flash, Strobe, Fade, and Smooth. These modes cycle through colors or provide dynamic lighting effects.
- **Brightness Adjustment:** Use the brightness control buttons on the remote to increase or decrease the intensity of the LED lights.



Image 5.1: Examples of the 16 available LED colors and 4 flashing modes, controlled by the included remote.

5.2. Sliding Drawer

The coffee table features a large-capacity sliding drawer with a push-to-open latch mechanism.

- **Opening the Drawer:** Gently push the front of the drawer inward. The latch mechanism will release, and the drawer will pop out slightly, allowing you to pull it open.
- **Closing the Drawer:** Push the drawer firmly inward until you hear a click, indicating the latch has engaged and the drawer is securely closed.




Image 5.2: The coffee table's open storage area and the fully extended sliding drawer, demonstrating its storage capacity.

6. Maintenance and Care

To ensure the longevity and appearance of your coffee table, follow these care guidelines:

- **Cleaning:** The high-gloss surface is waterproof and scratch-resistant. Wipe clean with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials.
- **Dusting:** Regularly dust the table with a dry microfiber cloth to prevent buildup.
- **Spills:** Wipe up spills immediately to prevent potential staining, especially on the high-gloss finish.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters for drinks. Protect from excessive

moisture.

- **Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration over time.




Image 6.1: Detail of the high-gloss acrylic finish, highlighting its smooth and reflective surface.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Drawer does not close properly or pops open.	◦ Push-to-open latch mechanism misaligned or faulty. ◦ Drawer slides not installed correctly. ◦ Obstruction in the drawer path.	◦ Re-check the installation of the push-to-open latch according to the assembly guide. Ensure it is securely mounted and aligned with the drawer. ◦ Verify that the drawer slides are installed level and correctly on both sides. ◦ Remove any items that might be blocking the drawer's movement. ◦ If the latch is damaged, contact customer support for a replacement.
LED lights are not working.	◦ Power connection loose. ◦ Remote control battery depleted. ◦ LED strip or controller malfunction.	◦ Check all power connections to the LED strip and ensure they are firmly plugged in. ◦ Replace the battery in the remote control. ◦ Ensure the remote control is pointed directly at the LED receiver. ◦ If issues persist, contact customer support.
Table feels wobbly after assembly.	◦ Screws or fasteners are loose. ◦ Components not fully seated.	◦ Carefully re-tighten all screws and fasteners. Do not overtighten. ◦ Ensure all panels and supports are fully engaged and seated as per the assembly instructions.

8. Specifications

Feature	Detail
Brand	ChooChoo
Model Name	CT2305-WH
Color	White
Product Dimensions (D x W x H)	23.62" x 43.31" x 16.14"
Item Weight	58.75 Pounds
Material Type	Engineered Wood (MDF), High-gloss Acrylic
Number of Drawers	1
LED Lighting	16 colors, 4 flashing modes (Flash, Strobe, Fade, Smooth), Brightness adjustment
Assembly Required	Yes (Recommended 2 people, tools included)
Indoor/Outdoor Usage	Indoor

9. Warranty and Support

For warranty information, missing parts, or technical assistance, please contact ChooChoo customer service. Refer to

your purchase documentation for specific warranty terms and contact details.
You can often find support contact information on the manufacturer's website or through the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D1JWLHYY

More documents and user manuals: **https://manuals.plus/**