

[manuals.plus](#) /

› [YITAHOME](#) /

› [YITAHOME 4-Drawer Fabric Storage Tower \(Model MAYIHX7JhG\) Instruction Manual](#)

YITAHOME MAYIHX7JhG

YITAHOME 4-Drawer Fabric Storage Tower Instruction Manual

Model: MAYIHX7JhG

1. INTRODUCTION

Thank you for choosing the YITAHOME 4-Drawer Fabric Storage Tower. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage unit. Please read these instructions carefully before use and retain them for future reference.



Figure 1: YITAHOME 4-Drawer Fabric Storage Tower

2. SAFETY INFORMATION

To ensure safe use of this product, please observe the following:

- **Always install tip-over restraint:** Children have died from furniture tip-over. To reduce the risk of furniture tip-over, always install the tip-over restraint provided.
- **Do not allow children to stand, climb, or hang on drawers, doors, or shelves.**
- Ensure all parts are securely fastened before use.
- Do not overload drawers.
- Keep small parts away from children during assembly.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact YITAHOME customer service.

EASY ASSEMBLY

- ▶ Installation Kit Included
- ▶ Instruction Manual Attached



Figure 2: Easy Assembly Components

The package typically includes:

- Metal Frame components
- MDF Wooden Top
- 4 Fabric Drawers
- Plastic Handles
- Adjustable Plastic Feet
- Assembly Hardware (screws, Allen wrench)
- Anti-tip Kit
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward. Follow the detailed instructions provided in the included manual. An installation video is also available for visual guidance.

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
- 2. Assemble Frame:** Connect the metal frame components using the provided hardware. Ensure all connections are secure.
- 3. Attach Wooden Top:** Secure the MDF wooden top to the assembled metal frame.
- 4. Insert Drawers:** Unfold the fabric drawers and insert the bottom support panels. Place the assembled drawers into the frame.
- 5. Install Handles:** Attach the plastic handles to the front of each fabric drawer.
- 6. Adjust Feet:** Screw in the adjustable plastic feet at the bottom of the frame. Adjust them to ensure the unit is stable and level on uneven floors.
- 7. Install Anti-tip Kit:** For safety, securely attach the anti-tip kit to the wall and the storage tower as per the instructions.

Figure 3: Key Assembly Steps

Assembly Video

Your browser does not support the video tag.

Video 1: Overview of the YITAHOME 4-Drawer Storage Tower. This video demonstrates the product's features and general appearance.

Your browser does not support the video tag.

Video 2: YITAHOME Dresser for Bedroom. This video showcases the dresser in a bedroom setting, highlighting its suitability for various room types.

5. OPERATING INSTRUCTIONS

The YITAHOME Storage Tower is designed for versatile storage in various living spaces.

- Drawer Use:** The 4 deep fabric drawers provide ample space for clothes, accessories, toys, or other household items. Use the easy-pull plastic handles to open and close the drawers smoothly.
- Top Surface:** The sturdy MDF wooden top can be used to place lamps, books, decorative items, or other small objects.
- Placement:** Its sleek design and compact dimensions make it suitable for bedrooms, living rooms, hallways, entryways, and closets.




Figure 4: Drawer Capacity and Use

Figure 5: Estimated Storage Capacity

6. MAINTENANCE

Proper care will extend the life of your storage tower:


- **Cleaning the Fabric Drawers:** The durable non-woven synthetic fabric drawers are easy to maintain. Simply wipe clean with a damp cloth and allow to air dry. Do not machine wash or tumble dry.
- **Cleaning the Wooden Top:** Wipe the wooden top with a dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Frame Care:** The steel frame can be wiped with a damp cloth. Ensure it is dried thoroughly to prevent rust.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.




Waterproof Desktop



Abrasion Resistance



Wipe Clean with Wet Cloth



Adjustable Legs

Figure 6: Product Features and Care

7. TROUBLESHOOTING

If you encounter any issues with your YITAHOME Storage Tower, refer to the following common solutions:

Problem	Possible Cause	Solution
Unit is wobbly or uneven.	Uneven floor or feet not adjusted.	Adjust the plastic feet at the bottom of the frame until the unit is stable.
Drawers do not slide smoothly.	Drawer overloaded or improperly inserted.	Reduce the weight in the drawer. Ensure the drawer is correctly placed within its slot in the frame.
Missing parts during assembly.	Packaging error.	Contact YITAHOME customer service with your product model and a description of the missing part.

8. SPECIFICATIONS

- **Brand:** YITAHOME
- **Model Name:** Storage Dresser
- **Model Number:** MAYIHX7JhG
- **Color:** Cool Black Grey Ash
- **Product Dimensions:** 17.7" L x 11.8" W x 37.4" H
- **Drawer Dimensions:** 15.7" L x 11.2" W x 8.3" H
- **Number of Drawers:** 4
- **Item Weight:** 13 Pounds
- **Material:** Wood (MDF), Iron, Plastic, Metal, Steel, Fabric (Non-woven synthetic)
- **Assembly Required:** Yes
- **Product Care Instructions:** Wipe with Dry Cloth (for top), Wipe clean with a damp cloth and let air dry (for fabric drawers)

PRODUCT SIZE



Figure 7: Product Dimensions

9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official YITAHOME website or contact their customer service directly. Keep your purchase receipt and model number handy for faster service.

YITAHOME Official Website: [Visit YITAHOME Store on Amazon](#)

© 2024 YITAHOME. All rights reserved.